智 能 控 制 系 统 解 决 方 案 提 供 商
智能酒店客房控制系统 | 高端开关面板

INTELLIGENT CONTROL SYSTEM SOLUTION PROVIDER
SMART HOTEL ROOM CONTROL SYSTEM | HIGH-END SWITCH PANEL

SWITCH AND SOCKET

Brands listed on CCTV



COMPANY PROFILE
企业简介

本公司是一家从事电器开关、移动排插及建筑信息智能化产品的设计、开发、生产、销售、服务为一体的外贸出口型企业，公司注重新产品的开发和研制，积极引进国内外先进技术和设备，运用先进的生产工艺和优质的美国进口原材料，生产出了多种规格的家用电器，家庭信息接入箱及电器附件系列产品。

公司始终坚持以“用户至上，质量第一”的质量方针，质量就是生命。本公司员工一直坚持把质量作为生命工程来建设，严格按照ISO9001质量体系标准进行内部管理，使质量文化渗透到生产，营销服务到每一个领域，并成为了公司员工的一种自觉行为。

公司不断吸纳和培养适用现代企业管理的高级管理人才，全面导入CIS企业形象策划的战略工程，提升品牌文化。公司的系列产品通过了中国质量认证中心的ISO9001质量体系认证，电工类产品通过了中国国家强制性认证，公司走上了一条可持续发展的道路，公司始终坚持以市场为导向；以科技进步为支柱，以科学管理为动力，追求经济效益与社会效益的完美统一为目标。

公司竭诚为新老客户提供优质可靠的产品和满意的服务，不断促进公司的全面发展，与您共创辉煌，迈进知识经济的新时代。

The Company is engaged in an electrical switch and construction information intelligent product design development, production to sales, Services as one of the export-oriented enterprises, companies focuson the development of new products and research and development, actively introduce advanced at home and abroad Technology and equipment and use of advanced production technology and quality of U.S. Im ports of raw materials to produce a variety of specifications home Using electrical appliances, household electrical appliances and information access me annex series.

We always adhere to the "customer first, quality first" quality, quality is life. The company is now The staff has always insisted the quality of life as a project to build, in strict accordance with the ISO9001 quality system standards within the Department of Management, so that the quality of cultural infiltration in to production, and marketing services in one area and become a staff of the company Conscious action.

Companies continue to absorb and apply modern business management training of senior management personnel, a comprehensive strategy to import CIS corporate image The designated strategic project to enhance brand culture. The company adopted a series of products in China's ISO9001 quality certification center Quality System Certification, electrical products through China's national compulsory certification, the company embarked on a sustainable development The road, the company always adhere to market-oriented; scientific and technological progress as a pillar for the management of branches as a driving force, the pursuit of the Economic efficiency and social unity as the perfect target.

PARTNER 合作伙伴

HOWARD GOHNSON
豪生

W'HOTELS
W酒店

WESTIN
威斯汀

WYNDHAM
温德姆

SOFITEL
索菲特

ST REGIS
瑞吉

DAYSLNN
戴斯

RENAISSANCE
万丽

MANDARIN ORIENTAL
文华东方

HIL TON
希尔顿

Cont
目录-ents



AB-K 烤漆系列 Baking paint series

AB-K1PC雅白系列 PC white series P01/10
AB-K1烤漆珍珠白系列 Pearl white paint series P11/20
AB-K2烤漆香槟金系列 Lacquered champagne gold series P21/30
AB-K3烤漆摩卡黑系列 Baking paint mocha black series P31/40
AB-K4烤漆太空灰系列 Baking paint mocha black series P41/50

AB-L 铝镁合金/不锈钢 Aluminum magnesium alloy/stainless steel

AB-L不锈钢(金色)系列 Stainless steel (gold) series P51/60
AB-L铝镁合金(黑色)系列 Aluminum magnesium alloy(black) series P61/70
AB-L不锈钢(灰色)系列 Stainless steel (grey) series P71/80

AB-G 钢化玻璃系列 Tempered glass series

AB-G1钢化玻璃水晶白系列 Tempered glass crystal white series P81/90
AB-G2钢化玻璃香槟金系列 Tempered glass champagne gold series P91/100
AB-G3钢化玻璃爵士黑系列 Tempered glass jazz black series P101/110
AB-G4钢化玻璃火山灰系列 Tempered glass volcanic grey series P111/120
AB-G5钢化玻璃水晶蓝系列 Tempered glass crystal blue series P121/130

F71 钢化玻璃系列 Tempered glass series

F71玻璃水晶白系列 Glass crystal white series P131/140
F71玻璃火山灰系列 Glass pozzolanic series P141/150
F71玻璃香槟金系列 Glass champagne gold series P151/160
F71玻璃爵士黑系列 Glass jazz black series P161/170

电工附件 Electrician accessories

146快充系列 146 Fast charging series P171/172
酒店门牌系列 Hotel house number series P173/174
隐藏式地插 Concealed ground socket P175/176
隐藏式弹起地插 Concealed spring socket P177/180
开启式地板插 Open floor socket P181/182
内销地板插功能键 Internal floor insert function key P183
防水盒/暗盒 Waterproof box/cassette P184
桌面插座 Desktop socket P185
手提式工程插座箱 Portable engineering socket box P186

AB-K1 PC雅白 PC white

内外兼具
表里如一

Both inside and outside
be the same outside and inside

大晓板设计，声音清脆，手感舒适
顶级PC料灌注而成，确保产品质量卓越
开关内部结构科学严谨

Big seesaw design, crisp sound, comfortable feel
Made of top PC material to ensure excellent product quality
The internal structure of the switch is scientific and rigorous

Zigbee智能按键开关

Zigbee Intelligent button switch

Zigbee一开
¥ 950.00

Zigbee二开
¥ 1050.00

Zigbee三开
¥ 1150.00

二三极USB/Type-c+开关
¥ 190.00

语音/APP/轻触机械控制	情景模式/联动/定时	支持多款AL音响	涂鸦无线场景开关 (单火零火通用)
Voice /APP/ touch mechanical control	Scenario mode/Linkage/timing	Support a variety of AL audio	Doodle wireless scene switch (Single fire and zero fire universal)

AB-K1 PC white PC雅白

AB-K1-0001
大板16A一位开关单控(荧光灯) ¥:34.00
1 gang 1 way switch
大板16A一位开关双控(荧光灯) ¥:38.00
1 gang 2 way switch
大板16A一位开关多控(荧光灯) ¥:55.00
1 gang more way switch

AB-K1-0002
大板16A二位开关单控(荧光灯) ¥:44.00
2 gang 1 way touch switch
大板16A二位开关双控(荧光灯) ¥:50.00
2 gang 2 way touch switch
大板16A二位开关多控(荧光灯) ¥:78.00
2 gang 3 way touch switch

AB-K1-0003
大板16A三位开关单控(荧光灯) ¥:54.00
3 gang 1 way switch
大板16A三位开关双控(荧光灯) ¥:63.00
3 gang 2 way switch

AB-K1-0004
大板16A四位开关单控(荧光灯) ¥:65.00
4 gang 1 way switch
大板16A四位开关双控(荧光灯) ¥:81.00
4 gang 2 way switch

AB-K1-0005
大板16A一位开关单控 ¥:34.00
Large panel 16A 1 gang 1 way switch
大板16A一位开关双控 ¥:38.00
Large panel 16A 1 gang 2 way switch
大板16A一位开关多控 ¥:55.00
Large panel 16A 1 gang more way switch

AB-K1-0006
大板16A二位开关单控 ¥:44.00
Large panel 16A 2 gang 1 way touch switch
大板16A二位开关双控 ¥:50.00
Large panel 16A 2 gang 2 way touch switch
大板16A二位开关多控 ¥:78.00
Large panel 16A 2 gang 3 way touch switch

AB-K1-0007
大板16A三位开关单控 ¥:54.00
Large panel 16A 3 gang 1 way switch
大板16A三位开关双控 ¥:63.00
Large panel 16A 3 gang 2 way switch

AB-K1-0008
大板16A四位开关单控 ¥:65.00
Large panel 16A 4 gang 1 way switch
大板16A四位开关双控 ¥:81.00
Large panel 16A 4 gang 2 way switch

AB-K1-0009
大板16A百叶窗升降开关
Large panel louver window lifter switch
¥:60.00

AB-K1-0010
大板16A门控开关
Large panel gating switch
¥:48.00

AB-K1-0011
大板16A英式门控开关
Large panel British gating switch
¥:48.00

AB-K1-0012
大板16A门铃开关
Large panel doorbell switch
¥:48.00

AB-K1-0013
大板20A双极开关带指示灯 ¥:115.00
20A bipolar switch with neon
大板32A双极开关带指示灯 ¥:124.00
32A bipolar switch with neon

AB-K1-0014
大板45A双极开关带指示灯
45A bipolar switch with indicator light
¥:142.00

AB-K1-0015
大板16A三极插座
16A 3 pole socket
¥:43.00

AB-K1-0016
大板16A多功能插座
16A 3 pin universal socket
¥:49.00

AB-K1-0017
大板10A二三极插座
10A 5 pole socket
¥:37.30

AB-K1-0018
大板10A错位二三极插座
10A Two or three pole socket
¥:48.00

AB-K1-0019
大板16A多功能五孔插座
16A 5 pin MF socket
¥:51.00

AB-K1-0020
大板10A二二三极插座
10A 7 pole socket
¥:50.00

AB-K1-0021
大板13A方角插座
13A square corner socket
¥:49.00

AB-K1-0022
大板二位USB带16A多功能五孔插座
2 USB with 5 pin multi-function socket
¥:145.00

AB-K1-0023
大板16A一位开关单控带16A三极插座
1gang1 way swith and 16A 3 pole socket
¥:60.00
大板16A一位开关双控带16A三极插座
1gang2 way swith and 16A 3 pole socket
¥:62.00

AB-K1-0024
大板一位开关单控带10A二三极插座
1gang2 way switch and 16A 5 pole socket
¥:56.00
大板一位开关双控带10A二三极插座
1gang 2 way switch and 5 pole socket
¥:58.00

AB-K1-0025
大板10A二位开关单控带二三极插座
2 gang 1 way switch and 5 pole socket
大板10A二位开关双控带二三极插座
2 gang 2 way switch and 5 pole socket
¥:80.00



AB-K1-0026
大板一位开关带16A三极多功能插座
(带指示灯)
1 gang switch and 16A 3 pin multi-purpose socket with indicator lighe
¥:63.00

AB-K1-0027
大板一位双极开关带13A方角插座
(指示灯)
1 gang weitch and 13A square pin socket with indicator light
¥:63.00



AB-K1-0028
大板一位开关带15A圆孔插座
(带指示灯)
1 gang weitch and 15A 3 square pin socket with indicator light
¥:63.00



AB-K1-0029
大板一位开关带16A二三极多功能插座(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
¥:69.00

AB-K1-0030
大板一开13A多功能带双USB
(带指示灯)
1gang 13A switch and 16A 3 pin MF socket +2USB with neon
¥:155.00

AB-K1-0031
大板一开13A方插带双USB
(带指示灯)
1gang 13A square plug with 2USB(with neon)
¥:155.00

AB-K1-0032
大板16A德式插座
Large board 16A German socket
¥:55.00

AB-K1-0033
大板16A法式插座
Large plate 16A French socket
¥:55.00

AB-K1-0034
大板16A俄式插座
Large board 16A Russian socket
¥:55.00

AB-K1-0035
大板16A德式插座+二位USB
16A German socket+2 USB
¥:155.00

AB-K1-0036
大板16A法式插座+二位USB
16A French socket + 2 USB
¥:155.00

AB-K1-0037
大板16A德式插座+USB/type-c
Large board 16A German socket
+ USB / type-C
¥:155.00

AB-K1-0038
大板16A法式插座+USB/type-c
Large board 16A French socket
+ USB / type-C
¥:155.00

AB-K1-0039
大板一位电视插座
TV socket
¥:55.00

AB-K1-0040
大板一位电话插座 ¥:55.00
telephone socket
大板一位电脑插座 ¥:60.00
computer socket
大板一位电脑插座(超六类) ¥:106.00
computer socket(6)

AB-K1-0041
大板一位电视电话插座 ¥:82.00
TV + telephone socket
大板一位电视电脑插座 ¥:91.00
TV + computer socket
大板一位电视电脑插座(超六类) ¥:127.00
TV + computer socket(6)

AB-K1-0042
大板二位电视插座
Two TV socket
¥:82.00

AB-K1-0043
大板二位电话插座 ¥:82.00
Two telephone socket
大板二位电脑插座 ¥:109.00
Two computer socket
大板二位电脑插座(超六类) ¥:181.00
Two computer socket(6)
大板电话+电脑插座 ¥:91.00
telephone+computer socket
大板电话+电脑插座(超六类) ¥:127.00
telephone+computer socket(6)

AB-K1-0044
86型大板空白面板
Large plate Blank plate
¥:28.00

AB-K1-0045
小板16A一位开关单控 ¥:48.00
16A 1 gang 1 way switch
小板16A一位开关双控 ¥:52.00
16A 1 gang 2 way switch
小板16A一位开关多控 ¥:88.00
16A 1 gang more way switch

AB-K1-0046
小板16A二位开关单控 ¥:62.00
16A 2 gang 1 way switch
小板16A二位开关双控 ¥:68.00
16A 2 gang 2 way switch
小板16A二位开关多控 ¥:120.00
16A 2 gang more way switch

AB-K1-0047
小板16A三位开关单控 ¥:75.00
16A 3 gang 1 way switch
小板16A三位开关双控 ¥:84.00
16A 3 gang 2 way switch

AB-K1-0048
小板16A四位开关单控 ¥:88.00
16A 4 gang 1 way switch
小板16A四位开关双控 ¥:100.00
16A 4 gang 2 way switch

AB-K1-0049
小板16A三位开关多控
16A 3 gang 3 way switch
¥:140.00

AB-K1-0050
小板16A百叶窗升降开关
Small panel louver window lifter switch
¥:83.00

AB-K1-0051
小板16A门控开关
Small panel gating switch
¥:68.00

AB-K1-0052
小板16A英式门控开关
Small panel British gating switch
¥:68.00

AB-K1-0053
小板16A门铃开关
Small panel doorbell switch
¥:68.00

AB-K1-0054
小板16A拨动一位开关单控 ¥:108.00
1 gang 1 way toggle switch
小板16A拨动一位开关双控 ¥:114.00
1 gang 2 way toggle switch



AB-K1-0055
小板16A拨动二位开关单控 ¥:128.00
2 gang 1 way toggle switch
小板16A拨动二位开关双控 ¥:140.00
2 gang 2 way toggle switch

AB-K1-0056
小板16A拨动三位开关单控 ¥:148.00
3 gang 1 way toggle switch
小板16A拨动三位开关双控 ¥:166.00
3 gang 2 way toggle switch

AB-K1-0057
小板16A拨动四位开关单控 ¥:168.00
4 gang 1 way toggle switch
小板16A拨动四位开关双控 ¥:192.00
4 gang 2 way toggle switch

AB-K1-0058
小板20A双极开关带指示灯 ¥:128.00
20A swich with indicator light
小板45A双极开关带指示灯 ¥:158.00
45A swich with indicator light

AB-K1-0059
小板45A双极开关带指示灯
45A swich with indicator light
¥:148.00

AB-K1-0060
小板16A卷帘门复位开关
German socket
¥:108.00

AB-K1 PC white PC雅白

AB-K1-0061
小板16A德式插座
German socket
¥:58.00

AB-K1-0062
小板16A法式插座
French socket
¥:58.00

AB-K1-0063
小板16A俄式插座
Russian socket
¥:58.00

AB-K1-0064
小板16A以色列插座
Israel socket
¥:68.00

AB-K1-0065
小板16A意大利+德式插座
Italy+German socket
¥:68.00

AB-K1-0066
小板10A二极插座
10A 2 pole socket
¥:55.00

AB-K1-0067
小板10A二二极插座
10A Double 2 pole socket
¥:55.00

AB-K1-0068
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:61.00

AB-K1-0069
小板10A一位开关带二二极座
1gang switch and 4 pole socket
¥:71.00

AB-K1-0070
小板16A多功能三极插座
16A MF 3 pin socket
¥:58.00

AB-K1-0071
小板13A二三极多功能插座
5 pin multi-function socket
¥:65.00

AB-K1-0072
小板13A错位多功能二三极插座
13A dislocation multi-function double and triple-pole socket
¥:68.00

AB-K1-0073
小板13A方角插座
13A square corner socket
¥:58.00

AB-K1-0074
小板15A圆角插座
15A 3 round pins socket
¥:58.00

AB-K1-0075
小板15A美标扁三极插座
15A triode flat American standard socket
¥:58.00

AB-K1-0076
小板15A泰式插座
15A Thai socket
¥:58.00

AB-K1-0077
小板15A泰式六孔插座
Dislocation Thai 6 pin socket
¥:75.00

AB-K1-0078
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:66.00

AB-K1-0079
小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pins socket
¥:68.00

AB-K1-0080
小板一位开关带16A多功能插座
1 gang switch and 16A 3 pin MF socket
¥:68.00

AB-K1-0081
小板一位开关带13A方角插座
（带指示灯）
1 gang switch and 13A square pin socket with indicator light
¥:65.00

AB-K1-0082
小板一位开关带15A圆孔插座
（带指示灯）
1 gang switch and 15A 3 round pins socket with indicator light
¥:68.00

AB-K1-0083
小板一位开关带16A多功能插座
（带指示灯）
1 gang switch and 3 pin MF socket with light
¥:70.00

AB-K1-0084
小板一位开关带13A多功能五孔插座
（带指示灯）
1 gang switch and 5 pin multi-function socket with indicator light
¥:75.00

AB-K1-0085
小板16A德式插座带二位USB
2 USB witch German socket
¥:165.00

AB-K1-0086
小板16A法式插座带二位USB
2 USB witch French socket
¥:165.00

AB-K1-0087
小板16A德标插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:165.00

AB-K1-0088
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:165.00

AB-K1-0089
小板16A一位开关带德式插座
1 gang German socket
¥:68.00

AB-K1-0090
小板16A一位开关带法式插座
1 gang French socket
¥:68.00

AB-K1-0091
小板16A德式插座带防水
German socket and Waterproof belt
¥:75.00

AB-K1-0092
小板16A法式插座带防水
French socket and Waterproof belt
¥:75.00

AB-K1-0093
小板二位USB带13A方角插座（横）
2 USB with 13A square corner socket with swith
¥:170.00

AB-K1-0094
小板15A美标插座+USB+type-c
American Standard + USB / type-C
¥:170.00

AB-K1-0095
小板15A泰式插座+USB+type-c
15A Thai + USB / type-C
¥:170.00

AB-K1-0096
小板二位USB带13A方角插座
（带保护门）
2 USB with 13A square corner socket with flip cover
¥:170.00

AB-K1-0097
小板二位USB带13A多功能插座
（带保护门）
2 USB with 3 pin multi-purpose socket with flip cover
¥:170.00



AB-K1-0098
小板一位开关带二位USB带13A多功能插座（带指示灯）
1 gang switch with two USB and 13A multi-function socket
¥:175.00

AB-K1-0099
小板一位开关带二位USB带13A方角插座（带指示灯）
2 USB with 13A aquare comer socket with flip cover
¥:175.00

AB-K1-0100
小板13A多功能插座带USB+type-c
13A multi-function with type-C + USB
¥:170.00

AB-K1-0101
小板13A方角插座带USB+type-c
13A square angle band type-C + USB
¥:170.00

AB-K1-0102
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with Type-c+USB(with light)
¥:175.00

AB-K1-0103
小板二位USB带13A多功能插座带小开关（竖）
2 USB with Three very multi-purpose socket with switch
¥:175.00

AB-K1-0104
小板一位开关13A方插带Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:175.00

AB-K1-0105
小板二位USB带13A方角插座带小开关（竖）
2 USB with 13A square corner socket with switch
¥:175.00

AB-K1-0106
小板15A美式插座带二位USB
American Standard + 2USB
¥:170.00

AB-K1-0107
小板15A泰式插座带双USB
15A Thai + 2USB
¥:170.00



AB-K1-0108
小板13A多功能插座带二位USB（横）
13A multi-function socket belt with two-bit USB(horizontal)
¥:183.00

AB-K1-0109
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:163.00

AB-K1-0110
小板二位USB带10A二三极插座带开关
2 USB and 5 pin socket with switch
¥:173.00

AB-K1-0111
小板10五孔插座带USB +Type-C (10W)
10A 5 pole socket with USB type-C (10W)
¥:170.00
小板10五孔插座带USB +Type-C (18W)
10A 5 pole socket with USB type-C (18W)
¥:235.00



AB-K1-0112
小板一位开关带13A多功能五孔插座带USB
1 gang swich and 5 pin multi-function socket with USB and indicator light
¥:190.00

AB-K1-0113
小板13A二位USB带多功能五孔插座
2 USB with 5 pin multi-function socket
¥:163.00

AB-K1-0114
小板13A二位USB带多功能五孔插座带开关
2 USB with 5 pin multi-function socket with switch
¥:173.00

AB-K1-0115
13A多功能五孔带USB+TYPE-C (10W)
13A MF 5 pin socket USB+type-C (10W)
¥:170.00
13A多功能五孔带USB+TYPE-C (18W)
13A MF 5 pin socket USB+type-C (18W)
¥:235.00



AB-K1-0116
小板一位电视插座
TV socket
¥:65.00

AB-K1-0117
小板一位电话插座 ¥:65.00
telephone socket
小板一位电脑插座 ¥:78.00
computer socket
小板一位电脑插座（超六类）¥:118.00
computer socket(6)



AB-K1-0118
小板双电视插座
Two TV socket
¥:91.00

AB-K1-0119
小板双电话插座 ¥:91.00
Two telephone socket
小板双电脑插座 ¥:121.00
Two computer socket
小板二位电脑插座(超六类) ¥:181.00
Two computer socket(6)
小板电话电脑插座 ¥:101.00
telephone+computer socket
小板电话电脑插座(超六类) ¥:141.00
telephone+computer socket(6)

AB-K1-0120
小板电视电话插座 ¥:91.00
TV + telephone socket
小板电视电脑插座 ¥:101.00
TV + computer socket
小板一位电视电脑插座(超六类) ¥:141.00
TV + computer socket(6)

AB-K1 PC white PC雅白

AB-K1-0121

小板一位电话带USB插座 ¥:243.00
TEL + USB socket
小板一位电脑带USB插座 ¥:243.00
computer + USB socket
小板一位电脑带USB(超六类) ¥:293.00
computer + USB socket(6)

AB-K1-0122

小板一位TV+FM
TV and FM
¥:150.00

AB-K1-0123

小板一位卫星插座
Satellite socket
¥:78.00

AB-K1-0124

小板二位卫星插座
Double satellite socket
¥:121.00



AB-K1-0125

小板卫星+电视插座
Satellite and TV socket
¥:101.00

AB-K1-0126

小板卫星带电话插座 ¥:101.00
Satellite and telephone socket
小板卫星带电脑插座 ¥:121.00
Satellite and computer socket
小板卫星带电脑插座（超六类） ¥:161.00
Satellite and computer socket(6)

AB-K1-0127

小板二极插座带电视插座
2 pin socket with TV
¥:243.00

AB-K1-0128

小板二极插座带电话插座 ¥:243.00
2 pin socket with telephone
小板二极插座带电脑插座 ¥:243.00
2 pin socket with computer
小板二极插座带电脑插座(超六类) ¥:293.00
2 pin socket with computer

AB-K1-0129

小板一位光纤插座
Optical fiber socket
¥:140.00

AB-K1-0130

小板二位USB插座
Double USB socket
¥:203.00

AB-K1-0131

小板单联音响插座
Single audio socket
¥:133.00

AB-K1-0132

小板双联音响插座
Double audio socket
¥:183.00

AB-K1-0133

触摸延时开关（节能）
Touch delay delay switch
(energy saving)
¥:113.00

AB-K1-0134

声光控延时开关（节能）
Sound-light controlled delay switch
(energy saving)
¥:113.00



AB-K1-0135

红外线人体感应开关
Human body induction
¥:248.00

AB-K1-0136

凹型地脚灯（亮光/暖光）
The footlights
¥:153.00

AB-K1-0137

凹型红外线人体感应地脚灯
（亮光/暖光）
The human body induction footlights
¥:268.00

AB-K1-0138

平面地脚灯（亮光/暖光）
Footlights
¥:153.00

AB-K1-0139

叮咚门铃
Ding dong doorbell
¥:175.00

AB-K1-0140

机械式40A插卡取电 ¥:230.00
Mechanical card for electricity
感应式低频40A插卡取电 ¥:350.00
Low frequency induction card
for electricity
感应式高频40A插卡取电 ¥:400.00
High frequency induction card
for electricity

AB-K1-0141

紧急呼叫开关
Emergency call switch
¥:163.00

AB-K1-0142

请勿打扰请即清理门铃开关
(按键式)
Do not disturb please namely cleaning
please + late doorbell "button"
¥:171.00

AB-K1-0143

请勿打扰门铃开关（按键式）
Do not disturb + doorbell "button"
¥:323.00

AB-K1-0144

请勿打扰请即清理门铃开关
（按键式）
Do not disturb please namely cleaning
please "button"
¥:323.00

AB-K1-0145

智能音乐控制开关
Intelligent music control switch
¥:2700.00

AB-K1-0146

温度控制调节开关
Temperature control switch
¥:683.00

AB-K1-0147

温度控制调节开关
Temperature control switch
¥:780.00

AB-K1-0148

调音开关
Tuning switch（fire）
¥:160.00

AB-K1-0149

调光开关300W ¥:133.00
Dimming 300W
调光开关600W ¥:173.00
Dimming 600W
调光开关1000W ¥:213.00
Dimming 1000W

AB-K1-0150

调速开关300W ¥:133.00
Speed 300W
调速开关600W ¥:173.00
Speed 600W
调速开关1000W ¥:213.00
Speed 1000W

AB-K1-0151

一位开关带调光开关500W
1 gang with dimmer switch
¥:165.00

AB-K1-0152

一位开关带调速开关500W
1 gang with speed switch
¥:165.00

AB-K1-0153

13A开关带保险丝（带指示灯）
13A switch with fuse(with neon)
¥:163.00

AB-K1-0154

20A出线柱
20A outgoing post
¥:153.00

AB-K1-0155

剃须插座
Shaving socket
¥:390.00

AB-K1-0156

USB+电脑插座+无线路由
USB + computer socket,wireless router
¥:650.00

AB-K1-0157

蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio + 3.5
+ 2USB + HDMI
¥:5203.00

AB-K1-0158

HDMI
¥:243.00

AB-K1-0159

Type-c+USB(小板)
¥:283.00

AB-K1-0160

HDMI+USB
¥:243.00

AB-K1-0161

HDMI+USB+3.5音频
HDMI+USB+3.5
¥:243.00

AB-K1-0162

VGA+USB+3.5音频
VGA+USB +3.5
¥:243.00

AB-K1-0163

AV+3.5音频
AV +3.5
¥:243.00

AB-K1-0164

VGA+AV音频接口
VGA + AV audio interface
¥:243.00

AB-K1-0165

HDMI+AV音频接口
HDMI + AV audio interface
¥:243.00

AB-K1-0166

二分之一AV音频+卫星
Half AV audio interface+Satellite socket
¥:243.00.

AB-K1-0167

二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:243.00

AB-K1-0168

二分之一VGA+TV
Half VGA+TV
¥:243.00

AB-K1-0169

二分之一VGA+电脑插座
Half VGA+computer socket
¥:243.00

AB-K1-0170

VGA+USB
¥:243.00

AB-K1-0171

VGA+HDMI
¥:243.00

AB-K1-0172

45A出线柱
45A Outlet
¥:163.00

AB-K1-0173

空白面板
Blank plate
¥:37.00

AB-K1-0174

147大板二位双极开关带二位13A方角
插座（带指示灯）
Two bipolar switch with two 13A square
angle socket (with light)
¥:138.00

AB-K1-0175

147大板二位开关带二位16A多功能
插座（带指示灯）
147 Tow switch and double 16A MF
socket with light
¥:138.00



AB-K1-0176

147 二位开关带二位13A方角插座
带二位USB（带指示灯）
147 Two switch and double 13A
square comer socket with two USB
¥:238.00

AB-K1-0177

147大板二位开关带二位16A多功
能插座+2USB（带指示灯）
147 Two switch and double 16A
MF 3 pin socket with 2USB
¥:238.00

AB-K1-0178

147二位开关二位13A方插带灯
+USB/Type-c（大板）
147 Two switch and double 13A
square comer socket with USB/
Type-c
¥:268.00

AB-K1-0179

147二位开关二位13A多功能带灯
+USB/Type-c（大板）
147 Two switch and double 3 pin
MF socket with neon Type-c+USB
¥:268.00

AB-K1-0180

147型45A双极开关+一开
13A方角插带灯(炉具开关)
147 type 45A bipolar switch
+ 13A square angle plug With
light (stove switch)
¥:230.00

AB-K1 PC white PC雅白

AB-K1-0181

147型45A双极开关带指示灯
147 type 45A bipolar switch with indicator light
¥:183.00



AB-K1-0191

147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:138.00

AB-K1-0201

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 13A square comer socket with indicator light
¥:138.00

AB-K1-0182

147型空白面板
147 blank panel
¥:68.00



AB-K1-0192

小板147型二位15A美标扁插座
Type 147 Double 15A US flat socket
¥:130.00

AB-K1-0202

147 二位开关带二位13A多功能插座（带指示灯）
147 Tow switch and double 13A MF socket with light
¥:138.00

AB-K1-0183

小板147型16A二位开关单控
147 2 gang 1 way switch
¥:96.00
小板147型16A二位开关双控
147 2 gang 2 way switch
¥:104.00

AB-K1-0193

小板147型二位15A泰式三极插座
147 Double 15A triode flat Ammerican standard socket
¥:130.00

AB-K1-0203

147二位开关二位13A方插+二位USB（小板）
147 Tow switch and double 13A square comer socket + 2USB
¥:238.00

AB-K1-0184

小板147型16A三位开关单控
147 3 gang 1 way switch
¥:110.00
小板147型16A三位开关双控
147 3 gang 2 way switch
¥:120.00



AB-K1-0194

小板147型二位13A方角插座
Double 13A square comer socket
¥:122.00

AB-K1-0204

147二位开关二位13A多功能+二位USB（小板）
147 Tow switch and double 13A MF socket+2USB
¥:238.00

AB-K1-0185

小板147型16A四位开关单控
147 4 gang 1 way switch
¥:124.00
小板147型16A四位开关双控
147 4 gang 2 way switch
¥:136.00

AB-K1-0195

小板147型二位15A圆角插座
type 147 Double 15A round socket
¥:130.00

AB-K1-0205

小板147二位开关二位13A方插+USB/Type-c（小板）
147 two switch and double 13A square band lamp+USB/Type-c
¥:268.00

AB-K1-0186

小板147型16A五位开关单控
147 5 gang 1 way switch
¥:137.00
小板147型16A五位开关双控
147 5 gang 2 way switch
¥:152.00

AB-K1-0196

小板147型13A错位二位多功能五孔插座
Type 147 Double 13A multi functional 5 pin socket
¥:170.00

AB-K1-0206

小板147二位开关二位13A多功能+USB/Type-c（小板）
147 two switch and double 13A MF band lamp +USB/Type-c
¥:268.00

AB-K1-0187

小板147型16A六位开关单控
147 6 gang 1 way switch
¥:150.00
小板147型16A六位开关双控
147 6 gang 2 way switch
¥:168.00

AB-K1-0197

小板147型10A二位二三极插座
Type 147 Double 10A 5 pin socket
¥:98.00



AB-K1-0207

147 二位开关带二位15A圆角插座（带指示灯）
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:156.00

AB-K1-0188

小板147型16A七位开关单控
147 7 gang 1 way switch
¥:163.00
小板147型16A七位开关双控
147 7 gang 2 way switch
¥:184.00

AB-K1-0198

147 二位开关带二位13A方角插座
147 Tow switch and double 13A square comer socket
¥:168.00

AB-K1-0208

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 15A square comer socket with indicator light
¥:146.00

AB-K1-0189

小板147型16A八位开关单控
147 8 gang 1 way switch
¥:176.00
小板147型16A八位开关双控
147 8 gang 2 way switch
¥:200.00

AB-K1-0199

147 二位开关带二位13A多功能插座
147 Tow switch and double 13A MF 3 pin socket
¥:168.00

AB-K1-0209

147 四孔剃须插座
147 two shaving socket
¥:563.00

AB-K1-0190

147 二位16A多功能三极插座
147 Double 16A MF socket
¥:123.00

AB-K1-0200

147二位开关带二位多功能五孔
147 two switch with double MF 5 pin
¥:186.00

AB-K1-0210

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 Kitchen switch
¥:260.00



AB-K1-0211

147 45A开关+一位开关13A方角插带指示灯(组合厨房开关)
147 Kitchen switch
¥:260.00

AB-K1-0221

147二位16A法式+2USB（小板连体）
147 Double 16A German standard socket with 2USB
¥:280.00

AB-K1-0231

小板147型二位开关带多功能五孔+USB/type-c
147 two switch with multi-function five-hole + USB/type-c
¥:350.00

AB-K1-0212

147 45A开关+一位开关13A方插带灯（厨房开关）
147 Kitchen switch
¥:260.00

AB-K1-0222

小板147型四位USB插座
147 4 USB socket
¥:350. 00



AB-K1-0232

小板147型二开13A二位多功能带指示灯/4USB
147 type two switch 13A Double multi-function with indicator light /4USB
¥:350.00

AB-K1-0213

147 45A双极开关带指示灯
147 type 45A bipolar switch
¥:183.00

AB-K1-0223

147 二位多功能插座+4USB
147 2-bit multi-function socket + 4USB
¥:350.00

AB-K1-0233

147型二开二位13A方角插座带指示灯/4USB
147 type two open two position 13A square comer socket with indicator light / 4USB
¥:350.00

AB-K1-0214

147 16A二位德式插座
147 Double Geman socket
¥:148.00

AB-K1-0224

147 二位13A方角插座+4USB
147 two bit 13A square socket +4USB
¥:350.00

AB-K1-0234

小板147二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A German socket+USB/Type-c w/neon
¥:330.00

AB-K1-0215

147 16A二位法式插座
147 Double French socket
¥:148.00



AB-K1-0225

147 一位13A方角插座+二位USB
13A square comer socket and two USB
¥:271.00

AB-K1-0235

小板147型二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A French socket+USB/Type-c w/neon
¥:330.00

AB-K1-0216

小板147型二位16A德标插座
147 Double Geman socket
¥:148.00



AB-K1-0226

147型16A多功能三孔带二位USB插座
147 16A 3 pin MF socket and 2USB socket
¥:271.00

AB-K1-0236

小板147型二位开关二位16A德式插座（带指示灯）
147 two switch double 16A German socket w/neon
¥:190.00

AB-K1-0217

小板147型二位16A法标插座
147 Double French socket
¥:148.00

AB-K1-0227

147型二位开关带二位多功能五孔插座带双USB
147 Tow switch and double 13A 5 pin multi-purpose socket+2USB
¥:330.00

AB-K1-0237

小板147型二位开关二位16A法式插座（带指示灯）
147 two switch double 16A French socket w/neon
¥:190.00

AB-K1-0218

小板147型二位16A德式插座+USB/Type-c(小板）
147 Double 16A French + USB / type-c
¥:340.00



AB-K1-0228

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two switch and double 13A MF 5-pin socket + 2USB (with indicator)
¥:350.00

AB-K1-0238

小板147型二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket with neon + 2USB
¥:320.00

AB-K1-0219

小板147型二位16A法式插座+USB/Type-c(小板）
147 Double 16A German + USB / type-c
¥:340.00



AB-K1-0229

147 二位13A多功能五孔插座+四位USB
147 13A double 5 pin multi function socket+4USB
¥:330.00

AB-K1-0239

小板147型二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch double 16A French socket w/neon+2USB
¥:320.00

AB-K1-0220

147型二位16A德式+2USB（小板连体）
147 Double 16A German Band socket +2USB
¥:280.00



AB-K1-0230

小板147型二位13A多功能五孔带四位USB带小开关/指示灯
147 type double 13A multi-functional five-hole With 4USB with small switch/indicator light
¥:350.00

AB-K1-0240

小板147型空白面板
147 Blank plate
¥:78.00

是开关插座，也是墙壁装饰，
装点出生活的新意，
臻致品味 从细节开始，
出众的外形使您的居住空间细节更加别致。

It is switch socket, also be wall adornment,
Deck gives the new idea of life,
fashionable taste, start from detail,
outstanding appearance makes your living space detail more chic.

Zigbee智能按键开关

Zigbee Intelligent button switch

Zigbee一开
￥950.00

Zigbee二开
￥1050.00

Zigbee三开
￥1150.00

二三极USB/Type-c+开关
￥190.00

语音/APP/轻触机械控制	情景模式/联动/定时	支持多款AL音响	涂鸦无线场景开关 (单火零火通用)
Voice /APP/ touch mechanical control	Scenario mode/Linkage/timing	Support a variety of AL audio	Doodle wireless scene switch (Single fire and zero fire universal)

外观颜色 / Appearance Color

珍珠白 Pearl White　香槟金 Champagne gold　太空灰 Space gray　摩卡黑 Mocha Black

模块颜色 / Module Color

珍珠白 Pearl White　香槟金 Champagne gold　太空灰 Space gray　摩卡黑 Mocha Black

147组合演示 / 147 Combination demo



联体产品 / Conjoined products

二位联体面框
Two-position face frame
塑板/钢板:50.00
Plastic board/Steel plate:50.00

四位联体面框
Four-position face frame
塑板/钢板:90.00
Plastic board/Steel plate:90.00

三位联体面框
Three-position face frame
塑板/钢板:70.00
Plastic board/Steel plate:70.00

五位联体面框
Five-position face frame
塑板/钢板:110.00
Plastic board/Steel plate:110.00

AB-K1 Pearl white paint 烤漆珍珠白

AB-K1-0001
大板16A一位开关单控(荧光灯) ¥:37.30
1 gang 1 way switch
大板16A一位开关双控(荧光灯) ¥:41.30
1 gang 2 way switch
大板16A一位开关多控(荧光灯) ¥:59.00
1 gang more way switch

AB-K1-0002
大板16A二位开关单控(荧光灯) ¥:47.30
2 gang 1 way touch switch
大板16A二位开关双控(荧光灯) ¥:53.10
2 gang 2 way touch switch
大板16A二位开关多控(荧光灯) ¥:85.10
2 gang 3 way touch switch

AB-K1-0003
大板16A三位开关单控(荧光灯) ¥:59.10
3 gang 1 way switch
大板16A三位开关双控(荧光灯) ¥:68.60
3 gang 2 way switch

AB-K1-0004
大板16A四位开关单控(荧光灯) ¥:73.30
4 gang 1 way switch
大板16A四位开关双控(荧光灯) ¥:88.00
4 gang 2 way switch

AB-K1-0005
大板16A一位开关单控 ¥:37.30
Large panel 16A 1 gang 1 way switch
大板16A一位开关双控 ¥:41.30
Large panel 16A 1 gang 2 way switch
大板16A一位开关多控 ¥:59.00
Large panel 16A 1 gang more way switch

AB-K1-0006
大板16A二位开关单控 ¥:47.30
Large panel 16A 2 gang 1 way touch switch
大板16A二位开关双控 ¥:53.10
Large panel 16A 2 gang 2 way touch switch
大板16A二位开关多控 ¥:85.10
Large panel 16A 2 gang 3 way touch switch

AB-K1-0007
大板16A三位开关单控 ¥:59.10
Large panel 16A 3 gang 1 way switch
大板16A三位开关双控 ¥:68.60
Large panel 16A 3 gang 2 way switch

AB-K1-0008
大板16A四位开关单控 ¥:73.30
Large panel 16A 4 gang 1 way switch
大板16A四位开关双控 ¥:88.00
Large panel 16A 4 gang 2 way switch

AB-K1-0009
大板16A百叶窗升降开关
Large panel louver window lifter switch
¥:64.40

AB-K1-0010
大板16A门控开关
Large panel gating switch
¥:52.40

AB-K1-0011
大板16A英式门控开关
Large panel British gating switch
¥:52.40



AB-K1-0012
大板16A门铃开关
Large panel doorbell switch
¥:52.40

AB-K1-0013
大板20A双极开关带指示灯 ¥:115.20
20A bipolar switch with neon
大板32A双极开关带指示灯 ¥:124.20
32A bipolar switch with neon

AB-K1-0014
大板45A双极开关带指示灯
45A bipolar switch with indicator light
¥:142.20

AB-K1-0015
大板16A三极插座
16A 3 pole socket
¥:48.60

AB-K1-0016
大板16A多功能插座
16A 3 pin universal socket
¥:51.50

AB-K1-0017
大板10A二三极插座
10A 5 pole socket
¥:38.30

AB-K1-0018
大板10A错位二三极插座
10A Two or three pole socket
¥:51.90

AB-K1-0019
大板16A多功能五孔插座
16A 5 pin MF socket
¥:53.60

AB-K1-0020
大板10A二二三极插座
10A 7 pole socket
¥:51.90

AB-K1-0021
大板13A方角插座
13A square corner socket
¥:51.50

AB-K1-0022
大板二位USB带16A多功能五孔插座
2 USB with 5 pin multi-function socket
¥:149. 00

AB-K1-0023
大板16A一位开关单控带16A三极插座
1gang1 way swith and 16A 3 pole socket
¥:62.90
大板16A一位开关双控带16A三极插座
1gang2 way swith and 16A 3 pole socket
¥:65.20

AB-K1-0024
大板一位开关单控带10A二三极插座
1gang2 way switch and 16A 5 pole socket
¥:59.00
大板一位开关双控带10A二三极插座
1gang 2 way switch and 5 pole socket
¥:61.10

AB-K1-0025
大板10A二位开关单控带二三极插座
2 gang 1 way switch and 5 pole socket
大板10A二位开关双控带二三极插座
2 gang 2 way switch and 5 pole socket
¥:84.80

AB-K1-0026
大板一位开关带16A三极多功能插座
(带指示灯)
1 gang switch and 16A 3 pin multi-purpose socket with indicator lighe
¥:66.00



AB-K1-0027
大板一位双极开关带13A方角插座
(指示灯)
1 gang weitch and 13A square pin socket with indicator light
¥:66.00

AB-K1-0028
大板一位开关带15A圆孔插座
(带指示灯)
1 gang weitch and 15A 3 square pin socket with indicator light
¥:66.00

AB-K1-0029
大板一位开关带16A二三极多功能插座(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
¥:72.00

AB-K1-0030
大板一开13A多功能带双USB
(带指示灯)
1gang 13A switch and 16A 3 pin MF socket +2USB with neon
¥:158.00

AB-K1-0031
大板一开13A方插带双USB (带指示灯)
1gang 13A square plug with 2USB(with neon)
¥:158.00

AB-K1-0032
大板16A德式插座
Large board 16A German socket
¥:58.00

AB-K1-0033
大板16A法式插座
Large plate 16A French socket
¥:58.00

AB-K1-0034
大板16A俄式插座
Large board 16A Russian socket
¥:55.00

AB-K1-0035
大板16A德式插座+二位USB
16A German socket+2 USB
¥:165.00

AB-K1-0036
大板16A法式插座+二位USB
16A French socket + 2 USB
¥:165.00

AB-K1-0037
大板16A德式插座+USB/type-c
Large board 16A German socket + USB / type-C
¥:165.00

AB-K1-0038
大板16A法式插座+USB/type-c
Large board 16A French socket + USB / type-C
¥:165.00

AB-K1-0039
大板一位电视插座
TV socket
¥:58.00

AB-K1-0040
大板一位电话插座 ¥:58.00
telephone socket
大板一位电脑插座 ¥:63.00
computer socket
大板一位电脑插座(超六类) ¥:106.00
computer socket(6)

AB-K1-0041
大板一位电视电话插座 ¥:82.00
TV + telephone socket
大板一位电视电脑插座 ¥:91.00
TV + computer socket
大板一位电视电脑插座(超六类) ¥:127.00
TV + computer socket(6)

AB-K1-0042
大板二位电视插座
Two TV socket
¥:82.00

AB-K1-0043
大板二位电话插座 ¥:82.00
Two telephone socket
大板二位电脑插座 ¥:109.00
Two computer socket
大板二位电脑插座(超六类) ¥:181.00
Two computer socket(6)
大板电话+电脑插座 ¥:91.00
telephone+computer socket
大板电话+电脑插座(超六类) ¥:127.00
telephone+computer socket(6)

AB-K1-0044
86型大板空白面板
Large plate Blank plate
¥:28.00

AB-K1-0045
小板16A一位开关单控 ¥:48.00
16A 1 gang 1 way switch
小板16A一位开关双控 ¥:52.00
16A 1 gang 2 way switch
小板16A一位开关多控 ¥:88.00
16A 1 gang more way switch

AB-K1-0046
小板16A二位开关单控 ¥:62.00
16A 2 gang 1 way switch
小板16A二位开关双控 ¥:68.00
16A 2 gang 2 way switch
小板16A二位开关多控 ¥:120.00
16A 2 gang more way switch

AB-K1-0047
小板16A三位开关单控 ¥:75.00
16A 3 gang 1 way switch
小板16A三位开关双控 ¥:84.00
16A 3 gang 2 way switch

AB-K1-0048
小板16A四位开关单控 ¥:88.00
16A 4 gang 1 way switch
小板16A四位开关双控 ¥:100.00
16A 4 gang 2 way switch

AB-K1-0049
小板16A三位开关多控
16A 3 gang 3 way switch
¥:140.00

AB-K1-0050
小板16A百叶窗升降开关
Small panel louver window lifter switch
¥:83.00

AB-K1-0051
小板16A门控开关
Small panel gating switch
¥:68.00

AB-K1-0052
小板16A英式门控开关
Small panel British gating switch
¥:68.00

AB-K1-0053
小板16A门铃开关
Small panel doorbell switch
¥:68.00

AB-K1-0054
小板16A拨动一位开关单控 ¥:108.00
1 gang 1 way toggle switch
小板16A拨动一位开关双控 ¥:114.00
1 gang 2 way toggle switch

AB-K1-0055
小板16A拨动二位开关单控 ¥:128.00
2 gang 1 way toggle switch
小板16A拨动二位开关双控 ¥:140.00
2 gang 2 way toggle switch

AB-K1-0056
小板16A拨动三位开关单控 ¥:148.00
3 gang 1 way toggle switch
小板16A拨动三位开关双控 ¥:166.00
3 gang 2 way toggle switch

AB-K1-0057
小板16A拨动四位开关单控 ¥:168.00
4 gang 1 way toggle switch
小板16A拨动四位开关双控 ¥:192.00
4 gang 2 way toggle switch



AB-K1-0058
小板20A双极开关带指示灯 ¥:128.00
20A swich with indicator light
小板45A双极开关带指示灯 ¥:158.00
45A swich with indicator light

AB-K1-0059
小板45A双极开关带指示灯
45A swich with indicator light
¥:148.00

AB-K1-0060
小板16A卷帘门复位开关
German socket
¥:108.00

AB-K1 Pearl white paint 烤漆珍珠白

AB-K1-0061
小板16A德式插座
German socket
¥:58.00

AB-K1-0062
小板16A法式插座
French socket
¥:58.00

AB-K1-0063
小板16A俄式插座
Russian socket
¥:58.00

AB-K1-0064
小板16A以色列插座
Israel socket
¥:68.00

AB-K1-0065
小板16A意大利+德式插座
Italy+German socket
¥:68.00

AB-K1-0066
小板10A二极插座
10A 2 pole socket
¥:55.00

AB-K1-0067
小板10A二二极插座
10A Double 2 pole socket
¥:63.00

AB-K1-0068
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:61.00

AB-K1-0069
小板10A一位开关带二二极座
1gang switch and 4 pole socket
¥:71.00

AB-K1-0070
小板16A多功能三极插座
16A MF 3 pin socket
¥:58.00

AB-K1-0071
小板13A二三极多功能插座
5 pin multi-function socket
¥:65.00

AB-K1-0072
小板13A错位多功能二三极插座
13A dislocation multi-function double and triple-pole socket
¥:68.00

AB-K1-0073
小板13A方角插座
13A square corner socket
¥:58.00

AB-K1-0074
小板15A圆角插座
15A 3 round pins socket
¥:58.00

AB-K1-0075
小板15A美标扁三极插座
15A triode flat American standard socket
¥:58.00

AB-K1-0076
小板15A泰式插座
15A Thai socket
¥:58.00

AB-K1-0077
小板15A泰式六孔插座
Dislocation Thai 6 pin socket
¥:75.00

AB-K1-0078
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:66.00

AB-K1-0079
小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pins socket
¥:68.00

AB-K1-0080
小板一位开关带16A多功能插座
1 gang switch and 16A 3 pin MF socket
¥:68.00

AB-K1-0081
小板一位开关带13A方角插座
（带指示灯）
1 gang switch and 13A square pin socket with indicator light
¥:65.00

AB-K1-0082
小板一位开关带15A圆孔插座
（带指示灯）
1 gang switch and 15A 3 round pins socket with indicator light
¥:68.00

AB-K1-0083
小板一位开关带16A多功能插座
（带指示灯）
1 gang switch and 3 pin MF socket with light
¥:70.00

AB-K1-0084
小板一位开关带13A多功能五孔插座
（带指示灯）
1 gang switch and 5 pin multi-function socket with indicator light
¥:75.00

AB-K1-0085
小板16A德式插座带二位USB
2 USB witch German socket
¥:165.00

AB-K1-0086
小板16A法式插座带二位USB
2 USB witch French socket
¥:165.00

AB-K1-0087
小板16A德标插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:165.00

AB-K1-0088
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:165.00

AB-K1-0089
小板16A一位开关带德式插座
1 gang German socket
¥:68.00

AB-K1-0090
小板16A一位开关带法式插座
1 gang French socket
¥:68.00

AB-K1-0091
小板16A德式插座带防水
German socket and Waterproof belt
¥:75.00

AB-K1-0092
小板16A法式插座带防水
French socket and Waterproof belt
¥:75.00

AB-K1-0093
小板二位USB带13A方角插座（横）
2 USB with 13A square corner socket with swith
¥:170.00

AB-K1-0094
小板15A美标插座+USB+type-c
American Standard + USB / type-C
¥:170.00

AB-K1-0095
小板15A泰式插座+USB+type-c
15A Thai + USB / type-C
¥:170.00

AB-K1-0096
小板二位USB带13A方角插座
（带保护门）
2 USB with 13A square corner socket with flip cover
¥:170.00

AB-K1-0097
小板二位USB带13A多功能插座
（带保护门）
2 USB with 3 pin multi-purpose socket with flip cover
¥:170.00

AB-K1-0098
小板一位开关带二位USB带13A多功能插座（带指示灯）
1 gang switch with two USB and 13A multi-function socket
¥:175.00

AB-K1-0099
小板一位开关带二位USB带13A方角插座（带指示灯）
2 USB with 13A aquare comer socket with flip cover
¥:175.00

AB-K1-0100
小板13A多功能插座带USB+type-c
13A multi-function with type-C + USB
¥:170.00

AB-K1-0101
小板13A方角插座带USB+type-c
13A square angle band type-C + USB
¥:170.00

AB-K1-0102
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with Type-c+USB(with light)
¥:175.00

AB-K1-0103
小板二位USB带13A多功能插座带小开关（竖）
2 USB with Three very multi-purpose socket with switch
¥:175.00

AB-K1-0104
小板一位开关13A方插带Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:175.00

AB-K1-0105
小板二位USB带13A方角插座带小开关（竖）
2 USB with 13A square corner socket with switch
¥:175.00

AB-K1-0106
小板15A美式插座带二位USB
American Standard + 2USB
¥:170.00

AB-K1-0107
小板15A泰式插座带双USB
15A Thai + 2USB
¥:170.00

AB-K1-0108
小板13A多功能插座带二位USB（横）
13A multi-function socket belt with two-bit USB(horizontal)
¥:183.00

AB-K1-0109
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:163.00

AB-K1-0110
小板二位USB带10A二三极插座带开关
2 USB and 5 pin socket with switch
¥:173.00

AB-K1-0111
小板10五孔插座带USB +Type-C (10W)
10A 5 pole socket with USB type-C (10W)
¥:170.00
小板10五孔插座带USB +Type-C (18W)
10A 5 pole socket with USB type-C (18W)
¥:235.00

AB-K1-0112
小板一位开关带13A多功能五孔插座带USB
1 gang swich and 5 pin multi-function socket with USB and indicator light
¥:190.00

AB-K1-0113
小板13A二位USB带多功能五孔插座
2 USB with 5 pin multi-function socket
¥:163.00

AB-K1-0114
小板13A二位USB带多功能五孔插座带开关
2 USB with 5 pin multi-function socket with switch
¥:173.00

AB-K1-0115
13A多功能五孔带USB+TYPE-C (10W)
13A MF 5 pin socket USB+type-C (10W)
¥:170.00
13A多功能五孔带USB+TYPE-C (18W)
13A MF 5 pin socket USB+type-C (18W)
¥:235.00



AB-K1-0116
小板一位电视插座
TV socket
¥:65.00

AB-K1-0117
小板一位电话插座 ¥:65.00
telephone socket
小板一位电脑插座 ¥:78.00
computer socket
小板一位电脑插座（超六类）¥:118.00
computer socket(6)

AB-K1-0118
小板双电视插座
Two TV socket
¥:91.00

AB-K1-0119
小板双电话插座 ¥:91.00
Two telephone socket
小板双电脑插座 ¥:121.00
Two computer socket
小板二位电脑插座(超六类) ¥:181.00
Two computer socket(6)
小板电话电脑插座 ¥:101.00
telephone+computer socket
小板电话电脑插座(超六类) ¥:141.00
telephone+computer socket(6)

AB-K1-0120
小板电视电话插座 ¥:91.00
TV + telephone socket
小板电视电脑插座 ¥:101.00
TV + computer socket
小板一位电视电脑插座(超六类) ¥:141.00
TV + computer socket(6)

AB-K1 Pearl white paint 烤漆珍珠白

AB-K1-0121

小板一位电话带USB插座 ¥:243.00
TEL + USB socket
小板一位电脑带USB插座 ¥:243.00
computer + USB socket
小板一位电脑带USB(超六类) ¥:293.00
computer + USB socket(6)

AB-K1-0122

小板一位TV+FM
TV and FM
¥:150.00

AB-K1-0123

小板一位卫星插座
Satellite socket
¥:78.00

AB-K1-0124

小板二位卫星插座
Double satellite socket
¥:121.00



AB-K1-0125

小板卫星+电视插座
Satellite and TV socket
¥:101.00

AB-K1-0126

小板卫星带电话插座 ¥:101.00
Satellite and telephone socket
小板卫星带电脑插座 ¥:121.00
Satellite and computer socket
小板卫星带电脑插座（超六类） ¥:161.00
Satellite and computer socket(6)

AB-K1-0127

小板二极插座带电视插座
2 pin socket with TV
¥:243.00

AB-K1-0128

小板二极插座带电话插座 ¥:243.00
2 pin socket with telephone
小板二极插座带电脑插座 ¥:243.00
2 pin socket with computer
小板二极插座带电脑插座(超六类) ¥:293.00
2 pin socket with computer

AB-K1-0129

小板一位光纤插座
Optical fiber socket
¥:140.00

AB-K1-0130

小板二位USB插座
Double USB socket
¥:203.00

AB-K1-0131

小板单联音响插座
Single audio socket
¥:133.00

AB-K1-0132

小板双联音响插座
Double audio socket
¥:183.00

AB-K1-0133

触摸延时开关（节能）
Touch delay delay switch
(energy saving)
¥:113.00

AB-K1-0134

声光控延时开关（节能）
Sound-light controlled delay switch
(energy saving)
¥:113.00



AB-K1-0135

红外线人体感应开关
Human body induction
¥:248.00

AB-K1-0136

凹型地脚灯（亮光/暖光）
The footlights
¥:153.00

AB-K1-0137

凹型红外线人体感应地脚灯
（亮光/暖光）
The human body induction footlights
¥:268.00

AB-K1-0138

平面地脚灯（亮光/暖光）
Footlights
¥:153.00

AB-K1-0139

叮咚门铃
Ding dong doorbell
¥:175.00

AB-K1-0140

机械式40A插卡取电 ¥:230.00
Mechanical card for electricity
感应式低频40A插卡取电 ¥:350.00
Low frequency induction card
for electricity
感应式高频40A插卡取电 ¥:400.00
High frequency induction card
for electricity

AB-K1-0141

紧急呼叫开关
Emergency call switch
¥:163.00

AB-K1-0142

请勿打扰请即清理门铃开关
(按键式)
Do not disturb please namely cleaning
please + late doorbell "button"
¥:171.00

AB-K1-0143

请勿打扰门铃开关（按键式）
Do not disturb + doorbell "button"
¥:323.00

AB-K1-0144

请勿打扰请即清理门铃开关
（按键式）
Do not disturb please namely cleaning
please "button"
¥:323.00

AB-K1-0145

智能音乐控制开关
Intelligent music control switch
¥:2700.00

AB-K1-0146

温度控制调节开关
Temperature control switch
¥:683.00

AB-K1-0147

温度控制调节开关
Temperature control switch
¥:780.00

AB-K1-0148

调音开关
Tuning switch（fire）
¥:160.00

AB-K1-0149

调光开关300W ¥:133.00
Dimming 300W
调光开关600W ¥:173.00
Dimming 600W
调光开关1000W ¥:213.00
Dimming 1000W

AB-K1-0150

调速开关300W ¥:133.00
Speed 300W
调速开关600W ¥:173.00
Speed 600W
调速开关1000W ¥:213.00
Speed 1000W

AB-K1-0151

一位开关带调光开关500W
1 gang with dimmer switch
¥:165.00

AB-K1-0152

一位开关带调速开关500W
1 gang with speed switch
¥:165.00

AB-K1-0153

13A开关带保险丝（带指示灯）
13A switch with fuse(with neon)
¥:163.00

AB-K1-0154

20A出线柱
20A outgoing post
¥:153.00



AB-K1-0155

剃须插座
Shaving socket
¥:390.00

AB-K1-0156

USB+电脑插座+无线路由
USB + computer socket,wireless router
¥:650.00

AB-K1-0157

蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio + 3.5
+ 2USB + HDMI
¥:5203.00

AB-K1-0158

HDMI
¥:243.00

AB-K1-0159

Type-c+USB(小板)
¥:283.00

AB-K1-0160

HDMI+USB
¥:243.00

AB-K1-0161

HDMI+USB+3.5音频
HDMI+USB+3.5
¥:243.00

AB-K1-0162

VGA+USB+3.5音频
VGA+USB +3.5
¥:243.00

AB-K1-0163

AV+3.5音频
AV +3.5
¥:243.00

AB-K1-0164

VGA+AV音频接口
VGA + AV audio interface
¥:243.00

AB-K1-0165

HDMI+AV音频接口
HDMI + AV audio interface
¥:243.00

AB-K1-0166

二分之一AV音频+卫星
Half AV audio interface+Satellite socket
¥:243.00.

AB-K1-0167

二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:243.00

AB-K1-0168

二分之一VGA+TV
Half VGA+TV
¥:243.00

AB-K1-0169

二分之一VGA+电脑插座
Half VGA+computer socket
¥:243.00

AB-K1-0170

VGA+USB
¥:243.00

AB-K1-0171

VGA+HDMI
¥:243.00

AB-K1-0172

45A出线柱
45A Outlet
¥:163.00

AB-K1-0173

空白面板
Blank plate
¥:37.00

AB-K1-0174

147大板二位双极开关带二位13A方角
插座（带指示灯）
Two bipolar switch with two 13A square
angle socket (with light)
¥:138.00

AB-K1-0175

147大板二位开关带二位16A多功能
插座（带指示灯）
147 Tow switch and double 16A MF
socket with light
¥:138.00

AB-K1-0176

147 二位开关带二位13A方角插座
带二位USB（带指示灯）
147 Two switch and double 13A
square comer socket with two USB
¥:238.00

AB-K1-0177

147大板二位开关带二位16A多功
能插座+2USB（带指示灯）
147 Two switch and double 16A
MF 3 pin socket with 2USB
¥:238.00

AB-K1-0178

147二位开关二位13A方插带灯
+USB/Type-c（大板）
147 Two switch and double 13A
square comer socket with USB/
Type-c
¥:268.00

AB-K1-0179

147二位开关二位13A多功能带灯
+USB/Type-c（大板）
147 Two switch and double 3 pin
MF socket with neon Type-c+USB
¥:268.00

AB-K1-0180

147型45A双极开关+一开
13A方角插带灯(炉具开关)
147 type 45A bipolar switch
+ 13A square angle plug With
light (stove switch)
¥:230.00

AB-K1 Pearl white paint 烤漆珍珠白

AB-K1-0181

147型45A双极开关带指示灯
147 type 45A bipolar switch with indicator light
¥:183.00

AB-K1-0182

147型空白面板
147 blank panel
¥:68.00

AB-K1-0183

小板147型16A二位开关单控
147 2 gang 1 way switch
¥:96.00
小板147型16A二位开关双控
147 2 gang 2 way switch
¥:104.00

AB-K1-0184

小板147型16A三位开关单控
147 3 gang 1 way switch
¥:110.00
小板147型16A三位开关双控
147 3 gang 2 way switch
¥:120.00

AB-K1-0185

小板147型16A四位开关单控
147 4 gang 1 way switch
¥:124.00
小板147型16A四位开关双控
147 4 gang 2 way switch
¥:136.00

AB-K1-0186

小板147型16A五位开关单控
147 5 gang 1 way switch
¥:137.00
小板147型16A五位开关双控
147 5 gang 2 way switch
¥:152.00

AB-K1-0187

小板147型16A六位开关单控
147 6 gang 1 way switch
¥:150.00
小板147型16A六位开关双控
147 6 gang 2 way switch
¥:168.00

AB-K1-0188

小板147型16A七位开关单控
147 7 gang 1 way switch
¥:163.00
小板147型16A七位开关双控
147 7 gang 2 way switch
¥:184.00

AB-K1-0189

小板147型16A八位开关单控
147 8 gang 1 way switch
¥:176.00
小板147型16A八位开关双控
147 8 gang 2 way switch
¥:200.00

AB-K1-0190

147 二位16A多功能三极插座
147 Double 16A MF socket
¥:123.00

AB-K1-0191

147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:138.00

AB-K1-0192

小板147型二位15A美标扁插座
Type 147 Double 15A US flat socket
¥:130.00

AB-K1-0193

小板147型二位15A泰式三极插座
147 Double 15A triode flat Ammerican standard socket
¥:130.00

AB-K1-0194

小板147型二位13A方角插座
Double 13A square comer socket
¥:122.00

AB-K1-0195

小板147型二位15A圆角插座
type 147 Double 15A round socket
¥:130.00

AB-K1-0196

小板147型13A错位二位多功能五孔插座
Type 147 Double 13A multi functional 5 pin socket
¥:170.00

AB-K1-0197

小板147型10A二位二三极插座
Type 147 Double 10A 5 pin socket
¥:98.00

AB-K1-0198

147 二位开关带二位13A方角插座
147 Tow switch and double 13A square corner socket
¥:168.00

AB-K1-0199

147 二位开关带二位13A多功能插座
147 Tow switch and double 13A MF 3 pin socket
¥:168.00

AB-K1-0200

147二位开关带二位多功能五孔
147 two switch with double MF 5 pin
¥:186.00

AB-K1-0201

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 13A square comer socket with indicator light
¥:138.00

AB-K1-0202

147 二位开关带二位13A多功能插座（带指示灯）
147 Tow switch and double 13A MF socket with light
¥:138.00

AB-K1-0203

147二位开关二位13A方插+二位USB（小板）
147 Tow switch and double 13A square corner socket + 2USB
¥:238.00

AB-K1-0204

147二位开关二位13A多功能+二位USB（小板）
147 Tow switch and double 13A MF socket+2USB
¥:238.00

AB-K1-0205

小板147二位开关二位13A方插+USB/Type-c（小板）
147 two switch and double 13A square band lamp+USB/Type-c
¥:268.00

AB-K1-0206

小板147二位开关二位13A多功能+USB/Type-c（小板）
147 two switch and double 13A MF band lamp +USB/Type-c
¥:268.00

AB-K1-0207

147 二位开关带二位15A圆角插座（带指示灯）
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:156.00

AB-K1-0208

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 15A square comer socket with indicator light
¥:146.00

AB-K1-0209

147 四孔剃须插座
147 two shaving socket
¥:563.00

AB-K1-0210

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 Kitchen switch
¥:260.00

AB-K1-0211

147 45A开关+一位开关13A方角插带指示灯(组合厨房开关)
147 Kitchen switch
¥:260.00

AB-K1-0212

147 45A开关+一位开关13A方插带灯（厨房开关）
147 Kitchen switch
¥:260.00

AB-K1-0213

147 45A双极开关带指示灯
147 type 45A bipolar switch
¥:183.00

AB-K1-0214

147 16A二位德式插座
147 Double Geman socket
¥:148.00

AB-K1-0215

147 16A二位法式插座
147 Double French socket
¥:148.00

AB-K1-0216

小板147型二位16A德标插座
147 Double Geman socket
¥:148.00

AB-K1-0217

小板147型二位16A法标插座
147 Double French socket
¥:148.00

AB-K1-0218

小板147型二位16A德式插座+USB/Type-c(小板）
147 Double 16A French + USB / type-c
¥:340.00

AB-K1-0219

小板147型二位16A法式插座+USB/Type-c(小板）
147 Double 16A German + USB / type-c
¥:340.00

AB-K1-0220

147型二位16A德式+2USB（小板连体）
147 Double 16A German Band socket +2USB
¥:280.00

AB-K1-0221

147二位16A法式+2USB（小板连体）
147 Double 16A German standard socket with 2USB
¥:280.00

AB-K1-0222

小板147型四位USB插座
147 4 USB socket
¥:350. 00



AB-K1-0223

147 二位多功能插座+4USB
147 2-bit multi-function socket + 4USB
¥:350.00

AB-K1-0224

147 二位13A方角插座+4USB
147 two bit 13A square socket +4USB
¥:350.00

AB-K1-0225

147 一位13A方角插座+二位USB
13A square comer socket and two USB
¥:271.00

AB-K1-0226

147型16A多功能三孔带二位USB插座
147 16A 3 pin MF socket and 2USB socket
¥:271.00



AB-K1-0227

147型二位开关带二位多功能五孔插座带双USB
147 Tow switch and double 13A 5 pin multi-purpose socket+2USB
¥:330.00



AB-K1-0228

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two switch and double 13A MF 5-pin socket + 2USB (with indicator)
¥:350.00

AB-K1-0229

147 二位13A多功能五孔插座+四位USB
147 13A double 5 pin multi function socket+4USB
¥:330.00

AB-K1-0230

小板147型二位13A多功能五孔带四位USB带小开关/指示灯
147 type double 13A multi-functional five-hole With 4USB with small switch/indicator light
¥:350.00

AB-K1-0231

小板147型二位开关带多功能五孔+USB/type-c
147 two switch with multi-function five-hole + USB/type-c
¥:350.00

AB-K1-0232

小板147型二开13A二位多功能带指示灯/4USB
147 type two switch 13A Double multi-function with indicator light /4USB
¥:350.00

AB-K1-0233

147型二开二位13A方角插座带指示灯/4USB
147 type two open two position 13A square comer socket with indicator light / 4USB
¥:350.00

AB-K1-0234

小板147二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A German socket+USB/Type-c w/neon
¥:330.00

AB-K1-0235

小板147型二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A French socket+USB/Type-c w/neon
¥:330.00

AB-K1-0236

小板147型二位开关二位16A德式插座（带指示灯）
147 two switch double 16A German socket w/neon
¥:190.00

AB-K1-0237

小板147型二位开关二位16A法式插座（带指示灯）
147 two switch double 16A French socket w/neon
¥:190.00

AB-K1-0238

小板147型二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket with neon + 2USB
¥:320.00

AB-K1-0239

小板147型二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch double 16A French socket w/neon+2USB
¥:320.00

AB-K1-0240

小板147型空白面板
147 Blank plate
¥:78.00

真彩
倾心

高贵与时尚，无声散发
优雅呈阅眼前，美学生活缓缓展开

Noble and fashionable, silent
Elegant and elegant,
Aesthetic life unfolds slowly

AB-K2

烤漆香槟金
Lacquered champagne gold

Zigbee智能按键开关

Zigbee Intelligent button switch

Zigbee一开
￥950.00

语音/APP/轻触机械控制
Voice /APP/ touch mechanical control

Zigbee二开
￥1050.00

情景模式/联动/定时
Scenario mode/Linkage/timing

Zigbee三开
￥1150.00

支持多款AL音响
Support a variety of AL audio

二三极USB/Type-c+开关
￥190.00

涂鸦无线场景开关
(单火零火通用)
Doodle wireless scene switch
(Single fire and zero fire universal)

AB-K2 Lacquered champagne gold 烤漆香槟金

AB-K2-0001
大板16A一位开关单控(荧光灯) ¥:37.30
1 gang 1 way switch
大板16A一位开关双控(荧光灯) ¥:41.30
1 gang 2 way switch
大板16A一位开关多控(荧光灯) ¥:59.00
1 gang more way switch

AB-K2-0002
大板16A二位开关单控(荧光灯) ¥:47.30
2 gang 1 way touch switch
大板16A二位开关双控(荧光灯) ¥:53.10
2 gang 2 way touch switch
大板16A二位开关多控(荧光灯) ¥:85.10
2 gang 3 way touch switch

AB-K2-0003
大板16A三位开关单控(荧光灯) ¥:59.10
3 gang 1 way switch
大板16A三位开关双控(荧光灯) ¥:68.60
3 gang 2 way switch

AB-K2-0004
大板16A四位开关单控(荧光灯) ¥:73.30
4 gang 1 way switch
大板16A四位开关双控(荧光灯) ¥:88.00
4 gang 2 way switch

AB-K2-0005
大板16A一位开关单控 ¥:37.30
Large panel 16A 1 gang 1 way switch
大板16A一位开关双控 ¥:41.30
Large panel 16A 1 gang 2 way switch
大板16A一位开关多控 ¥:59.00
Large panel 16A 1 gang more way switch

AB-K2-0006
大板16A二位开关单控 ¥:47.30
Large panel 16A 2 gang 1 way touch switch
大板16A二位开关双控 ¥:53.10
Large panel 16A 2 gang 2 way touch switch
大板16A二位开关多控 ¥:85.10
Large panel 16A 2 gang 3 way touch switch

AB-K2-0007
大板16A三位开关单控 ¥:59.10
Large panel 16A 3 gang 1 way switch
大板16A三位开关双控 ¥:68.60
Large panel 16A 3 gang 2 way switch

AB-K2-0008
大板16A四位开关单控 ¥:73.30
Large panel 16A 4 gang 1 way switch
大板16A四位开关双控 ¥:88.00
Large panel 16A 4 gang 2 way switch

AB-K2-0009
大板16A百叶窗升降开关
Large panel louver window lifter switch
¥:64.40

AB-K2-0010
大板16A门控开关
Large panel gating switch
¥:52.40

AB-K2-0011
大板16A英式门控开关
Large panel British gating switch
¥:52.40

AB-K2-0012
大板16A门铃开关
Large panel doorbell switch
¥:52.40

AB-K2-0013
大板20A双极开关带指示灯 ¥:115.20
20A bipolar switch with neon
大板32A双极开关带指示灯 ¥:124.20
32A bipolar switch with neon

AB-K2-0014
大板45A双极开关带指示灯
45A bipolar switch with indicator light
¥:142.20

AB-K2-0015
大板16A三极插座
16A 3 pole socket
¥:48.60

AB-K2-0016
大板16A多功能插座
16A 3 pin universal socket
¥:51.50

AB-K2-0017
大板10A二三极插座
10A 5 pole socket
¥:38.30

AB-K2-0018
大板10A错位二三极插座
10A Two or three pole socket
¥:51.90

AB-K2-0019
大板16A多功能五孔插座
16A 5 pin MF socket
¥:53.60

AB-K2-0020
大板10A二二三极插座
10A 7 pole socket
¥:51.90

AB-K2-0021
大板13A方角插座
13A square corner socket
¥:51.50

AB-K2-0022
大板二位USB带16A多功能五孔插座
2 USB with 5 pin multi-function socket
¥:149. 00

AB-K2-0023
大板16A一位开关单控带16A三极插座
1gang1 way swith and 16A 3 pole socket
¥:62.90
大板16A一位开关双控带16A三极插座
1gang2 way swith and 16A 3 pole socket
¥:65.20

AB-K2-0024
大板一位开关单控带10A二三极插座
1gang2 way swith and 16A 5 pole socket
¥:59.00
大板一位开关双控带10A二三极插座
1gang 2 way swith and 5 pole socket
¥:61.10

AB-K2-0025
大板10A二位开关单控带二三极插座
2 gang 1 way swith and 5 pole socket
大板10A二位开关双控带二三极插座
2 gang 2 way swith and 5 pole socket
¥:84.80

AB-K2-0026
大板一位开关带16A三极多功能插座
(带指示灯)
1 gang swith and 16A 3 pin multi-purpose socket with indicator lighe
¥:66.00

AB-K2-0027
大板一位双极开关带13A方角插座
(指示灯)
1 gang weitch and 13A square pin socket with indicator light
¥:66.00

AB-K2-0028
大板一位开关带15A圆孔插座
(带指示灯)
1 gang weitch and 15A 3 square pin socket with indicator light
¥:66.00

AB-K2-0029
大板一位开关带16A二三极多功能
插座(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
¥:72.00

AB-K2-0030
大板一开13A多功能带双USB
(带指示灯)
1gang 13A switch and 16A 3 pin MF socket +2USB with neon
¥:158.00

AB-K2-0031
大板一开13A方插带双USB
(带指示灯)
1gang 13A square plug with 2USB(with neon)
¥:158.00

AB-K2-0032
大板16A德式插座
Large board 16A German socket
¥:58.00

AB-K2-0033
大板16A法式插座
Large plate 16A French socket
¥:58.00

AB-K2-0034
大板16A俄式插座
Large board 16A Russian socket
¥:55.00

AB-K2-0035
大板16A德式插座+二位USB
16A German socket+2 USB
¥:165.00

AB-K2-0036
大板16A法式插座+二位USB
16A French socket + 2 USB
¥:165.00

AB-K2-0037
大板16A德式插座+USB/type-c
Large board 16A German socket
+ USB / type-C
¥:165.00

AB-K2-0038
大板16A法式插座+USB/type-c
Large board 16A French socket
+ USB / type-C
¥:165.00

AB-K2-0039
大板一位电视插座
TV socket
¥:58.00

AB-K2-0040
大板一位电话插座 ¥:58.00
telephone socket
大板一位电脑插座 ¥:63.00
computer socket
大板一位电脑插座(超六类) ¥:106.00
computer socket(6)

AB-K2-0041
大板一位电视电话插座 ¥:82.00
TV + telephone socket
大板一位电视电脑插座 ¥:91.00
TV + computer socket
大板一位电视电脑插座(超六类) ¥:127.00
TV + computer socket(6)

AB-K2-0042
大板二位电视插座
Two TV socket
¥:82.00

AB-K2-0043
大板二位电话插座 ¥:82.00
Two telephone socket
大板二位电脑插座 ¥:109.00
Two computer socket
大板二位电脑插座(超六类) ¥:181.00
Two computer socket(6)
大板电话+电脑插座 ¥:91.00
telephone+computer socket
大板电话+电脑插座(超六类) ¥:127.00
telephone+computer socket(6)

AB-K2-0044
86型大板空白面板
Large plate Blank plate
¥:28.00

AB-K2-0045
小板16A一位开关单控 ¥:48.00
16A 1 gang 1 way switch
小板16A一位开关双控 ¥:52.00
16A 1 gang 2 way switch
小板16A一位开关多控 ¥:88.00
16A 1 gang more way switch

AB-K2-0046
小板16A二位开关单控 ¥:62.00
16A 2 gang 1 way switch
小板16A二位开关双控 ¥:68.00
16A 2 gang 2 way switch
小板16A二位开关多控 ¥:120.00
16A 2 gang more way switch

AB-K2-0047
小板16A三位开关单控 ¥:75.00
16A 3 gang 1 way switch
小板16A三位开关双控 ¥:84.00
16A 3 gang 2 way switch

AB-K2-0048
小板16A四位开关单控 ¥:88.00
16A 4 gang 1 way switch
小板16A四位开关双控 ¥:100.00
16A 4 gang 2 way switch

AB-K2-0049
小板16A三位开关多控
16A 3 gang 3 way switch
¥:140.00

AB-K2-0050
小板16A百叶窗升降开关
Small panel louver window lifter switch
¥:83.00

AB-K2-0051
小板16A门控开关
Small panel gating switch
¥:68.00

AB-K2-0052
小板16A英式门控开关
Small panel British gating switch
¥:68.00

AB-K2-0053
小板16A门铃开关
Small panel doorbell switch
¥:68.00

AB-K2-0054
小板16A拨动一位开关单控 ¥:108.00
1 gang 1 way toggle switch
小板16A拨动一位开关双控 ¥:114.00
1 gang 2 way toggle switch



AB-K2-0055
小板16A拨动二位开关单控 ¥:128.00
2 gang 1 way toggle switch
小板16A拨动二位开关双控 ¥:140.00
2 gang 2 way toggle switch

AB-K2-0056
小板16A拨动三位开关单控 ¥:148.00
3 gang 1 way toggle switch
小板16A拨动三位开关双控 ¥:166.00
3 gang 2 way toggle switch

AB-K2-0057
小板16A拨动四位开关单控 ¥:168.00
4 gang 1 way toggle switch
小板16A拨动四位开关双控 ¥:192.00
4 gang 2 way toggle switch

AB-K2-0058
小板20A双极开关带指示灯 ¥:128.00
20A swich with indicator light
小板45A双极开关带指示灯 ¥:158.00
45A swich with indicator light

AB-K2-0059
小板45A双极开关带指示灯
45A swich with indicator light
¥:148.00

AB-K2-0060
小板16A卷帘门复位开关
German socket
¥:108.00

AB-K2 Lacquered champagne gold 烤漆香槟金

AB-K2-0061
小板16A德式插座
German socket
¥:58.00

AB-K2-0062
小板16A法式插座
French socket
¥:58.00

AB-K2-0063
小板16A俄式插座
Russian socket
¥:58.00

AB-K2-0064
小板16A以色列插座
Israel socket
¥:68.00

AB-K2-0065
小板16A意大利+德式插座
Italy+German socket
¥:68.00

AB-K2-0066
小板10A二极插座
10A 2 pole socket
¥:55.00



AB-K2-0067
小板10A二二极插座
10A Double 2 pole socket
¥:63.00



AB-K2-0068
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:61.00



AB-K2-0069
小板10A一位开关带二二极座
1gang switch and 4 pole socket
¥:71.00

AB-K2-0070
小板16A多功能三极插座
16A MF 3 pin socket
¥:58.00

AB-K2-0071
小板13A二三极多功能插座
5 pin multi-function socket
¥:65.00

AB-K2-0072
小板13A错位多功能二三极插座
13A dislocation multi-function double and triple-pole socket
¥:68.00

AB-K2-0073
小板13A方角插座
13A square corner socket
¥:58.00

AB-K2-0074
小板15A圆角插座
15A 3 round pins socket
¥:58.00



AB-K2-0075
小板15A美标扁三极插座
15A triode flat American standard socket
¥:58.00

AB-K2-0076
小板15A泰式插座
15A Thai socket
¥:58.00



AB-K2-0077
小板15A泰式六孔插座
Dislocation Thai 6 pin socket
¥:75.00



AB-K2-0078
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:66.00



AB-K2-0079
小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pins socket
¥:68.00

AB-K2-0080
小板一位开关带16A多功能插座
1 gang switch and 16A 3 pin MF socket
¥:68.00

AB-K2-0081
小板一位开关带13A方角插座（带指示灯）
1 gang switch and 13A square pin socket with indicator light
¥:65.00

AB-K2-0082
小板一位开关带15A圆孔插座（带指示灯）
1 gang switch and 15A 3 round pins socket with indicator light
¥:68.00

AB-K2-0083
小板一位开关带16A多功能插座（带指示灯）
1 gang switch and 3 pin MF socket with light
¥:70.00

AB-K2-0084
小板一位开关带13A多功能五孔插座（带指示灯）
1 gang switch and 5 pin multi-function socket with indicator light
¥:75.00

AB-K2-0085
小板16A德式插座带二位USB
2 USB witch German socket
¥:165.00

AB-K2-0086
小板16A法式插座带二位USB
2 USB witch French socket
¥:165.00

AB-K2-0087
小板16A德标插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:165.00

AB-K2-0088
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:165.00

AB-K2-0089
小板16A一位开关带德式插座
1 gang German socket
¥:68.00

AB-K2-0090
小板16A一位开关带法式插座
1 gang French socket
¥:68.00

AB-K2-0091
小板16A德式插座带防水
German socket and Waterproof belt
¥:75.00

AB-K2-0092
小板16A法式插座带防水
French socket and Waterproof belt
¥:75.00

AB-K2-0093
小板二位USB带13A方角插座（横）
2 USB with 13A square corner socket with swith
¥:170.00

AB-K2-0094
小板15A美标插座+USB+type-c
American Standard + USB / type-C
¥:170.00

AB-K2-0095
小板15A泰式插座+USB+type-c
15A Thai + USB / type-C
¥:170.00

AB-K2-0096
小板二位USB带13A方角插座（带保护门）
2 USB with 13A square corner socket with flip cover
¥:170.00

AB-K2-0097
小板二位USB带13A多功能插座（带保护门）
2 USB with 3 pin multi-purpose socket with flip cover
¥:170.00

AB-K2-0098
小板一位开关带二位USB带13A多功能插座（带指示灯）
1 gang switch with two USB and 13A multi-function socket
¥:175.00

AB-K2-0099
小板一位开关带二位USB带13A方角插座（带指示灯）
2 USB with 13A aquare comer socket with flip cover
¥:175.00

AB-K2-0100
小板13A多功能插座带USB+type-c
13A multi-function with type-C + USB
¥:170.00

AB-K2-0101
小板13A方角插座带USB+type-c
13A square angle band type-C + USB
¥:170.00

AB-K2-0102
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with Type-c+USB(with light)
¥:175.00

AB-K2-0103
小板二位USB带13A多功能插座带小开关（竖）
2 USB with Three very multi-purpose socket with switch
¥:175.00

AB-K2-0104
小板一位开关13A方插带Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:175.00

AB-K2-0105
小板二位USB带13A方角插座带小开关（竖）
2 USB with 13A square corner socket with switch
¥:175.00

AB-K2-0106
小板15A美式插座带二位USB
American Standard + 2USB
¥:170.00

AB-K2-0107
小板15A泰式插座带双USB
15A Thai + 2USB
¥:170.00

AB-K2-0108
小板13A多功能插座带二位USB（横）
13A multi-function socket belt with two-bit USB(horizontal)
¥:183.00

AB-K2-0109
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:163.00

AB-K2-0110
小板二位USB带10A二三极插座带开关
2 USB and 5 pin socket with switch
¥:173.00

AB-K2-0111
小板10五孔插座带USB +Type-C (10W)
10A 5 pole socket with USB type-C (10W)
¥:170.00
小板10五孔插座带USB +Type-C (18W)
10A 5 pole socket with USB type-C (18W)
¥:235.00

AB-K2-0112
小板一位开关带13A多功能五孔插座带USB
1 gang swich and 5 pin multi-function socket with USB and indicator light
¥:190.00

AB-K2-0113
小板13A二位USB带多功能五孔插座
2 USB with 5 pin multi-function socket
¥:163.00

AB-K2-0114
小板13A二位USB带多功能五孔插座带开关
2 USB with 5 pin multi-function socket with switch
¥:173.00

AB-K2-0115
13A多功能五孔带USB+TYPE-C (10W)
13A MF 5 pin socket USB+type-C (10W)
¥:170.00
13A多功能五孔带USB+TYPE-C (18W)
13A MF 5 pin socket USB+type-C (18W)
¥:235.00

AB-K2-0116
小板一位电视插座
TV socket
¥:65.00

AB-K2-0117
小板一位电话插座 ¥:65.00
telephone socket
小板一位电脑插座 ¥:78.00
computer socket
小板一位电脑插座（超六类）¥:118.00
computer socket(6)

AB-K2-0118
小板双电视插座
Two TV socket
¥:91.00

AB-K2-0119
小板双电话插座 ¥:91.00
Two telephone socket
小板双电脑插座 ¥:121.00
Two computer socket
小板二位电脑插座(超六类) ¥:181.00
Two computer socket(6)
小板电话电脑插座 ¥:101.00
telephone+computer socket
小板电话电脑插座(超六类) ¥:141.00
telephone+computer socket(6)

AB-K2-0120
小板电视电话插座 ¥:91.00
TV + telephone socket
小板电视电脑插座 ¥:101.00
TV + computer socket
小板一位电视电脑插座(超六类) ¥:141.00
TV + computer socket(6)

AB-K2 Lacquered champagne gold 烤漆香槟金

AB-K2-0121

小板一位电话带USB插座 ¥:243.00
TEL + USB socket
小板一位电脑带USB插座 ¥:243.00
computer + USB socket
小板一位电脑带USB(超六类) ¥:293.00
computer + USB socket(6)

AB-K2-0122

小板一位TV+FM
TV and FM
¥:150.00

AB-K2-0123

小板一位卫星插座
Satellite socket
¥:78.00

AB-K2-0124

小板二位卫星插座
Double satellite socket
¥:121.00

AB-K2-0125

小板卫星+电视插座
Satellite and TV socket
¥:101.00

AB-K2-0126

小板卫星带电话插座 ¥:101.00
Satellite and telephone socket
小板卫星带电脑插座 ¥:121.00
Satellite and computer socket
小板卫星带电脑插座（超六类） ¥:161.00
Satellite and computer socket(6)

AB-K2-0127

小板二极插座带电视插座
2 pin socket with TV
¥:243.00

AB-K2-0128

小板二极插座带电话插座 ¥:243.00
2 pin socket with telephone
小板二极插座带电脑插座 ¥:243.00
2 pin socket with computer
小板二极插座带电脑插座(超六类) ¥:293.00
2 pin socket with computer

AB-K2-0129

小板一位光纤插座
Optical fiber socket
¥:140.00

AB-K2-0130

小板二位USB插座
Double USB socket
¥:203.00

AB-K2-0131

小板单联音响插座
Single audio socket
¥:133.00

AB-K2-0132

小板双联音响插座
Double audio socket
¥:183.00

AB-K2-0133

触摸延时开关（节能）
Touch delay delay switch
(energy saving)
¥:113.00

AB-K2-0134

声光控延时开关（节能）
Sound-light controlled delay switch
(energy saving)
¥:113.00

AB-K2-0135

红外线人体感应开关
Human body induction
¥:248.00

AB-K2-0136

凹型地脚灯（亮光/暖光）
The footlights
¥:153.00

AB-K2-0137

凹型红外线人体感应地脚灯
（亮光/暖光）
The human body induction footlights
¥:268.00

AB-K2-0138

平面地脚灯（亮光/暖光）
Footlights
¥:153.00

AB-K2-0139

叮咚门铃
Ding dong doorbell
¥:175.00

AB-K2-0140

机械式40A插卡取电 ¥:230.00
Mechanical card for electricity
感应式低频40A插卡取电 ¥:350.00
Low frequency induction card
for electricity
感应式高频40A插卡取电 ¥:400.00
High frequency induction card
for electricity

AB-K2-0141

紧急呼叫开关
Emergency call switch
¥:163.00

AB-K2-0142

请勿打扰请即清理门铃开关
(按键式)
Do not disturb please namely cleaning
please + late doorbell "button"
¥:171.00

AB-K2-0143

请勿打扰门铃开关（按键式）
Do not disturb + doorbell "button"
¥:323.00

AB-K2-0144

请勿打扰请即清理门铃开关
（按键式）
Do not disturb please namely cleaning
please "button"
¥:323.00

AB-K2-0145

智能音乐控制开关
Intelligent music control switch
¥:2700.00

AB-K2-0146

温度控制调节开关
Temperature control switch
¥:683.00

AB-K2-0147

温度控制调节开关
Temperature control switch
¥:780.00

AB-K2-0148

调音开关
Tuning switch（fire）
¥:160.00

AB-K2-0149

调光开关300W ¥:133.00
Dimming 300W
调光开关600W ¥:173.00
Dimming 600W
调光开关1000W ¥:213.00
Dimming 1000W

AB-K2-0150

调速开关300W ¥:133.00
Speed 300W
调速开关600W ¥:173.00
Speed 600W
调速开关1000W ¥:213.00
Speed 1000W

AB-K2-0151

一位开关带调光开关500W
1 gang with dimmer switch
¥:165.00

AB-K2-0152

一位开关带调速开关500W
1 gang with speed switch
¥:165.00

AB-K2-0153

13A开关带保险丝（带指示灯）
13A switch with fuse(with neon)
¥:163.00

AB-K2-0154

20A出线柱
20A outgoing post
¥:153.00

AB-K2-0155

剃须插座
Shaving socket
¥:390.00

AB-K2-0156

USB+电脑插座+无线路由
USB + computer socket,wireless router
¥:650.00

AB-K2-0157

蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio + 3.5
+ 2USB + HDMI
¥:5203.00

AB-K2-0158

HDMI
¥:243.00

AB-K2-0159

Type-c+USB(小板)
¥:283.00

AB-K2-0160

HDMI+USB
¥:243.00

AB-K2-0161

HDMI+USB+3.5音频
HDMI+USB+3.5
¥:243.00

AB-K2-0162

VGA+USB+3.5音频
VGA+USB +3.5
¥:243.00

AB-K2-0163

AV+3.5音频
AV +3.5
¥:243.00

AB-K2-0164

VGA+AV音频接口
VGA + AV audio interface
¥:243.00

AB-K2-0165

HDMI+AV音频接口
HDMI + AV audio interface
¥:243.00

AB-K2-0166

二分之一AV音频+卫星
Half AV audio interface+Satellite socket
¥:243.00.

AB-K2-0167

二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:243.00

AB-K2-0168

二分之一VGA+TV
Half VGA+TV
¥:243.00

AB-K2-0169

二分之一VGA+电脑插座
Half VGA+computer socket
¥:243.00

AB-K2-0170

VGA+USB
¥:243.00

AB-K2-0171

VGA+HDMI
¥:243.00

AB-K2-0172

45A出线柱
45A Outlet
¥:163.00

AB-K2-0173

空白面板
Blank plate
¥:37.00

AB-K2-0174

147大板二位双极开关带二位13A方角
插座（带指示灯）
Two bipolar switch with two 13A square
angle socket (with light)
¥:138.00



AB-K2-0175

147大板二位开关带二位16A多功能
插座（带指示灯）
147 Tow switch and double 16A MF
socket with light
¥:138.00



AB-K2-0176

147 二位开关带二位13A方角插座
带二位USB（带指示灯）
147 Two switch and double 13A
square comer socket with two USB
¥:238.00



AB-K2-0177

147大板二位开关带二位16A多功
能插座+2USB（带指示灯）
147 Two switch and double 16A
MF 3 pin socket with 2USB
¥:238.00

AB-K2-0178

147二位开关二位13A方插带灯
+USB/Type-c（大板）
147 Two switch and double 13A
square comer socket with USB/
Type-c
¥:268.00

AB-K2-0179

147二位开关二位13A多功能带灯
+USB/Type-c（大板）
147 Two switch and double 3 pin
MF socket with neon Type-c+USB
¥:268.00

AB-K2-0180

147型45A双极开关+一开
13A方角插带灯(炉具开关)
147 type 45A bipolar switch
+ 13A square angle plug With
light (stove switch)
¥:230.00

AB-K2 Lacquered champagne gold 烤漆香槟金

AB-K2-0181

147型45A双极开关带指示灯
147 type 45A bipolar switch with indicator light
¥:183.00

AB-K2-0182

147型空白面板
147 blank panel
¥:68.00

AB-K2-0183

小板147型16A二位开关单控
147 2 gang 1 way switch
¥:96.00
小板147型16A二位开关双控
147 2 gang 2 way switch
¥:104.00

AB-K2-0184

小板147型16A三位开关单控
147 3 gang 1 way switch
¥:110.00
小板147型16A三位开关双控
147 3 gang 2 way switch
¥:120.00

AB-K2-0185

小板147型16A四位开关单控
147 4 gang 1 way switch
¥:124.00
小板147型16A四位开关双控
147 4 gang 2 way switch
¥:136.00

AB-K2-0186

小板147型16A五位开关单控
147 5 gang 1 way switch
¥:137.00
小板147型16A五位开关双控
147 5 gang 2 way switch
¥:152.00

AB-K2-0187

小板147型16A六位开关单控
147 6 gang 1 way switch
¥:150.00
小板147型16A六位开关双控
147 6 gang 2 way switch
¥:168.00

AB-K2-0188

小板147型16A七位开关单控
147 7 gang 1 way switch
¥:163.00
小板147型16A七位开关双控
147 7 gang 2 way switch
¥:184.00

AB-K2-0189

小板147型16A八位开关单控
147 8 gang 1 way switch
¥:176.00
小板147型16A八位开关双控
147 8 gang 2 way switch
¥:200.00

AB-K2-0190

147 二位16A多功能三极插座
147 Double 16A MF socket
¥:123.00



AB-K2-0191

147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:138.00

AB-K2-0192

小板147型二位15A美标扁插座
Type 147 Double 15A US flat socket
¥:130.00



AB-K2-0193

小板147型二位15A泰式三极插座
147 Double 15A triode flat Ammerican standard socket
¥:130.00



AB-K2-0194

小板147型二位13A方角插座
Double 13A square comer socket
¥:122.00



AB-K2-0195

小板147型二位15A圆角插座
type 147 Double 15A round socket
¥:130.00

AB-K2-0196

小板147型13A错位二位多功能五孔插座
Type 147 Double 13A multi functional 5 pin socket
¥:170.00

AB-K2-0197

小板147型10A二位二三极插座
Type 147 Double 10A 5 pin socket
¥:98.00

AB-K2-0198

147 二位开关带二位13A方角插座
147 Tow switch and double 13A square comer socket
¥:168.00

AB-K2-0199

147 二位开关带二位13A多功能插座
147 Tow switch and double 13A MF 3 pin socket
¥:168.00

AB-K2-0200

147二位开关带二位多功能五孔
147 two switch with double MF 5 pin
¥:186.00

AB-K2-0201

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 13A square comer socket with indicator light
¥:138.00

AB-K2-0202

147 二位开关带二位13A多功能插座（带指示灯）
147 Tow switch and double 13A MF socket with light
¥:138.00



AB-K2-0203

147二位开关二位13A方插+二位USB（小板）
147 Tow switch and double 13A square comer socket + 2USB
¥:238.00



AB-K2-0204

147二位开关二位13A多功能+二位USB（小板）
147 Tow switch and double 13A MF socket+2USB
¥:238.00



AB-K2-0205

小板147二位开关二位13A方插+USB/Type-c（小板）
147 two switch and double 13A square band lamp+USB/Type-c
¥:268.00

AB-K2-0206

小板147二位开关二位13A多功能+USB/Type-c（小板）
147 two switch and double 13A MF band lamp +USB/Type-c
¥:268.00



AB-K2-0207

147 二位开关带二位15A圆角插座（带指示灯）
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:156.00



AB-K2-0208

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 15A square comer socket with indicator light
¥:146.00

AB-K2-0209

147 四孔剃须插座
147 two shaving socket
¥:563.00

AB-K2-0210

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 Kitchen switch
¥:260.00

AB-K2-0211

147 45A开关+一位开关13A方角插带指示灯(组合厨房开关)
147 Kitchen switch
¥:260.00

AB-K2-0212

147 45A开关+一位开关13A方插带灯（厨房开关）
147 Kitchen switch
¥:260.00

AB-K2-0213

147 45A双极开关带指示灯
147 type 45A bipolar switch
¥:183.00

AB-K2-0214

147 16A二位德式插座
147 Double Geman socket
¥:148.00

AB-K2-0215

147 16A二位法式插座
147 Double French socket
¥:148.00

AB-K2-0216

小板147型二位16A德标插座
147 Double Geman socket
¥:148.00

AB-K2-0217

小板147型二位16A法标插座
147 Double French socket
¥:148.00

AB-K2-0218

小板147型二位16A德式插座+USB/Type-c(小板）
147 Double 16A French + USB / type-c
¥:340.00

AB-K2-0219

小板147型二位16A法式插座+USB/Type-c(小板）
147 Double 16A German + USB / type-c
¥:340.00

AB-K2-0220

147型二位16A德式+2USB（小板连体）
147 Double 16A German Band socket +2USB
¥:280.00

AB-K2-0221

147二位16A法式+2USB（小板连体）
147 Double 16A German standard socket with 2USB
¥:280.00

AB-K2-0222

小板147型四位USB插座
147 4 USB socket
¥:350. 00

AB-K2-0223

147 二位多功能插座+4USB
147 2-bit multi-function socket + 4USB
¥:350.00



AB-K2-0224

147 二位13A方角插座+4USB
147 two bit 13A square socket +4USB
¥:350.00



AB-K2-0225

147 一位13A方角插座+二位USB
13A square comer socket and two USB
¥:271.00

AB-K2-0226

147型16A多功能三孔带二位USB插座
147 16A 3 pin MF socket and 2USB socket
¥:271.00

AB-K2-0227

147型二位开关带二位多功能五孔插座带双USB
147 Tow switch and double 13A 5 pin multi-purpose socket+2USB
¥:330.00



AB-K2-0228

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two switch and double 13A MF 5-pin socket + 2USB (with indicator)
¥:350.00



AB-K2-0229

147 二位13A多功能五孔插座+四位USB
147 13A double 5 pin multi function socket+4USB
¥:330.00



AB-K2-0230

小板147型二位13A多功能五孔带四位USB带小开关/指示灯
147 type double 13A multi-functional five-hole With 4USB with small switch/indicator light
¥:350.00

AB-K2-0231

小板147型二位开关带多功能五孔+USB/type-c
147 two switch with multi-function five-hole + USB/type-c
¥:350.00



AB-K2-0232

小板147型二开13A二位多功能带指示灯/4USB
147 type two switch 13A Double multi-function with indicator light /4USB
¥:350.00

AB-K2-0233

147型二开二位13A方角插座带指示灯/4USB
147 type two open two position 13A square comer socket with indicator light / 4USB
¥:350.00

AB-K2-0234

小板147二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A German socket+USB/Type-c w/neon
¥:330.00

AB-K2-0235

小板147型二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A French socket+USB/Type-c w/neon
¥:330.00

AB-K2-0236

小板147型二位开关二位16A德式插座（带指示灯）
147 two switch double 16A German socket w/neon
¥:190.00

AB-K2-0237

小板147型二位开关二位16A法式插座（带指示灯）
147 two switch double 16A French socket w/neon
¥:190.00

AB-K2-0238

小板147型二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket with neon + 2USB
¥:320.00

AB-K2-0239

小板147型二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch double 16A French socket w/neon+2USB
¥:320.00

AB-K2-0240

小板147型空白面板
147 Blank plate
¥:78.00

AB-K3 烤漆摩卡黑
Black of the lacquer that bake

让生活艺术化、让艺术生活化。艺术与生活融为一体，创造无穷的时尚诱惑与灵性空间。

Life Art for Art's lives. Integration of art and life.
Create endless fashion temptation and spiritual space.

语音/APP/轻触机械控制
Voice /APP/ touch mechanical control

情景模式/联动/定时
Scenario mode/Linkage/timing

支持多款AL音响
Support a variety of AL audio

涂鸦无线场景开关
(单火零火通用)
Doodle wireless scene switch
(Single fire and zero fire universal)

Zigbee智能按键开关
Zigbee Intelligent button switch

Zigbee一开
￥950.00

Zigbee二开
￥1050.00

Zigbee三开
￥1150.00

二三极USB/Type-c+开关
￥190.00

AB-K3 Paint mocha black 烤漆摩卡黑

AB-K3-0001
大板16A一位开关单控(荧光灯) ¥:37.30
1 gang 1 way switch
大板16A一位开关双控(荧光灯) ¥:41.30
1 gang 2 way switch
大板16A一位开关多控(荧光灯) ¥:59.00
1 gang more way switch

AB-K3-0002
大板16A二位开关单控(荧光灯) ¥:47.30
2 gang 1 way touch switch
大板16A二位开关双控(荧光灯) ¥:53.10
2 gang 2 way touch switch
大板16A二位开关多控(荧光灯) ¥:85.10
2 gang 3 way touch switch

AB-K3-0003
大板16A三位开关单控(荧光灯) ¥:59.10
3 gang 1 way switch
大板16A三位开关双控(荧光灯) ¥:68.60
3 gang 2 way switch

AB-K3-0004
大板16A四位开关单控(荧光灯) ¥:73.30
4 gang 1 way switch
大板16A四位开关双控(荧光灯) ¥:88.00
4 gang 2 way switch

AB-K3-0005
大板16A一位开关单控 ¥:37.30
Large panel 16A 1 gang 1 way switch
大板16A一位开关双控 ¥:41.30
Large panel 16A 1 gang 2 way switch
大板16A一位开关多控 ¥:59.00
Large panel 16A 1 gang more way switch

AB-K3-0006
大板16A二位开关单控 ¥:47.30
Large panel 16A 2 gang 1 way touch switch
大板16A二位开关双控 ¥:53.10
Large panel 16A 2 gang 2 way touch switch
大板16A二位开关多控 ¥:85.10
Large panel 16A 2 gang 3 way touch switch

AB-K3-0007
大板16A三位开关单控 ¥:59.10
Large panel 16A 3 gang 1 way switch
大板16A三位开关双控 ¥:68.60
Large panel 16A 3 gang 2 way switch

AB-K3-0008
大板16A四位开关单控 ¥:73.30
Large panel 16A 4 gang 1 way switch
大板16A四位开关双控 ¥:88.00
Large panel 16A 4 gang 2 way switch

AB-K3-0009
大板16A百叶窗升降开关
Large panel louver window lifter switch
¥:64.40

AB-K3-0010
大板16A门控开关
Large panel gating switch
¥:52.40

AB-K3-0011
大板16A英式门控开关
Large panel British gating switch
¥:52.40

AB-K3-0012
大板16A门铃开关
Large panel doorbell switch
¥:52.40

AB-K3-0013
大板20A双极开关带指示灯 ¥:115.20
20A bipolar switch with neon
大板32A双极开关带指示灯 ¥:124.20
32A bipolar switch with neon

AB-K3-0014
大板45A双极开关带指示灯
45A bipolar switch with indicator light
¥:142.20

AB-K3-0015
大板16A三极插座
16A 3 pole socket
¥:48.60

AB-K3-0016
大板16A多功能插座
16A 3 pin universal socket
¥:51.50

AB-K3-0017
大板10A二三极插座
10A 5 pole socket
¥:38.30

AB-K3-0018
大板10A错位二三极插座
10A Two or three pole socket
¥:51.90

AB-K3-0019
大板16A多功能五孔插座
16A 5 pin MF socket
¥:53.60

AB-K3-0020
大板10A二二三极插座
10A 7 pole socket
¥:51.90

AB-K3-0021
大板13A方角插座
13A square corner socket
¥:51.50

AB-K3-0022
大板二位USB带16A多功能五孔插座
2 USB with 5 pin multi-function socket
¥:149. 00

AB-K3-0023
大板16A一位开关单控带16A三极插座
1gang1 way swith and 16A 3 pole socket
¥:62.90
大板16A一位开关双控带16A三极插座
1gang2 way swith and 16A 3 pole socket
¥:65.20

AB-K3-0024
大板一位开关单控带10A二三极插座
1gang2 way switch and 16A 5 pole socket
¥:59.00
大板一位开关双控带10A二三极插座
1gang 2 way switch and 5 pole socket
¥:61.10

AB-K3-0025
大板10A二位开关单控带二三极插座
2 gang 1 way switch and 5 pole socket
大板10A二位开关双控带二三极插座
2 gang 2 way switch and 5 pole socket
¥:84.80

AB-K3-0026
大板一位开关带16A三极多功能插座
(带指示灯)
1 gang switch and 16A 3 pin multi-purpose socket with indicator lighe
¥:66.00

AB-K3-0027
大板一位双极开关带13A方角插座
(指示灯)
1 gang weitch and 13A square pin socket with indicator light
¥:66.00

AB-K3-0028
大板一位开关带15A圆孔插座
(带指示灯)
1 gang weitch and 15A 3 square pin socket with indicator light
¥:66.00

AB-K3-0029
大板一位开关带16A二三极多功能
插座(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
¥:72.00

AB-K3-0030
大板一开13A多功能带双USB
(带指示灯)
1gang 13A switch and 16A 3 pin MF socket +2USB with neon
¥:158.00

AB-K3-0031
大板一开13A方插带双USB
(带指示灯)
1gang 13A square plug with 2USB(with neon)
¥:158.00

AB-K3-0032
大板16A德式插座
Large board 16A German socket
¥:58.00

AB-K3-0033
大板16A法式插座
Large plate 16A French socket
¥:58.00

AB-K3-0034
大板16A俄式插座
Large board 16A Russian socket
¥:55.00

AB-K3-0035
大板16A德式插座+二位USB
16A German socket+2 USB
¥:165.00

AB-K3-0036
大板16A法式插座+二位USB
16A French socket + 2 USB
¥:165.00

AB-K3-0037
大板16A德式插座+USB/type-c
Large board 16A German socket
+ USB / type-C
¥:165.00

AB-K3-0038
大板16A法式插座+USB/type-c
Large board 16A French socket
+ USB / type-C
¥:165.00

AB-K3-0039
大板一位电视插座
TV socket
¥:58.00

AB-K3-0040
大板一位电话插座 ¥:58.00
telephone socket
大板一位电脑插座 ¥:63.00
computer socket
大板一位电脑插座(超六类) ¥:106.00
computer socket(6)

AB-K3-0041
大板一位电视电话插座 ¥:82.00
TV + telephone socket
大板一位电视电脑插座 ¥:91.00
TV + computer socket
大板一位电视电脑插座(超六类) ¥:127.00
TV + computer socket(6)

AB-K3-0042
大板二位电视插座
Two TV socket
¥:82.00

AB-K3-0043
大板二位电话插座 ¥:82.00
Two telephone socket
大板二位电脑插座 ¥:109.00
Two computer socket
大板二位电脑插座(超六类) ¥:181.00
Two computer socket(6)
大板电话+电脑插座 ¥:91.00
telephone+computer socket
大板电话+电脑插座(超六类) ¥:127.00
telephone+computer socket(6)

AB-K3-0044
86型大板空白面板
Large plate Blank plate
¥:28.00

AB-K3-0045
小板16A一位开关单控 ¥:48.00
16A 1 gang 1 way switch
小板16A一位开关双控 ¥:52.00
16A 1 gang 2 way switch
小板16A一位开关多控 ¥:88.00
16A 1 gang more way switch

AB-K3-0046
小板16A二位开关单控 ¥:62.00
16A 2 gang 1 way switch
小板16A二位开关双控 ¥:68.00
16A 2 gang 2 way switch
小板16A二位开关多控 ¥:120.00
16A 2 gang more way switch

AB-K3-0047
小板16A三位开关单控 ¥:75.00
16A 3 gang 1 way switch
小板16A三位开关双控 ¥:84.00
16A 3 gang 2 way switch

AB-K3-0048
小板16A四位开关单控 ¥:88.00
16A 4 gang 1 way switch
小板16A四位开关双控 ¥:100.00
16A 4 gang 2 way switch

AB-K3-0049
小板16A三位开关多控
16A 3 gang 3 way switch
¥:140.00

AB-K3-0050
小板16A百叶窗升降开关
Small panel louver window lifter switch
¥:83.00

AB-K3-0051
小板16A门控开关
Small panel gating switch
¥:68.00

AB-K3-0052
小板16A英式门控开关
Small panel British gating switch
¥:68.00

AB-K3-0053
小板16A门铃开关
Small panel doorbell switch
¥:68.00

AB-K3-0054
小板16A拨动一位开关单控 ¥:108.00
1 gang 1 way toggle switch
小板16A拨动一位开关双控 ¥:114.00
1 gang 2 way toggle switch

AB-K3-0055
小板16A拨动二位开关单控 ¥:128.00
2 gang 1 way toggle switch
小板16A拨动二位开关双控 ¥:140.00
2 gang 2 way toggle switch

AB-K3-0056
小板16A拨动三位开关单控 ¥:148.00
3 gang 1 way toggle switch
小板16A拨动三位开关双控 ¥:166.00
3 gang 2 way toggle switch

AB-K3-0057
小板16A拨动四位开关单控 ¥:168.00
4 gang 1 way toggle switch
小板16A拨动四位开关双控 ¥:192.00
4 gang 2 way toggle switch

AB-K3-0058
小板20A双极开关带指示灯 ¥:128.00
20A swich with indicator light
小板45A双极开关带指示灯 ¥:158.00
45A swich with indicator light

AB-K3-0059
小板45A双极开关带指示灯
45A swich with indicator light
¥:148.00

AB-K3-0060
小板16A卷帘门复位开关
German socket
¥:108.00

AB-K3 Paint mocha black 烤漆摩卡黑

AB-K3-0061
小板16A德式插座
German socket
¥:58.00

AB-K3-0062
小板16A法式插座
French socket
¥:58.00

AB-K3-0063
小板16A俄式插座
Russian socket
¥:58.00

AB-K3-0064
小板16A以色列插座
Israel socket
¥:68.00

AB-K3-0065
小板16A意大利+德式插座
Italy+German socket
¥:68.00

AB-K3-0071
小板13A二三极多功能插座
5 pin multi-function socket
¥:65.00

AB-K3-0072
小板13A错位多功能二三极插座
13A dislocation multi-function double and triple-pole socket
¥:68.00

AB-K3-0073
小板13A方角插座
13A square corner socket
¥:58.00

AB-K3-0074
小板15A圆角插座
15A 3 round pins socket
¥:58.00

AB-K3-0075
小板15A美标扁三极插座
15A triode flat American standard socket
¥:58.00

AB-K3-0081
小板一位开关带13A方角插座
（带指示灯）
1 gang switch and 13A square pin socket with indicator light
¥:65.00

AB-K3-0082
小板一位开关带15A圆孔插座
（带指示灯）
1 gang switch and 15A 3 round pins socket with indicator light
¥:68.00

AB-K3-0083
小板一位开关带16A多功能插座
（带指示灯）
1 gang switch and 3 pin MF socket with light
¥:70.00

AB-K3-0084
小板一位开关带13A多功能五孔插座
（带指示灯）
1 gang switch and 5 pin multi-function socket with indicator light
¥:75.00

AB-K3-0085
小板16A德式插座带二位USB
2 USB witch German socket
¥:165.00

AB-K3-0066
小板10A二极插座
10A 2 pole socket
¥:55.00

AB-K3-0067
小板10A二二极插座
10A Double 2 pole socket
¥:63.00

AB-K3-0068
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:61.00

AB-K3-0069
小板10A一位开关带二二极座
1gang switch and 4 pole socket
¥:71.00

AB-K3-0070
小板16A多功能三极插座
16A MF 3 pin socket
¥:58.00

AB-K3-0076
小板15A泰式插座
15A Thai socket
¥:58.00

AB-K3-0077
小板15A泰式六孔插座
Dislocation Thai 6 pin socket
¥:75.00

AB-K3-0078
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:66.00

AB-K3-0079
小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pins socket
¥:68.00

AB-K3-0080
小板一位开关带16A多功能插座
1 gang switch and 16A 3 pin MF socket
¥:68.00

AB-K3-0086
小板16A法式插座带二位USB
2 USB witch French socket
¥:165.00

AB-K3-0087
小板16A德标插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:165.00

AB-K3-0088
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:165.00

AB-K3-0089
小板16A一位开关带德式插座
1 gang German socket
¥:68.00

AB-K3-0090
小板16A一位开关带法式插座
1 gang French socket
¥:68.00

AB-K3-0091
小板16A德式插座带防水
German socket and Waterproof belt
¥:75.00

AB-K3-0092
小板16A法式插座带防水
French socket and Waterproof belt
¥:75.00

AB-K3-0093
小板二位USB带13A方角插座（横）
2 USB with 13A square corner socket with swith
¥:170.00

AB-K3-0094
小板15A美标插座+USB+type-c
American Standard + USB / type-C
¥:170.00

AB-K3-0095
小板15A泰式插座+USB+type-c
15A Thai + USB / type-C
¥:170.00

AB-K3-0096
小板二位USB带13A方角插座
（带保护门）
2 USB with 13A square corner socket with flip cover
¥:170.00

AB-K3-0097
小板二位USB带13A多功能插座
（带保护门）
2 USB with 3 pin multi-purpose socket with flip cover
¥:170.00

AB-K3-0098
小板一位开关带二位USB带13A多功能插座（带指示灯）
1 gang switch with two USB and 13A multi-function socket
¥:175.00

AB-K3-0099
小板一位开关带二位USB带13A方角插座（带指示灯）
2 USB with 13A aquare comer socket with flip cover
¥:175.00

AB-K3-0100
小板13A多功能插座带USB+type-c
13A multi-function with type-C + USB
¥:170.00

AB-K3-0101
小板13A方角插座带USB+type-c
13A square angle band type-C + USB
¥:170.00

AB-K3-0102
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with Type-c+USB(with light)
¥:175.00

AB-K3-0103
小板二位USB带13A多功能插座带小开关（竖）
2 USB with Three very multi-purpose socket with switch
¥:175.00

AB-K3-0104
小板一位开关13A方插带Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:175.00

AB-K3-0105
小板二位USB带13A方角插座带小开关（竖）
2 USB with 13A square corner socket with switch
¥:175.00

AB-K3-0106
小板15A美式插座带二位USB
American Standard + 2USB
¥:170.00

AB-K3-0107
小板15A泰式插座带双USB
15A Thai + 2USB
¥:170.00

AB-K3-0108
小板13A多功能插座带二位USB（横）
13A multi-function socket belt with two-bit USB(horizontal)
¥:183.00

AB-K3-0109
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:163.00

AB-K3-0110
小板二位USB带10A二三极插座带开关
2 USB and 5 pin socket with switch
¥:173.00

AB-K3-0111
小板10五孔插座带USB +Type-C (10W)
10A 5 pole socket with USB type-C (10W)
¥:170.00
小板10五孔插座带USB +Type-C (18W)
10A 5 pole socket with USB type-C (18W)
¥:235.00

AB-K3-0112
小板一位开关带13A多功能五孔插座带USB
1 gang swich and 5 pin multi-function socket with USB and indicator light
¥:190.00

AB-K3-0113
小板13A二位USB带多功能五孔插座
2 USB with 5 pin multi-function socket
¥:163.00

AB-K3-0114
小板13A二位USB带多功能五孔插座带开关
2 USB with 5 pin multi-function socket with switch
¥:173.00

AB-K3-0115
13A多功能五孔带USB+TYPE-C (10W)
13A MF 5 pin socket USB+type-C (10W)
¥:170.00
13A多功能五孔带USB+TYPE-C (18W)
13A MF 5 pin socket USB+type-C (18W)
¥:235.00

AB-K3-0116
小板一位电视插座
TV socket
¥:65.00

AB-K3-0117
小板一位电话插座 ¥:65.00
telephone socket
小板一位电脑插座 ¥:78.00
computer socket
小板一位电脑插座（超六类）¥:118.00
computer socket(6)

AB-K3-0118
小板双电视插座
Two TV socket
¥:91.00

AB-K3-0119
小板双电话插座 ¥:91.00
Two telephone socket
小板双电脑插座 ¥:121.00
Two computer socket
小板二位电脑插座(超六类) ¥:181.00
Two computer socket(6)
小板电话电脑插座 ¥:101.00
telephone+computer socket
小板电话电脑插座(超六类) ¥:141.00
telephone+computer socket(6)

AB-K3-0120
小板电视电话插座 ¥:91.00
TV + telephone socket
小板电视电脑插座 ¥:101.00
TV + computer socket
小板一位电视电脑插座(超六类) ¥:141.00
TV + computer socket(6)

AB-K3 Paint mocha black 烤漆摩卡黑

AB-K3-0121

小板一位电话带USB插座 ¥:243.00
TEL + USB socket
小板一位电脑带USB插座 ¥:243.00
computer + USB socket
小板一位电脑带USB(超六类) ¥:293.00
computer + USB socket(6)

AB-K3-0122

小板一位TV+FM
TV and FM
¥:150.00

AB-K3-0123

小板一位卫星插座
Satellite socket
¥:78.00

AB-K3-0124

小板二位卫星插座
Double satellite socket
¥:121.00

AB-K3-0125

小板卫星+电视插座
Satellite and TV socket
¥:101.00

AB-K3-0126

小板卫星带电话插座 ¥:101.00
Satellite and telephone socket
小板卫星带电脑插座 ¥:121.00
Satellite and computer socket
小板卫星带电脑插座（超六类） ¥:161.00
Satellite and computer socket(6)

AB-K3-0127

小板二极插座带电视插座
2 pin socket with TV
¥:243.00

AB-K3-0128

小板二极插座带电话插座 ¥:243.00
2 pin socket with telephone
小板二极插座带电脑插座 ¥:243.00
2 pin socket with computer
小板二极插座带电脑插座(超六类) ¥:293.00
2 pin socket with computer

AB-K3-0129

小板一位光纤插座
Optical fiber socket
¥:140.00

AB-K3-0130

小板二位USB插座
Double USB socket
¥:203.00

AB-K3-0131

小板单联音响插座
Single audio socket
¥:133.00

AB-K3-0132

小板双联音响插座
Double audio socket
¥:183.00

AB-K3-0133

触摸延时开关（节能）
Touch delay delay switch
(energy saving)
¥:113.00

AB-K3-0134

声光控延时开关（节能）
Sound-light controlled delay switch
(energy saving)
¥:113.00

AB-K3-0135

红外线人体感应开关
Human body induction
¥:248.00

AB-K3-0136

凹型地脚灯（亮光/暖光）
The footlights
¥:153.00

AB-K3-0137

凹型红外线人体感应地脚灯
（亮光/暖光）
The human body induction footlights
¥:268.00

AB-K3-0138

平面地脚灯（亮光/暖光）
Footlights
¥:153.00

AB-K3-0139

叮咚门铃
Ding dong doorbell
¥:175.00

AB-K3-0140

机械式40A插卡取电 ¥:230.00
Mechanical card for electricity
感应式低频40A插卡取电 ¥:350.00
Low frequency induction card
for electricity
感应式高频40A插卡取电 ¥:400.00
High frequency induction card
for electricity

AB-K3-0141

紧急呼叫开关
Emergency call switch
¥:163.00

AB-K3-0142

请勿打扰请即清理门铃开关
(按键式)
Do not disturb please namely cleaning
please + late doorbell "button"
¥:171.00

AB-K3-0143

请勿打扰门铃开关（按键式）
Do not disturb + doorbell "button"
¥:323.00

AB-K3-0144

请勿打扰请即清理门铃开关
（按键式）
Do not disturb please namely cleaning
please "button"
¥:323.00

AB-K3-0145

智能音乐控制开关
Intelligent music control switch
¥:2700.00

AB-K3-0146

温度控制调节开关
Temperature control switch
¥:683.00

AB-K3-0147

温度控制调节开关
Temperature control switch
¥:780.00

AB-K3-0148

调音开关
Tuning switch（fire）
¥:160.00

AB-K3-0149

调光开关300W ¥:133.00
Dimming 300W
调光开关600W ¥:173.00
Dimming 600W
调光开关1000W ¥:213.00
Dimming 1000W

AB-K3-0150

调速开关300W ¥:133.00
Speed 300W
调速开关600W ¥:173.00
Speed 600W
调速开关1000W ¥:213.00
Speed 1000W

AB-K3-0151

一位开关带调光开关500W
1 gang with dimmer switch
¥:165.00

AB-K3-0152

一位开关带调速开关500W
1 gang with speed switch
¥:165.00

AB-K3-0153

13A开关带保险丝（带指示灯）
13A switch with fuse(with neon)
¥:163.00

AB-K3-0154

20A出线柱
20A outgoing post
¥:153.00

AB-K3-0155

剃须插座
Shaving socket
¥:390.00

AB-K3-0156

USB+电脑插座+无线路由
USB + computer socket,wireless router
¥:650.00

AB-K3-0157

蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio + 3.5
+ 2USB + HDMI
¥:5203.00

AB-K3-0158

HDMI
¥:243.00

AB-K3-0159

Type-c+USB(小板）
¥:283.00

AB-K3-0160

HDMI+USB
¥:243.00

AB-K3-0161

HDMI+USB+3.5音频
HDMI+USB+3.5
¥:243.00

AB-K3-0162

VGA+USB+3.5音频
VGA+USB +3.5
¥:243.00

AB-K3-0163

AV+3.5音频
AV +3.5
¥:243.00

AB-K3-0164

VGA+AV音频接口
VGA + AV audio interface
¥:243.00

AB-K3-0165

HDMI+AV音频接口
HDMI + AV audio interface
¥:243.00

AB-K3-0166

二分之一AV音频+卫星
Half AV audio interface+Satellite socket
¥:243.00.

AB-K3-0167

二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:243.00

AB-K3-0168

二分之一VGA+TV
Half VGA+TV
¥:243.00

AB-K3-0169

二分之一VGA+电脑插座
Half VGA+computer socket
¥:243.00

AB-K3-0170

VGA+USB
¥:243.00

AB-K3-0171

VGA+HDMI
¥:243.00

AB-K3-0172

45A出线柱
45A Outlet
¥:163.00

AB-K3-0173

空白面板
Blank plate
¥:37.00

AB-K3-0174

147大板二位双极开关带二位13A方角
插座（带指示灯）
Two bipolar switch with two 13A square
angle socket (with light)
¥:138.00

AB-K3-0175

147大板二位开关带二位16A多功能
插座（带指示灯）
147 Tow switch and double 16A MF
socket with light
¥:138.00

AB-K3-0176

147 二位开关带二位13A方角插座
带二位USB（带指示灯）
147 Two switch and double 13A
square corner socket with two USB
¥:238.00

AB-K3-0177

147大板二位开关带二位16A多功
能插座+2USB（带指示灯）
147 Two switch and double 16A
MF 3 pin socket with 2USB
¥:238.00

AB-K3-0178

147二位开关二位13A方插带灯
+USB/Type-c（大板）
147 Two switch and double 13A
square corner socket with USB/
Type-c
¥:268.00

AB-K3-0179

147二位开关二位13A多功能带灯
+USB/Type-c（大板）
147 Two switch and double 3 pin
MF socket with neon Type-c+USB
¥:268.00

AB-K3-0180

147型45A双极开关+一开
13A方角插带灯(炉具开关)
147 type 45A bipolar switch
+ 13A square angle plug With
light (stove switch)
¥:230.00

AB-K3 Paint mocha black 烤漆摩卡黑

AB-K3-0181

147型45A双极开关带指示灯
147 type 45A bipolar switch with indicator light
¥:183.00

AB-K3-0191

147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:138.00

AB-K3-0201

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 13A square comer socket with indicator light
¥:138.00

AB-K3-0182

147型空白面板
147 blank panel
¥:68.00

AB-K3-0192

小板147型二位15A美标扁插座
Type 147 Double 15A US flat socket
¥:130.00

AB-K3-0202

147 二位开关带二位13A多功能插座（带指示灯）
147 Tow switch and double 13A MF socket with light
¥:138.00

AB-K3-0183

小板147型16A二位开关单控
147 2 gang 1 way switch
¥:96.00
小板147型16A二位开关双控
147 2 gang 2 way switch
¥:104.00

AB-K3-0193

小板147型二位15A泰式三极插座
147 Double 15A triode flat Ammerican standard socket
¥:130.00

AB-K3-0203

147二位开关二位13A方插+二位USB（小板）
147 Tow switch and double 13A square corner socket + 2USB
¥:238.00

AB-K3-0184

小板147型16A三位开关单控
147 3 gang 1 way switch
¥:110.00
小板147型16A三位开关双控
147 3 gang 2 way switch
¥:120.00

AB-K3-0194

小板147型二位13A方角插座
Double 13A square comer socket
¥:122.00

AB-K3-0204

147二位开关二位13A多功能+二位USB（小板）
147 Tow switch and double 13A MF socket+2USB
¥:238.00

AB-K3-0185

小板147型16A四位开关单控
147 4 gang 1 way switch
¥:124.00
小板147型16A四位开关双控
147 4 gang 2 way switch
¥:136.00

AB-K3-0195

小板147型二位15A圆角插座
type 147 Double 15A round socket
¥:130.00

AB-K3-0205

小板147二位开关二位13A方插+USB/Type-c（小板）
147 two switch and double 13A square band lamp+USB/Type-c
¥:268.00

AB-K3-0186

小板147型16A五位开关单控
147 5 gang 1 way switch
¥:137.00
小板147型16A五位开关双控
147 5 gang 2 way switch
¥:152.00

AB-K3-0196

小板147型13A错位二位多功能五孔插座
Type 147 Double 13A multi functional 5 pin socket
¥:170.00

AB-K3-0206

小板147二位开关二位13A多功能+USB/Type-c（小板）
147 two switch and double 13A MF band lamp +USB/Type-c
¥:268.00

AB-K3-0187

小板147型16A六位开关单控
147 6 gang 1 way switch
¥:150.00
小板147型16A六位开关双控
147 6 gang 2 way switch
¥:168.00

AB-K3-0197

小板147型10A二位二三极插座
Type 147 Double 10A 5 pin socket
¥:98.00

AB-K3-0207

147 二位开关带二位15A圆角插座（带指示灯）
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:156.00

AB-K3-0188

小板147型16A七位开关单控
147 7 gang 1 way switch
¥:163.00
小板147型16A七位开关双控
147 7 gang 2 way switch
¥:184.00

AB-K3-0198

147 二位开关带二位13A方角插座
147 Tow switch and double 13A square corner socket
¥:168.00

AB-K3-0208

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 15A square corner socket with indicator light
¥:146.00

AB-K3-0189

小板147型16A八位开关单控
147 8 gang 1 way switch
¥:176.00
小板147型16A八位开关双控
147 8 gang 2 way switch
¥:200.00

AB-K3-0199

147 二位开关带二位13A多功能插座
147 Tow switch and double 13A MF 3 pin socket
¥:168.00

AB-K3-0209

147 四孔剃须插座
147 two shaving socket
¥:563.00



AB-K3-0190

147 二位16A多功能三极插座
147 Double 16A MF socket
¥:123.00

AB-K3-0200

147二位开关带二位多功能五孔
147 two switch with double MF 5 pin
¥:186.00

AB-K3-0210

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 Kitchen switch
¥:260.00

AB-K3-0211

147 45A开关+一位开关13A方角插带指示灯(组合厨房开关)
147 Kitchen switch
¥:260.00

AB-K3-0221

147二位16A法式+2USB（小板连体）
147 Double 16A German standard socket with 2USB
¥:280.00

AB-K3-0231

小板147型二位开关带多功能五孔+USB/type-c
147 two switch with multi-function five-hole + USB/type-c
¥:350.00

AB-K3-0212

147 45A开关+一位开关13A方插带灯（厨房开关）
147 Kitchen switch
¥:260.00

AB-K3-0222

小板147型四位USB插座
147 4 USB socket
¥:350. 00

AB-K3-0232

小板147型二开13A二位多功能带指示灯/4USB
147 type two switch 13A Double multi-function with indicator light /4USB
¥:350.00

AB-K3-0213

147 45A双极开关带指示灯
147 type 45A bipolar switch
¥:183.00

AB-K3-0223

147 二位多功能插座+4USB
147 2-bit multi-function socket + 4USB
¥:350.00

AB-K3-0233

147型二开二位13A方角插座带指示灯/4USB
147 type two open two position 13A square corner socket with indicator light / 4USB
¥:350.00

AB-K3-0214

147 16A二位德式插座
147 Double Geman socket
¥:148.00

AB-K3-0224

147 二位13A方角插座+4USB
147 two bit 13A square socket +4USB
¥:350.00

AB-K3-0234

小板147二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A German socket+USB/Type-c w/neon
¥:330.00

AB-K3-0215

147 16A二位法式插座
147 Double French socket
¥:148.00

AB-K3-0225

147 一位13A方角插座+二位USB
13A square comer socket and two USB
¥:271.00

AB-K3-0235

小板147型二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A French socket+USB/Type-c w/neon
¥:330.00

AB-K3-0216

小板147型二位16A德标插座
147 Double Geman socket
¥:148.00

AB-K3-0226

147型16A多功能三孔带二位USB插座
147 16A 3 pin MF socket and 2USB socket
¥:271.00

AB-K3-0236

小板147型二位开关二位16A德式插座（带指示灯）
147 two switch double 16A German socket w/neon
¥:190.00

AB-K3-0217

小板147型二位16A法标插座
147 Double French socket
¥:148.00

AB-K3-0227

147型二位开关带二位多功能五孔插座带双USB
147 Tow switch and double 13A 5 pin multi-purpose socket+2USB
¥:330.00

AB-K3-0237

小板147型二位开关二位16A法式插座（带指示灯）
147 two switch double 16A French socket w/neon
¥:190.00

AB-K3-0218

小板147型二位16A德式插座+USB/Type-c(小板）
147 Double 16A French + USB / type-c
¥:340.00

AB-K3-0228

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two switch and double 13A MF 5-pin socket + 2USB (with indicator)
¥:350.00

AB-K3-0238

小板147型二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket with neon + 2USB
¥:320.00

AB-K3-0219

小板147型二位16A法式插座+USB/Type-c(小板）
147 Double 16A German + USB / type-c
¥:340.00

AB-K3-0229

147 二位13A多功能五孔插座+四位USB
147 13A double 5 pin multi function socket+4USB
¥:330.00

AB-K3-0239

小板147型二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch double 16A French socket w/neon+2USB
¥:320.00

AB-K3-0220

147型二位16A德式+2USB（小板连体）
147 Double 16A German Band socket +2USB
¥:280.00

AB-K3-0230

小板147型二位13A多功能五孔带四位USB带小开关/指示灯
147 type double 13A multi-functional five-hole With 4USB with small switch/indicator light
¥:350.00

AB-K3-0240

小板147型空白面板
147 Blank plate
¥:78.00



Zigbee智能按键开关

Zigbee Intelligent button switch

Zigbee一开
￥950.00

语音/APP/轻触机械控制
Voice /APP/ touch mechanical control

Zigbee二开
￥1050.00

情景模式/联动/定时
Scenario mode/Linkage/timing

Zigbee三开
￥1150.00

支持多款AL音响
Support a variety of AL audio

二三极USB/Type-c+开关
￥190.00

涂鸦无线场景开关
(单火零火通用)
Doodle wireless scene switch
(Single fire and zero fire universal)

AB-K4 烤漆太空灰

Baking paint space gray



时尚 · 简约自然

小角度开合
轻简却令人倍感舒心
注重家的每处细节

Fashion & simple and natural

Small angle opening and closing
Simple but comfortable
Pay attention to every detail of home

AB-K4 Baking paint space gray 烤漆太空灰

AB-K4-0001
大板16A一位开关单控(荧光灯) ¥:37.30
1 gang 1 way switch
大板16A一位开关双控(荧光灯) ¥:41.30
1 gang 2 way switch
大板16A一位开关多控(荧光灯) ¥:59.00
1 gang more way switch

AB-K4-0002
大板16A二位开关单控(荧光灯) ¥:47.30
2 gang 1 way touch switch
大板16A二位开关双控(荧光灯) ¥:53.10
2 gang 2 way touch switch
大板16A二位开关多控(荧光灯) ¥:85.10
2 gang 3 way touch switch

AB-K4-0003
大板16A三位开关单控(荧光灯) ¥:59.10
3 gang 1 way switch
大板16A三位开关双控(荧光灯) ¥:68.60
3 gang 2 way switch

AB-K4-0004
大板16A四位开关单控(荧光灯) ¥:73.30
4 gang 1 way switch
大板16A四位开关双控(荧光灯) ¥:88.00
4 gang 2 way switch

AB-K4-0005
大板16A一位开关单控 ¥:37.30
Large panel 16A 1 gang 1 way switch
大板16A一位开关双控 ¥:41.30
Large panel 16A 1 gang 2 way switch
大板16A一位开关多控 ¥:59.00
Large panel 16A 1 gang more way switch

AB-K4-0006
大板16A二位开关单控 ¥:47.30
Large panel 16A 2 gang 1 way touch switch
大板16A二位开关双控 ¥:53.10
Large panel 16A 2 gang 2 way touch switch
大板16A二位开关多控 ¥:85.10
Large panel 16A 2 gang 3 way touch switch

AB-K4-0007
大板16A三位开关单控 ¥:59.10
Large panel 16A 3 gang 1 way switch
大板16A三位开关双控 ¥:68.60
Large panel 16A 3 gang 2 way switch

AB-K4-0008
大板16A四位开关单控 ¥:73.30
Large panel 16A 4 gang 1 way switch
大板16A四位开关双控 ¥:88.00
Large panel 16A 4 gang 2 way switch

AB-K4-0009
大板16A百叶窗升降开关
Large panel louver window lifter switch
¥:64.40

AB-K4-0010
大板16A门控开关
Large panel gating switch
¥:52.40

AB-K4-0011
大板16A英式门控开关
Large panel British gating switch
¥:52.40

AB-K4-0012
大板16A门铃开关
Large panel doorbell switch
¥:52.40

AB-K4-0013
大板20A双极开关带指示灯 ¥:115.20
20A bipolar switch with neon
大板32A双极开关带指示灯 ¥:124.20
32A bipolar switch with neon

AB-K4-0014
大板45A双极开关带指示灯
45A bipolar switch with indicator light
¥:142.20

AB-K4-0015
大板16A三极插座
16A 3 pole socket
¥:48.60

AB-K4-0016
大板16A多功能插座
16A 3 pin universal socket
¥:51.50

AB-K4-0017
大板10A二三极插座
10A 5 pole socket
¥:38.30

AB-K4-0018
大板10A错位二三极插座
10A Two or three pole socket
¥:51.90

AB-K4-0019
大板16A多功能五孔插座
16A 5 pin MF socket
¥:53.60

AB-K4-0020
大板10A二二三极插座
10A 7 pole socket
¥:51.90

AB-K4-0021
大板13A方角插座
13A square corner socket
¥:51.50

AB-K4-0022
大板二位USB带16A多功能五孔插座
2 USB with 5 pin multi-function socket
¥:149. 00

AB-K4-0023
大板16A一位开关单控带16A三极插座
1gang1 way swith and 16A 3 pole socket
¥:62.90
大板16A一位开关双控带16A三极插座
1gang2 way swith and 16A 3 pole socket
¥:65.20

AB-K4-0024
大板一位开关单控带10A二三极插座
1gang2 way switch and 16A 5 pole socket
¥:59.00
大板一位开关双控带10A二三极插座
1gang 2 way switch and 5 pole socket
¥:61.10

AB-K4-0025
大板10A二位开关单控带二三极插座
2 gang 1 way switch and 5 pole socket
大板10A二位开关双控带二三极插座
2 gang 2 way switch and 5 pole socket
¥:84.80

AB-K4-0026
大板一位开关带16A三极多功能插座
(带指示灯)
1 gang switch and 16A 3 pin multi-purpose socket with indicator lighe
¥:66.00

AB-K4-0027
大板一位双极开关带13A方角插座
(指示灯)
1 gang weitch and 13A square pin socket with indicator light
¥:66.00

AB-K4-0028
大板一位开关带15A圆孔插座
(带指示灯)
1 gang weitch and 15A 3 square pin socket with indicator light
¥:66.00

AB-K4-0029
大板一位开关带16A二三极多功能插座(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
¥:72.00

AB-K4-0030
大板一开13A多功能带双USB
(带指示灯)
1gang 13A switch and 16A 3 pin MF socket +2USB with neon
¥:158.00

AB-K4-0031
大板一开13A方插带双USB
(带指示灯)
1gang 13A square plug with 2USB(with neon)
¥:158.00

AB-K4-0032
大板16A德式插座
Large board 16A German socket
¥:58.00

AB-K4-0033
大板16A法式插座
Large plate 16A French socket
¥:58.00

AB-K4-0034
大板16A俄式插座
Large board 16A Russian socket
¥:55.00

AB-K4-0035
大板16A德式插座+二位USB
16A German socket+2 USB
¥:165.00

AB-K4-0036
大板16A法式插座+二位USB
16A French socket + 2 USB
¥:165.00

AB-K4-0037
大板16A德式插座+USB/type-c
Large board 16A German socket
+ USB / type-C
¥:165.00

AB-K4-0038
大板16A法式插座+USB/type-c
Large board 16A French socket
+ USB / type-C
¥:165.00

AB-K4-0039
大板一位电视插座
TV socket
¥:58.00

AB-K4-0040
大板一位电话插座 ¥:58.00
telephone socket
大板一位电脑插座 ¥:63.00
computer socket
大板一位电脑插座(超六类) ¥:106.00
computer socket(6)

AB-K4-0041
大板一位电视电话插座 ¥:82.00
TV + telephone socket
大板一位电视电脑插座 ¥:91.00
TV + computer socket
大板一位电视电脑插座(超六类) ¥:127.00
TV + computer socket(6)

AB-K4-0042
大板二位电视插座
Two TV socket
¥:82.00

AB-K4-0043
大板二位电话插座 ¥:82.00
Two telephone socket
大板二位电脑插座 ¥:109.00
Two computer socket
大板二位电脑插座(超六类) ¥:181.00
Two computer socket(6)
大板电话+电脑插座 ¥:91.00
telephone+computer socket
大板电话+电脑插座(超六类) ¥:127.00
telephone+computer socket(6)

AB-K4-0044
86型大板空白面板
Large plate Blank plate
¥:28.00

AB-K4-0045
小板16A一位开关单控 ¥:48.00
16A 1 gang 1 way switch
小板16A一位开关双控 ¥:52.00
16A 1 gang 2 way switch
小板16A一位开关多控 ¥:88.00
16A 1 gang more way switch

AB-K4-0046
小板16A二位开关单控 ¥:62.00
16A 2 gang 1 way switch
小板16A二位开关双控 ¥:68.00
16A 2 gang 2 way switch
小板16A二位开关多控 ¥:120.00
16A 2 gang more way switch

AB-K4-0047
小板16A三位开关单控 ¥:75.00
16A 3 gang 1 way switch
小板16A三位开关双控 ¥:84.00
16A 3 gang 2 way switch



AB-K4-0048
小板16A四位开关单控 ¥:88.00
16A 4 gang 1 way switch
小板16A四位开关双控 ¥:100.00
16A 4 gang 2 way switch

AB-K4-0049
小板16A三位开关多控
16A 3 gang 3 way switch
¥:140.00

AB-K4-0050
小板16A百叶窗升降开关
Small panel louver window lifter switch
¥:83.00

AB-K4-0051
小板16A门控开关
Small panel gating switch
¥:68.00

AB-K4-0052
小板16A英式门控开关
Small panel British gating switch
¥:68.00

AB-K4-0053
小板16A门铃开关
Small panel doorbell switch
¥:68.00

AB-K4-0054
小板16A拨动一位开关单控 ¥:108.00
1 gang 1 way toggle switch
小板16A拨动一位开关双控 ¥:114.00
1 gang 2 way toggle switch

AB-K4-0055
小板16A拨动二位开关单控 ¥:128.00
2 gang 1 way toggle switch
小板16A拨动二位开关双控 ¥:140.00
2 gang 2 way toggle switch

AB-K4-0056
小板16A拨动三位开关单控 ¥:148.00
3 gang 1 way toggle switch
小板16A拨动三位开关双控 ¥:166.00
3 gang 2 way toggle switch

AB-K4-0057
小板16A拨动四位开关单控 ¥:168.00
4 gang 1 way toggle switch
小板16A拨动四位开关双控 ¥:192.00
4 gang 2 way toggle switch

AB-K4-0058
小板20A双极开关带指示灯 ¥:128.00
20A swich with indicator light
小板45A双极开关带指示灯 ¥:158.00
45A swich with indicator light

AB-K4-0059
小板45A双极开关带指示灯
45A swich with indicator light
¥:148.00

AB-K4-0060
小板16A卷帘门复位开关
German socket
¥:108.00

AB-K4 Baking paint space gray 烤漆太空灰

AB-K4-0061
小板16A德式插座
German socket
¥:58.00

AB-K4-0062
小板16A法式插座
French socket
¥:58.00

AB-K4-0063
小板16A俄式插座
Russian socket
¥:58.00

AB-K4-0064
小板16A以色列插座
Israel socket
¥:68.00

AB-K4-0065
小板16A意大利+德式插座
Italy+German socket
¥:68.00

AB-K4-0066
小板10A二极插座
10A 2 pole socket
¥:55.00

AB-K4-0067
小板10A二二极插座
10A Double 2 pole socket
¥:63.00

AB-K4-0068
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:61.00

AB-K4-0069
小板10A一位开关带二二极座
1gang switch and 4 pole socket
¥:71.00

AB-K4-0070
小板16A多功能三极插座
16A MF 3 pin socket
¥:58.00

AB-K4-0071
小板13A二三极多功能插座
5 pin multi-function socket
¥:65.00

AB-K4-0072
小板13A错位多功能二三极插座
13A dislocation multi-function double and triple-pole socket
¥:68.00

AB-K4-0073
小板13A方角插座
13A square corner socket
¥:58.00

AB-K4-0074
小板15A圆角插座
15A 3 round pins socket
¥:58.00

AB-K4-0075
小板15A美标扁三极插座
15A triode flat American standard socket
¥:58.00

AB-K4-0076
小板15A泰式插座
15A Thai socket
¥:58.00

AB-K4-0077
小板15A泰式六孔插座
Dislocation Thai 6 pin socket
¥:75.00

AB-K4-0078
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:66.00

AB-K4-0079
小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pins socket
¥:68.00

AB-K4-0080
小板一位开关带16A多功能插座
1 gang switch and 16A 3 pin MF socket
¥:68.00

AB-K4-0081
小板一位开关带13A方角插座
（带指示灯）
1 gang switch and 13A square pin socket with indicator light
¥:65.00

AB-K4-0082
小板一位开关带15A圆孔插座
（带指示灯）
1 gang switch and 15A 3 round pins socket with indicator light
¥:68.00

AB-K4-0083
小板一位开关带16A多功能插座
（带指示灯）
1 gang switch and 3 pin MF socket with light
¥:70.00

AB-K4-0084
小板一位开关带13A多功能五孔插座
（带指示灯）
1 gang switch and 5 pin multi-function socket with indicator light
¥:75.00

AB-K4-0085
小板16A德式插座带二位USB
2 USB witch German socket
¥:165.00

AB-K4-0086
小板16A法式插座带二位USB
2 USB witch French socket
¥:165.00

AB-K4-0087
小板16A德标插座+USB/Type-c
Small board 16A German socket
+ USB / type-c
¥:165.00

AB-K4-0088
小板16A法式插座+USB/Type-c
Small board 16A French socket
+ USB / type-c
¥:165.00

AB-K4-0089
小板16A一位开关带德式插座
1 gang German socket
¥:68.00

AB-K4-0090
小板16A一位开关带法式插座
1 gang French socket
¥:68.00

AB-K4-0091
小板16A德式插座带防水
German socket and Waterproof belt
¥:75.00

AB-K4-0092
小板16A法式插座带防水
French socket and Waterproof belt
¥:75.00

AB-K4-0093
小板二位USB带13A方角插座（横）
2 USB with 13A square corner socket with swith
¥:170.00

AB-K4-0094
小板15A美标插座+USB+type-c
American Standard + USB / type-C
¥:170.00

AB-K4-0095
小板15A泰式插座+USB+type-c
15A Thai + USB / type-C
¥:170.00

AB-K4-0096
小板二位USB带13A方角插座
（带保护门）
2 USB with 13A square corner socket with flip cover
¥:170.00

AB-K4-0097
小板二位USB带13A多功能插座
（带保护门）
2 USB with 3 pin multi-purpose socket with flip cover
¥:170.00

AB-K4-0098
小板一位开关带二位USB带13A多功能插座（带指示灯）
1 gang switch with two USB and 13A multi-function socket
¥:175.00

AB-K4-0099
小板一位开关带二位USB带13A方角插座（带指示灯）
2 USB with 13A aquare comer socket with flip cover
¥:175.00

AB-K4-0100
小板13A多功能插座带USB+type-c
13A multi-function with type-C + USB
¥:170.00

AB-K4-0101
小板13A方角插座带USB+type-c
13A square angle band type-C + USB
¥:170.00

AB-K4-0102
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with Type-c+USB(with light)
¥:175.00

AB-K4-0103
小板二位USB带13A多功能插座带小开关（竖）
2 USB with Three very multi-purpose socket with switch
¥:175.00

AB-K4-0104
小板一位开关13A方插带Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:175.00

AB-K4-0105
小板二位USB带13A方角插座带小开关（竖）
2 USB with 13A square corner socket with switch
¥:175.00

AB-K4-0106
小板15A美式插座带二位USB
American Standard + 2USB
¥:170.00

AB-K4-0107
小板15A泰式插座带双USB
15A Thai + 2USB
¥:170.00

AB-K4-0108
小板13A多功能插座带二位USB（横）
13A multi-function socket belt with two-bit USB(horizontal)
¥:183.00

AB-K4-0109
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:163.00

AB-K4-0110
小板二位USB带10A二三极插座带开关
2 USB and 5 pin socket with switch
¥:173.00

AB-K4-0111
小板10五孔插座带USB +Type-C (10W)
10A 5 pole socket with USB type-C (10W)
¥:170.00
小板10五孔插座带USB +Type-C (18W)
10A 5 pole socket with USB type-C (18W)
¥:235.00

AB-K4-0112
小板一位开关带13A多功能五孔插座带USB
1 gang swich and 5 pin multi-function socket with USB and indicator light
¥:190.00

AB-K4-0113
小板13A二位USB带多功能五孔插座
2 USB with 5 pin multi-function socket
¥:163.00

AB-K4-0114
小板13A二位USB带多功能五孔插座带开关
2 USB with 5 pin multi-function socket with switch
¥:173.00

AB-K4-0115
13A多功能五孔带USB+TYPE-C (10W)
13A MF 5 pin socket USB+type-C (10W)
¥:170.00
13A多功能五孔带USB+TYPE-C (18W)
13A MF 5 pin socket USB+type-C (18W)
¥:235.00

AB-K4-0116
小板一位电视插座
TV socket
¥:65.00

AB-K4-0117
小板一位电话插座 ¥:65.00
telephone socket
小板一位电脑插座 ¥:78.00
computer socket
小板一位电脑插座（超六类）¥:118.00
computer socket(6)

AB-K4-0118
小板双电视插座
Two TV socket
¥:91.00

AB-K4-0119
小板双电话插座 ¥:91.00
Two telephone socket
小板双电脑插座 ¥:121.00
Two computer socket
小板二位电脑插座(超六类) ¥:181.00
Two computer socket(6)
小板电话电脑插座 ¥:101.00
telephone+computer socket
小板电话电脑插座(超六类) ¥:141.00
telephone+computer socket(6)

AB-K4-0120
小板电视电话插座 ¥:91.00
TV + telephone socket
小板电视电脑插座 ¥:101.00
TV + computer socket
小板一位电视电脑插座(超六类) ¥:141.00
TV + computer socket(6)

AB-K4 Baking paint space gray 烤漆太空灰

AB-K4-0121

小板一位电话带USB插座 ¥:243.00
TEL + USB socket
小板一位电脑带USB插座 ¥:243.00
computer + USB socket
小板一位电脑带USB(超六类) ¥:293.00
computer + USB socket(6)

AB-K4-0122

小板一位TV+FM
TV and FM
¥:150.00

AB-K4-0123

小板一位卫星插座
Satellite socket
¥:78.00

AB-K4-0124

小板二位卫星插座
Double satellite socket
¥:121.00

AB-K4-0125

小板卫星+电视插座
Satellite and TV socket
¥:101.00

AB-K4-0126

小板卫星带电话插座 ¥:101.00
Satellite and telephone socket
小板卫星带电脑插座 ¥:121.00
Satellite and computer socket
小板卫星带电脑插座（超六类） ¥:161.00
Satellite and computer socket(6)

AB-K4-0127

小板二极插座带电视插座
2 pin socket with TV
¥:243.00

AB-K4-0128

小板二极插座带电话插座 ¥:243.00
2 pin socket with telephone
小板二极插座带电脑插座 ¥:243.00
2 pin socket with computer
小板二极插座带电脑插座(超六类) ¥:293.00
2 pin socket with computer

AB-K4-0129

小板一位光纤插座
Optical fiber socket
¥:140.00

AB-K4-0130

小板二位USB插座
Double USB socket
¥:203.00

AB-K4-0131

小板单联音响插座
Single audio socket
¥:133.00

AB-K4-0132

小板双联音响插座
Double audio socket
¥:183.00

AB-K4-0133

触摸延时开关（节能）
Touch delay delay switch
(energy saving)
¥:113.00

AB-K4-0134

声光控延时开关（节能）
Sound-light controlled delay switch
(energy saving)
¥:113.00

AB-K4-0135

红外线人体感应开关
Human body induction
¥:248.00

AB-K4-0136

凹型地脚灯（亮光/暖光）
The footlights
¥:153.00

AB-K4-0137

凹型红外线人体感应地脚灯
（亮光/暖光）
The human body induction footlights
¥:268.00

AB-K4-0138

平面地脚灯（亮光/暖光）
Footlights
¥:153.00

AB-K4-0139

叮咚门铃
Ding dong doorbell
¥:175.00

AB-K4-0140

机械式40A插卡取电 ¥:230.00
Mechanical card for electricity
感应式低频40A插卡取电 ¥:350.00
Low frequency induction card
for electricity
感应式高频40A插卡取电 ¥:400.00
High frequency induction card
for electricity

AB-K4-0141

紧急呼叫开关
Emergency call switch
¥:163.00

AB-K4-0142

请勿打扰请即清理门铃开关
(按键式)
Do not disturb please namely cleaning
please + late doorbell "button"
¥:171.00

AB-K4-0143

请勿打扰门铃开关（按键式）
Do not disturb + doorbell "button"
¥:323.00

AB-K4-0144

请勿打扰请即清理门铃开关
（按键式）
Do not disturb please namely cleaning
please "button"
¥:323.00

AB-K4-0145

智能音乐控制开关
Intelligent music control switch
¥:2700.00

AB-K4-0146

温度控制调节开关
Temperature control switch
¥:683.00

AB-K4-0147

温度控制调节开关
Temperature control switch
¥:780.00

AB-K4-0148

调音开关
Tuning switch（fire）
¥:160.00

AB-K4-0149

调光开关300W ¥:133.00
Dimming 300W
调光开关600W ¥:173.00
Dimming 600W
调光开关1000W ¥:213.00
Dimming 1000W

AB-K4-0150

调速开关300W ¥:133.00
Speed 300W
调速开关600W ¥:173.00
Speed 600W
调速开关1000W ¥:213.00
Speed 1000W

AB-K4-0151

一位开关带调光开关500W
1 gang with dimmer switch
¥:165.00

AB-K4-0152

一位开关带调速开关500W
1 gang with speed switch
¥:165.00

AB-K4-0153

13A开关带保险丝（带指示灯）
13A switch with fuse(with neon)
¥:163.00

AB-K4-0154

20A出线柱
20A outgoing post
¥:153.00

AB-K4-0155

剃须插座
Shaving socket
¥:390.00

AB-K4-0156

USB+电脑插座+无线路由
USB + computer socket,wireless router
¥:650.00

AB-K4-0157

蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio + 3.5
+ 2USB + HDMI
¥:5203.00

AB-K4-0158

HDMI
¥:243.00

AB-K4-0159

Type-c+USB(小板)
¥:283.00

AB-K4-0160

HDMI+USB
¥:243.00

AB-K4-0161

HDMI+USB+3.5音频
HDMI+USB+3.5
¥:243.00

AB-K4-0162

VGA+USB+3.5音频
VGA+USB +3.5
¥:243.00

AB-K4-0163

AV+3.5音频
AV +3.5
¥:243.00

AB-K4-0164

VGA+AV音频接口
VGA + AV audio interface
¥:243.00

AB-K4-0165

HDMI+AV音频接口
HDMI + AV audio interface
¥:243.00

AB-K4-0166

二分之一AV音频+卫星
Half AV audio interface+Satellite socket
¥:243.00.

AB-K4-0167

二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:243.00

AB-K4-0168

二分之一VGA+TV
Half VGA+TV
¥:243.00

AB-K4-0169

二分之一VGA+电脑插座
Half VGA+computer socket
¥:243.00

AB-K4-0170

VGA+USB
¥:243.00

AB-K4-0171

VGA+HDMI
¥:243.00

AB-K4-0172

45A出线柱
45A Outlet
¥:163.00

AB-K4-0173

空白面板
Blank plate
¥:37.00

AB-K4-0174

147大板二位双极开关带二位13A方角
插座（带指示灯）
Two bipolar switch with two 13A square
angle socket (with light)
¥:138.00

AB-K4-0175

147大板二位开关带二位16A多功能
插座（带指示灯）
147 Tow switch and double 16A MF
socket with light
¥:138.00

AB-K4-0176

147 二位开关带二位13A方角插座
带二位USB（带指示灯）
147 Two switch and double 13A
square corner socket with two USB
¥:238.00

AB-K4-0177

147大板二位开关带二位16A多功
能插座+2USB（带指示灯）
147 Two switch and double 16A
MF 3 pin socket with 2USB
¥:238.00

AB-K4-0178

147二位开关二位13A方插带灯
+USB/Type-c（大板）
147 Two switch and double 13A
square corner socket with USB/
Type-c
¥:268.00

AB-K4-0179

147二位开关二位13A多功能带灯
+USB/Type-c（大板）
147 Two switch and double 3 pin
MF socket with neon Type-c+USB
¥:268.00

AB-K4-0180

147型45A双极开关+一开
13A方角插带灯(炉具开关)
147 type 45A bipolar switch
+ 13A square angle plug With
light (stove switch)
¥:230.00

AB-K4 Baking paint space gray 烤漆太空灰

AB-K4-0181

147型45A双极开关带指示灯
147 type 45A bipolar switch with indicator light
¥:183.00

AB-K4-0182

147型空白面板
147 blank panel
¥:68.00

AB-K4-0183

小板147型16A二位开关单控
147 2 gang 1 way switch
¥:96.00
小板147型16A二位开关双控
147 2 gang 2 way switch
¥:104.00

AB-K4-0184

小板147型16A三位开关单控
147 3 gang 1 way switch
¥:110.00
小板147型16A三位开关双控
147 3 gang 2 way switch
¥:120.00

AB-K4-0185

小板147型16A四位开关单控
147 4 gang 1 way switch
¥:124.00
小板147型16A四位开关双控
147 4 gang 2 way switch
¥:136.00

AB-K4-0186

小板147型16A五位开关单控
147 5 gang 1 way switch
¥:137.00
小板147型16A五位开关双控
147 5 gang 2 way switch
¥:152.00

AB-K4-0187

小板147型16A六位开关单控
147 6 gang 1 way switch
¥:150.00
小板147型16A六位开关双控
147 6 gang 2 way switch
¥:168.00

AB-K4-0188

小板147型16A七位开关单控
147 7 gang 1 way switch
¥:163.00
小板147型16A七位开关双控
147 7 gang 2 way switch
¥:184.00

AB-K4-0189

小板147型16A八位开关单控
147 8 gang 1 way switch
¥:176.00
小板147型16A八位开关双控
147 8 gang 2 way switch
¥:200.00

AB-K4-0190

147 二位16A多功能三极插座
147 Double 16A MF socket
¥:123.00



AB-K4-0191

147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:138.00



AB-K4-0192

小板147型二位15A美标扁插座
Type 147 Double 15A US flat socket
¥:130.00

AB-K4-0193

小板147型二位15A泰式三极插座
147 Double 15A triode flat Ammerican standard socket
¥:130.00



AB-K4-0194

小板147型二位13A方角插座
Double 13A square comer socket
¥:122.00



AB-K4-0195

小板147型二位15A圆角插座
type 147 Double 15A round socket
¥:130.00



AB-K4-0196

小板147型13A错位二位多功能五孔插座
Type 147 Double 13A multi functional 5 pin socket
¥:170.00

AB-K4-0197

小板147型10A二位二三极插座
Type 147 Double 10A 5 pin socket
¥:98.00

AB-K4-0198

147 二位开关带二位13A方角插座
147 Tow switch and double 13A square corner socket
¥:168.00

AB-K4-0199

147 二位开关带二位13A多功能插座
147 Tow switch and double 13A MF 3 pin socket
¥:168.00

AB-K4-0200

147二位开关带二位多功能五孔
147 two switch with double MF 5 pin
¥:186.00

AB-K4-0201

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 13A square comer socket with indicator light
¥:138.00

AB-K4-0202

147 二位开关带二位13A多功能插座（带指示灯）
147 Tow switch and double 13A MF socket with light
¥:138.00

AB-K4-0203

147二位开关二位13A方插+二位USB（小板）
147 Tow switch and double 13A square corner socket + 2USB
¥:238.00

AB-K4-0204

147二位开关二位13A多功能+二位USB（小板）
147 Tow switch and double 13A MF socket+2USB
¥:238.00

AB-K4-0205

小板147二位开关二位13A方插+USB/Type-c（小板）
147 two switch and double 13A square band lamp+USB/Type-c
¥:268.00

AB-K4-0206

小板147二位开关二位13A多功能+USB/Type-c（小板）
147 two switch and double 13A MF band lamp +USB/Type-c
¥:268.00



AB-K4-0207

147 二位开关带二位15A圆角插座（带指示灯）
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:156.00



AB-K4-0208

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 15A square corner socket with indicator light
¥:146.00

AB-K4-0209

147 四孔剃须插座
147 two shaving socket
¥:563.00

AB-K4-0210

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 Kitchen switch
¥:260.00

AB-K4-0211

147 45A开关+一位开关13A方角插带指示灯(组合厨房开关)
147 Kitchen switch
¥:260.00

AB-K4-0212

147 45A开关+一位开关13A方插带灯（厨房开关）
147 Kitchen switch
¥:260.00

AB-K4-0213

147 45A双极开关带指示灯
147 type 45A bipolar switch
¥:183.00

AB-K4-0214

147 16A二位德式插座
147 Double Geman socket
¥:148.00

AB-K4-0215

147 16A二位法式插座
147 Double French socket
¥:148.00

AB-K4-0216

小板147型二位16A德标插座
147 Double Geman socket
¥:148.00

AB-K4-0217

小板147型二位16A法标插座
147 Double French socket
¥:148.00

AB-K4-0218

小板147型二位16A德式插座+USB/Type-c(小板）
147 Double 16A French + USB / type-c
¥:340.00

AB-K4-0219

小板147型二位16A法式插座+USB/Type-c(小板）
147 Double 16A German + USB / type-c
¥:340.00

AB-K4-0220

147型二位16A德式+2USB（小板连体）
147 Double 16A German Band socket +2USB
¥:280.00

AB-K4-0221

147二位16A法式+2USB（小板连体）
147 Double 16A German standard socket with 2USB
¥:280.00

AB-K4-0222

小板147型四位USB插座
147 4 USB socket
¥:350. 00

AB-K4-0223

147 二位多功能插座+4USB
147 2-bit multi-function socket + 4USB
¥:350.00

AB-K4-0224

147 二位13A方角插座+4USB
147 two bit 13A square socket +4USB
¥:350.00



AB-K4-0225

147 一位13A方角插座+二位USB
13A square comer socket and two USB
¥:271.00

AB-K4-0226

147型16A多功能三孔带二位USB插座
147 16A 3 pin MF socket and 2USB socket
¥:271.00

AB-K4-0227

147型二位开关带二位多功能五孔插座带双USB
147 Tow switch and double 13A 5 pin multi-purpose socket+2USB
¥:330.00

AB-K4-0228

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two switch and double 13A MF 5-pin socket + 2USB (with indicator)
¥:350.00

AB-K4-0229

147 二位13A多功能五孔插座+四位USB
147 13A double 5 pin multi function socket+4USB
¥:330.00

AB-K4-0230

小板147型二位13A多功能五孔带四位USB带小开关/指示灯
147 type double 13A multi-functional five-hole With 4USB with small switch/indicator light
¥:350.00

AB-K4-0231

小板147型二位开关带多功能五孔+USB/type-c
147 two switch with multi-function five-hole + USB/type-c
¥:350.00

AB-K4-0232

小板147型二开13A二位多功能带指示灯/4USB
147 type two switch 13A Double multi-function with indicator light /4USB
¥:350.00

AB-K4-0233

147型二开二位13A方角插座带指示灯/4USB
147 type two open two position 13A square corner socket with indicator light / 4USB
¥:350.00

AB-K4-0234

小板147二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A German socket+USB/Type-c w/neon
¥:330.00

AB-K4-0235

小板147型二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A French socket+USB/Type-c w/neon
¥:330.00

AB-K4-0236

小板147型二位开关二位16A德式插座（带指示灯）
147 two switch double 16A German socket w/neon
¥:190.00

AB-K4-0237

小板147型二位开关二位16A法式插座（带指示灯）
147 two switch double 16A French socket w/neon
¥:190.00

AB-K4-0238

小板147型二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket with neon + 2USB
¥:320.00

AB-K4-0239

小板147型二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch double 16A French socket w/neon+2USB
¥:320.00

AB-K4-0240

小板147型空白面板
147 Blank plate
¥:78.00

AB-K4 Baking paint space gray 烤漆太空灰

AB-K4-0181

147型45A双极开关带指示灯
147 type 45A bipolar switch with indicator light
¥:183.00



AB-K4-0191

147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:138.00

AB-K4-0201

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 13A square comer socket with indicator light
¥:138.00

AB-K4-0182

147型空白面板
147 blank panel
¥:68.00



AB-K4-0192

小板147型二位15A美标扁插座
Type 147 Double 15A US flat socket
¥:130.00

AB-K4-0202

147 二位开关带二位13A多功能插座（带指示灯）
147 Tow switch and double 13A MF socket with light
¥:138.00

AB-K4-0183

小板147型16A二位开关单控
147 2 gang 1 way switch
¥:96.00
小板147型16A二位开关双控
147 2 gang 2 way switch
¥:104.00

AB-K4-0193

小板147型二位15A泰式三极插座
147 Double 15A triode flat Ammerican standard socket
¥:130.00

AB-K4-0203

147二位开关二位13A方插+二位USB（小板）
147 Tow switch and double 13A square comer socket + 2USB
¥:238.00

AB-K4-0184

小板147型16A三位开关单控
147 3 gang 1 way switch
¥:110.00
小板147型16A三位开关双控
147 3 gang 2 way switch
¥:120.00



AB-K4-0194

小板147型二位13A方角插座
Double 13A square comer socket
¥:122.00

AB-K4-0204

147二位开关二位13A多功能+二位USB（小板）
147 Tow switch and double 13A MF socket+2USB
¥:238.00

AB-K4-0185

小板147型16A四位开关单控
147 4 gang 1 way switch
¥:124.00
小板147型16A四位开关双控
147 4 gang 2 way switch
¥:136.00



AB-K4-0195

小板147型二位15A圆角插座
type 147 Double 15A round socket
¥:130.00

AB-K4-0205

小板147二位开关二位13A方插+USB/Type-c（小板）
147 two switch and double 13A square band lamp+USB/Type-c
¥:268.00

AB-K4-0186

小板147型16A五位开关单控
147 5 gang 1 way switch
¥:137.00
小板147型16A五位开关双控
147 5 gang 2 way switch
¥:152.00



AB-K4-0196

小板147型13A错位二位多功能五孔插座
Type 147 Double 13A multi functional 5 pin socket
¥:170.00

AB-K4-0206

小板147二位开关二位13A多功能+USB/Type-c（小板）
147 two switch and double 13A MF band lamp +USB/Type-c
¥:268.00

AB-K4-0187

小板147型16A六位开关单控
147 6 gang 1 way switch
¥:150.00
小板147型16A六位开关双控
147 6 gang 2 way switch
¥:168.00



AB-K4-0197

小板147型10A二位二三极插座
Type 147 Double 10A 5 pin socket
¥:98.00



AB-K4-0207

147 二位开关带二位15A圆角插座（带指示灯）
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:156.00

AB-K4-0188

小板147型16A七位开关单控
147 7 gang 1 way switch
¥:163.00
小板147型16A七位开关双控
147 7 gang 2 way switch
¥:184.00

AB-K4-0198

147 二位开关带二位13A方角插座
147 Tow switch and double 13A square comer socket
¥:168.00

AB-K4-0208

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 15A square comer socket with indicator light
¥:146.00

AB-K4-0189

小板147型16A八位开关单控
147 8 gang 1 way switch
¥:176.00
小板147型16A八位开关双控
147 8 gang 2 way switch
¥:200.00

AB-K4-0199

147 二位开关带二位13A多功能插座
147 Tow switch and double 13A MF 3 pin socket
¥:168.00

AB-K4-0209

147 四孔剃须插座
147 two shaving socket
¥:563.00

AB-K4-0190

147 二位16A多功能三极插座
147 Double 16A MF socket
¥:123.00

AB-K4-0200

147二位开关带二位多功能五孔
147 two switch with double MF 5 pin
¥:186.00

AB-K4-0210

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 Kitchen switch
¥:260.00

AB-K4-0211

147 45A开关+一位开关13A方角插带指示灯(组合厨房开关)
147 Kitchen switch
¥:260.00

AB-K4-0221

147二位16A法式+2USB（小板连体）
147 Double 16A German standard socket with 2USB
¥:280.00

AB-K4-0231

小板147型二位开关带多功能五孔+USB/type-c
147 two switch with multi-function five-hole + USB/type-c
¥:350.00

AB-K4-0212

147 45A开关+一位开关13A方插带灯（厨房开关）
147 Kitchen switch
¥:260.00

AB-K4-0222

小板147型四位USB插座
147 4 USB socket
¥:350. 00

AB-K4-0232

小板147型二开13A二位多功能带指示灯/4USB
147 type two switch 13A Double multi-function with indicator light /4USB
¥:350.00

AB-K4-0213

147 45A双极开关带指示灯
147 type 45A bipolar switch
¥:183.00

AB-K4-0223

147 二位多功能插座+4USB
147 2-bit multi-function socket + 4USB
¥:350.00

AB-K4-0233

147型二开二位13A方角插座带指示灯/4USB
147 type two open two position 13A square comer socket with indicator light / 4USB
¥:350.00

AB-K4-0214

147 16A二位德式插座
147 Double Geman socket
¥:148.00

AB-K4-0224

147 二位13A方角插座+4USB
147 two bit 13A square socket +4USB
¥:350.00

AB-K4-0234

小板147二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A German socket+USB/Type-c w/neon
¥:330.00

AB-K4-0215

147 16A二位法式插座
147 Double French socket
¥:148.00

AB-K4-0225

147 一位13A方角插座+二位USB
13A square comer socket and two USB
¥:271.00

AB-K4-0235

小板147型二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A French socket+USB/Type-c w/neon
¥:330.00

AB-K4-0216

小板147型二位16A德标插座
147 Double Geman socket
¥:148.00

AB-K4-0226

147型16A多功能三孔带二位USB插座
147 16A 3 pin MF socket and 2USB socket
¥:271.00

AB-K4-0236

小板147型二位开关二位16A德式插座（带指示灯）
147 two switch double 16A German socket w/neon
¥:190.00

AB-K4-0217

小板147型二位16A法标插座
147 Double French socket
¥:148.00

AB-K4-0227

147型二位开关带二位多功能五孔插座带双USB
147 Tow switch and double 13A 5 pin multi-purpose socket+2USB
¥:330.00

AB-K4-0237

小板147型二位开关二位16A法式插座（带指示灯）
147 two switch double 16A French socket w/neon
¥:190.00

AB-K4-0218

小板147型二位16A德式插座+USB/Type-c(小板）
147 Double 16A French + USB / type-c
¥:340.00

AB-K4-0228

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two switch and double 13A MF 5-pin socket + 2USB (with indicator)
¥:350.00

AB-K4-0238

小板147型二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket with neon + 2USB
¥:320.00

AB-K4-0219

小板147型二位16A法式插座+USB/Type-c(小板）
147 Double 16A German + USB / type-c
¥:340.00

AB-K4-0229

147 二位13A多功能五孔插座+四位USB
147 13A double 5 pin multi function socket+4USB
¥:330.00

AB-K4-0239

小板147型二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch double 16A French socket w/neon+2USB
¥:320.00

AB-K4-0220

147型二位16A德式+2USB（小板连体）
147 Double 16A German Band socket +2USB
¥:280.00

AB-K4-0230

小板147型二位13A多功能五孔带四位USB带小开关/指示灯
147 type double 13A multi-functional five-hole With 4USB with small switch/indicator light
¥:350.00

AB-K4-0240

小板147型空白面板
147 Blank plate
¥:78.00

AB-L 不锈钢(金色)
Stainless steel (gold)

304/不锈钢

金属便条装饰使整体开关更具格调性
成就奢华气度。
线条设计硬朗,突出现代都市元素
内涵科技结晶,呈现脱俗之美

Metal note decoration makes the overall switch more stylish
Achieve luxury.
The line design is tough, highlighting modern urban elements
Connotation of technology crystallization, showing refined beauty

一开后座

五孔后座

Zigbee智能按键开关
Zigbee Intelligent button switch

Zigbee一开
￥950.00

Zigbee二开
￥1050.00

Zigbee三开
￥1150.00

二三极USB/Type-c+开关
￥215.00

语音/APP/轻触机械控制	情景模式/联动/定时	支持多款AL音响	涂鸦无线场景开关(单火零火通用)
Voice /APP/ touch mechanical control	Scenario mode/Linkage/timing	Support a variety of AL audio	Doodle wireless scene switch (Single fire and zero fire universal)

外观颜色 / Appearance Color

香槟金 Champagne gold
太空灰 Space gray
摩卡黑 Mocha Black
咖啡棕 Coffee Brown

模块颜色 / Module Color

香槟金 Champagne gold
太空灰 Space gray
摩卡黑 Mocha Black

147组合演示 /147 Combination demo:



86型功能键 Type 86 function key
填空键 Blank key
86型功能键 Type 86 function key

联体面框 / Conjoined face frame

二位联体面框
Two-position face frame
塑板/钢板:50.00
Plastic board/Steel plate:50.00

四位联体面框
Four-position face frame
塑板/钢板:90.00
Plastic board/Steel plate:90.00

三位联体面框
Three-position face frame
塑板/钢板:70.00
Plastic board/Steel plate:70.00

五位联体面框
Five-position face frame
塑板/钢板:110.00
Plastic board/Steel plate:110.00

AB-L Stainless steel gold 不锈钢(金色)

AB-L-0001
大板16A一位开关单控 ¥:68.00
Large panel 16A 1 gang 1 way switch
大板16A一位开关双控 ¥:70.00
Large panel 16A 1 gang 2 way switch
大板16A一位开关多控 ¥:108.00
Large panel 16A 1 gang more way switch

AB-L-0002
大板16A二位开关单控 ¥:86.00
Large panel 16A 2 gang 1 way switch
大板16A二位开关双控 ¥:91.00
Large panel 16A 2 gang 2 way switch
大板16A二位开关多控 ¥:144.00
Large panel 16A 2 gang more way switch

AB-L-0003
大板16A三位开关单控 ¥:104.00
Large panel 16A 3 gang 1 way switch
大板16A三位开关双控 ¥:112.00
Large panel 16A 3 gang 2 way switch

AB-L-0004
大板16A四位开关单控 ¥:122.00
Large panel 16A 4 gang 1 way switch
大板16A四位开关双控 ¥:132.00
Large panel 16A 4 gang 2 way switch

AB-L-0005
大板16A百叶窗升降开关
Large panel louver window lifter switch
¥:126.00

AB-L-0006
大板16A门控开关
Large panel gating switch
¥:86.00

AB-L-0007
大板16A英式门控开关
Large panel British gating switch
¥:86.00

AB-L-0008
大板16A门铃开关
Large panel doorbell switch
¥:86.00

AB-L-0009
大板20A双极开关带指示灯 ¥:133.00
Board 20A bipolar switch with indicator light
大板32A双极开关带指示灯 ¥:142.00
Board 32A bipolar switch with indicator light

AB-L-0010
大板45A双极开关带指示灯
Board 45A bipolar switch with indicator light
¥:160.00

AB-L-0011
大板16A三极插座
16A 3 pole socket
¥:70.00

AB-L-0012
大板16A多功能插座
16A 3 pin universal socket
¥:77.00

AB-L-0013
大板10A二三极插座
10A 5 pole socket
¥:68.00

AB-L-0014
大板10A错位二三极插座
10A Two or three pole socket
¥:79.00

AB-L-0015
大板16A多功能五孔插座
5 pin multi-function socket
¥:77.00

AB-L-0016
大板10A二二三极插座
10A 7 pole socket
¥:84.00

AB-L-0017
大板13A方角插座
13A square corner socket
¥:73.00

AB-L-0018
大板二位USB带16A多功能五孔插座
2 USB with 5 pin multi-function socket
¥:167.00

AB-L-0019
大板16A一位开关单控带16A三极插座
1gang 1 way switch and 16A 3 pole socket
¥:88.00
大板16A一位开关双控带16A三极插座
1gang 2 way switch and 16A 3 pole socket
¥:91.00

AB-L-0020
大板16A一位开关单控带10A二三极插座
1 gang 1 way switch and 5 pole socket
¥:88.00
大板16A一位开关双控带10A二三极插座
1 gang 2 way switch and 5 pole socket
¥:91.00

AB-L-0021
大板10A二位开关单控带二三极插座
2 gang 1 way switch and 5 pole socket
大板10A二位开关双控带二三极插座
2 gang 2 way switch and 5 pole socket
¥:108.00

AB-L-0022
大板一位开关带16A三极多功能插座(带指示灯)
1 gang switch and 16A 3 pin multi-purpose socket with indicator light
¥:97.00

AB-L-0023
大板一位双极开关带13A方角插座(指示灯)
1 gang switch and 13A square pin socket with indicator light
¥:97.00

AB-L-0024
大板一位开关带15A圆角插座(指示灯)
Large board one position switch with 15A round socket (indicator light)
¥:104.00

AB-L-0025
大板一位开关带16A二三极多功能插座(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
¥:115.00

AB-L-0026
大板16A德式插座
Large board 16A German socket
¥:86.00

AB-L-0027
大板16A法式插座
Large plate 16A French socket
¥:86.00

AB-L-0028
大板16A俄式插座
Large board 16A Russian socket
¥:86.00

AB-L-0029
大板16A德标插座带二位USB
German socket+2 USB
¥:185.00

AB-L-0030
大板16A法标插座带二位USB
French socket + 2 USB
¥:185.00

AB-L-0031
大板16A德标插座+USB/type-c
Large board 16A German socket + USB / type-C
¥:185.00

AB-L-0032
大板16A法式插座+USB/Type-c
Large board 16A French socket + USB / type-C
¥:185.00

AB-L-0033
大板一位电视插座
TV socket
¥:81.00

AB-L-0034
大板一位电话插座 ¥:81.00
telephone socket
大板一位电脑插座 ¥:99.00
computer socket
大板一位电脑插座(超六类) ¥:144.00
computer socket(6)

AB-L-0035
大板一位电视电话插座 ¥:108.00
TV + telephone socket
大板一位电视电脑插座 ¥:117.00
TV + computer socket
大板一位电视电脑插座(超六类) ¥:153.00
TV + computer socket(6)

AB-L-0036
大板二位电视插座
Two TV socket
¥:108.00

AB-L-0037
大板二位电话插座 ¥:108.00
Two TV socket
大板二位电脑插座 ¥:135.00
Two computer socket
大板二位电脑插座(超六类) ¥:207.00
Two computer socket(6)
大板电话+电脑插座 ¥:117.00
telephone+computer socket
大板电话+电脑插座(超六类) ¥:153.00
telephone+computer socket(6)

AB-L-0038
大板空白面板
Large plate Blank plate
¥:51.00

AB-L-0039
小板16A一位开关单控 ¥:75.00
16A 1 gang 1 way switch
小板16A一位开关双控 ¥:78.00
16A 1 gang 2 way switch
小板16A一位开关多控 ¥:120.00
16A 1 gang more way switch

AB-L-0040
小板16A二位开关单控 ¥:95.00
16A 2 gang 1 way switch
小板16A二位开关双控 ¥:101.00
16A 2 gang 2 way switch
小板16A二位开关多控 ¥:160.00
16A 2 gang more way switch

AB-L-0041
小板16A三位开关单控 ¥:115.00
16A 3 gang 1 way switch
小板16A三位开关双控 ¥:124.00
16A 3 gang 2 way switch

AB-L-0042
小板16A四位开关单控 ¥:135.00
16A 4 gang 1 way switch
小板16A四位开关双控 ¥:147.00
16A 4 gang 2 way switch

AB-L-0043
小板16A三位开关多控
16A 3 gang 3 way switch
¥:180.00

AB-L-0044
小板16A百叶窗升降开关
louver window lifter switch
¥:140.00

AB-L-0045
小板16A门控开关
gating switch
¥:95.00

AB-L-0046
小板16A英式门控开关
British gating switch
¥:95.00

AB-L-0047
小板16A门铃开关
doorbell switch
¥:95.00

AB-L-0048
小板16A拨动一位开关单控
1 gang 1 way toggle switch
¥:138.00
小板16A拨动一位开关双控
1 gang 2 way toggle switch
¥:148.00

AB-L-0049
小板16A拨动二位开关单控
2 gang 1 way toggle switch
¥:158.00
小板16A拨动二位开关双控
2 gang 2 way toggle switch
¥:170.00

AB-L-0050
小板16A拨动三位开关单控
3 gang 1 way toggle switch
¥:178.00
小板16A拨动三位开关双控
3 gang 2 way toggle switch
¥:196.00

AB-L-0051
小板16A拨动四位开关单控
4 gang 1 way toggle switch
¥:198.00
小板16A拨动四位开关双控
4 gang 2 way toggle switch
¥:222.00

AB-L-0052
小板20A双极开关带指示灯
20A swich with indicator light
¥:148.00
小板45A双极开关带指示灯
45A swich with indicator light
¥:178.00

AB-L-0053
小板45A双极开关带指示灯
45A swich with indicator light
¥:168.00

AB-L-0054
小板16A卷帘门复位开关
Shutter reset switch
¥:170.00

AB-L-0055
小板16A德式插座
German socket
¥:95.00

AB-L-0056
小板16A法式插座
French socket
¥:95.00

AB-L-0057
小板16A俄式插座
Russian socket
¥:95.00

AB-L-0058
小板16A以色列插座
Israel socket
¥:105.00

AB-L-0059
小板16A意大利+德式插座
Italy+German socket
¥:105.00

AB-L-0060
小板10A二极插座
10A 2 pole socket
¥:75.00

AB-L Stainless steel gold 不锈钢(金色)

AB-L-0061
小板10A二二极插座
10A Double 2 pole socket
¥:83.00

AB-L-0062
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:85.00

AB-L-0063
小板10A一位开关带二二极座
1gang switch and 4 pole socket
¥:95.00

AB-L-0064
小板16A多功能三极插座
16A 3 pin multi-function socket
¥:78.00

AB-L-0065
小板13A二三极多功能插座
5 pin multi-function socket
¥:85.00

AB-L-0066
小板13A错位多功能二三极插座
Dislocation multi 5 pin multi-function socket
¥:95.00

AB-L-0067
小板13A方角插座
13A square corner socket
¥:81.00

AB-L-0068
小板15A圆角插座
15A 3 round pins socket
¥:85.00

AB-L-0069
小板15A美标扁三极插座
15A triode flat American standard socket
¥:85.00

AB-L-0070
小板15A泰式插座
15A Thai socket
¥:85.00

AB-L-0071
小板错位泰式六孔插座
Dislocation Thai 6 pin socket
¥:95.00

AB-L-0072
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:108.00

AB-L-0073
小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pin socket
¥:115.00

AB-L-0074
小板一位开关带16A多功能插座
1 gang switch and 3 pin MF socket
¥:115.00

AB-L-0075
小板一位开关带13A方角插座（带指示灯）
1 gang switch and 13A square pin socket with indicator light
¥:108.00

AB-L-0076
小板一位开关带15A圆孔插座（带指示灯）
1 gang switch and 15A 3 round pins socket with indicator light
¥:115.00

AB-L-0077
小板一位开关带16A多功能插座（带指示灯）
1 gang switch and 16A 3 pin MF socket with light
¥:115.00

AB-L-0078
小板一位开关带13A多功能五孔插座（带指示灯）
1 gang switch and 5 pin multi-function socket with indicator light
¥:128.00

AB-L-0079
小板16A德式插座带二位USB
2 USB with German socket
¥:205.00

AB-L-0080
小板16A法式插座带二位USB
2 USB with French socket
¥:205.00

AB-L-0081
小板16A德式插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:205.00

AB-L-0082
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:205.00

AB-L-0083
小板16A一位开关带德式插座
1 gang German socket
¥:110.00

AB-L-0084
小板16A一位开关带法式插座
1 gang French socket
¥:110.00

AB-L-0085
小板16A德式插座带防水
German socket and Waterproof belt
¥:105.00

AB-L-0086
小板16A法式插座带防水
French socket and Waterproof belt
¥:105.00

AB-L-0087
小板二位USB带13A方角插座（横）
2 USB with 13A square corner socket with swich
¥:205.00

AB-L-0088
小板美标+USB/Type-c
American Standard + USB / type-c
¥:205.00

AB-L-0089
小板15A泰式+USB/type-c
15A Thai+ USB / type-c
¥:205.00

AB-L-0090
小板二位USB带13A方角插座（带保护门）
2 USB with 13A square corner socket with flip cover
¥:225.00

AB-L-0091
小板二位USB带13A多功能插座（带保护门）
2 USB with 3 pin multi-purpose socket with flip cover
¥:225.00

AB-L-0092
小板一位开关带二位USB带13A多功能插座（带指示灯）
1 gang switch with two USB and 13A multi-function socket
¥:215.00

AB-L-0093
小板一位开关带二位USB带13A方角插座（带指示灯）
2 USB with 13A a quare comer socket with flip cover
¥:215.00

AB-L-0094
小板13A多功能带Type-c+USB
13A multifunction with type-C + USB
¥:205.00

AB-L-0095
小板13A方角插带Type-c+USB
13A square angle band type-C + USB
¥:205.00

AB-L-0096
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with Type-c+USB(with light)
¥:215.00

AB-L-0097
小板二位USB带13A多功能插座带小开关（竖）
2 USB with Three very multi-purpose socket with switch
¥:195.00

AB-L-0098
小板一位开关13A方插带Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:215.00

AB-L-0099
小板二位USB带13A方角插座带小开关（竖）
2 USB with 13A square corner socket with switch
¥:195.00

AB-L-0100
小板美标+2USB
American Standard + 2USB
¥:185.00

AB-L-0101
小板15A泰式+2USB
15A Thai + 2USB
¥:185.00

AB-L-0102
小板二位USB带13A多功能插座（横）
2 USB with 3 pin multi-purpose socket
¥:205.00

AB-L-0103
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:185.00

AB-L-0104
小板二位USB带10A二三极插座带开关
2 USB and 5 pin socket with switch
¥:195.00

AB-L-0105
小板10五孔插座带USB +Type-c 2.1A
10A 5 pole socket with USB type-C 2.1A
¥:205.00
小板10五孔插座带USB +Type-c 4A
10A 5 pole socket with USB type-c 4A
¥:310.00

AB-L-0106
小板一位开关带13A多功能五孔插座带USB
1 gang switch and 5 pin multi-function socket with USB and indicator light
¥:240.00

AB-L-0107
小板13A二位USB带多功能五孔插座
2 USB with 5 pin multi-function socket
¥:185.00

AB-L-0108
小板13A二位USB带多功能五孔插座带开关
2 USB with 5 pin multi-function socket with switch
¥:195.00

AB-L-0109
小板13A多功能五孔带USB+TYPE-C 2.1A
13A MF 5 pin socket USB+type-C 2.1A
¥:205.00
小板13A多功能五孔带USB+TYPE-C 4A
13A MF 5 pin socket USB+type-C 4A
¥:310.00

AB-L-0110
小板一位电视插座
TV socket
¥:90.00

AB-L-0111
小板一位电话插座 ¥:90.00
telephone socket
小板一位电脑插座 ¥:110.00
computer socket
小板一位电脑插座(超六类) ¥:150.00
computer socket(6)

AB-L-0112
小板双电视插座
Two TV socket
¥:120.00

AB-L-0113
小板双电话插座 ¥:120.00
Two telephone socket
小板双电脑插座 ¥:150.00
Two computer socket
小板双电脑插座（超六类） ¥:200.00
Two computer socket(6)
小板电话电脑插座 ¥:120.00
telephone+computer socket
小板电话电脑插座（超六类） ¥:170.00
telephone+computer socket(6)

AB-L-0114
小板电视电话插座 ¥:110.00
TV + telephone socket
小板电视电脑插座 ¥:120.00
TV + computer socket
小板一位电视电脑插座(超六类) ¥:170.00
TV + computer socket(6)

AB-L-0115
小板一位电话带USB插座 ¥:270.00
TEL + USB socket
小板一位电脑带USB插座 ¥:270.00
computer + USB socket
小板一位电脑带USB插座(超六类) ¥:320.00
computer + USB socket(6)

AB-L-0116
小板一位TV+FM
TV and FM
¥:190.00

AB-L-0117
小板一位卫星插座
Satellite socket
¥:110.00

AB-L-0118
小板二位卫星插座
Double satellite socket
¥:140.00

AB-L-0119
小板卫星+电视插座
Satellite and TV socket
¥:120.00

AB-L-0120
小板卫星带电话插座 ¥:120.00
Satellite and telephone socket
小板卫星带电脑插座 ¥:140.00
Satellite and computer socket
小板卫星带电脑插座(超六类) ¥:190.00
Satellite and computer socket(6)

AB-L Stainless steel gold series 不锈钢金色系列

AB-L-0121
小板二极插座带电视插座
2 pin socket with TV
¥:270.00

AB-L-0122
小板二极插座带电话插座 ¥:270.00
2 pin socket with telephone
小板二极插座带电脑插座 ¥:270.00
2 pin socket with computer
小板二极插座带电脑(超六类) ¥:320.00
2 pin socket with computer

AB-L-0123
小板一位光纤插座
Optical fiber socket
¥:148.00

AB-L-0124
小板二位USB插座
Double USB socket
¥:225.00

AB-L-0125
小板单联音响插座
Single audio socket
¥:153.00

AB-L-0126
小板双联音响插座
Double audio socket
¥:203.00

AB-L-0127
触摸延时开关（节能）
Touch delay delay switch
¥:133.00

AB-L-0128
声光控延时开关（节能）
Sound-light controlled delay switch
¥:133.00

AB-L-0129
红外线人体感应开关
Human body induction
¥:268.00

AB-L-0130
凹型地脚灯（亮光/暖光）
The footlights
¥:173.00

AB-L-0131
凹型红外线人体感应地脚灯
（亮光/暖光）
The human body induction footlights
¥:288.00

AB-L-0132
平面地脚灯（亮光/暖光）
Footlights
¥:173.00

AB-L-0133
叮咚门铃
Ding dong doorbell
¥:221.00

AB-L-0134
机械式40A插卡取电 ¥:260.00
Mechanical card for electricity
感应式低频40A插卡取电 ¥:380.00
Low frequency induction card for electricity
感应式高频40A插卡取电 ¥:440.00
High frequency induction card for electricity

AB-L-0135
紧急呼叫开关
Emergency call switch
¥:183.00

AB-L-0136
请勿打扰请即清理门铃开关
（按键式）
Do not disturb, please namely cleaning please + later doorbell "button"
¥:191.00

AB-L-0137
请勿打扰门铃开关（按键式）
Do not disturb + doorbell "button"
¥:343.00

AB-L-0138
请勿打扰请即清理门铃开关
（按键式）
Do not disturb plese namely cleaning please "button"
¥:343.00

AB-L-0139
智能音乐控制开关
Intelligent music control switch
¥:2750.00

AB-L-0140
小板温度控制调节器
Temperature control switch
¥:710.00

AB-L-0141
小板温度控制调节器
Temperature control switch
¥:800.00

AB-L-0142
调音开关
Tuning switch（fire）
¥:185.00

AB-L-0143
调光开关300W ¥:155.00
Dimming 300W
调光开关600W ¥:195.00
Dimming 600W
调光开关1000W ¥:235.00
Dimming 1000W

AB-L-0144
调速开关300W ¥:155.00
Speed 300W
调速开关600W ¥:195.00
Speed 600W
调速开关1000W ¥:235.00
Speed 1000W

AB-L-0145
一位开关带调光开关500W
1 gang with dimmer switch
¥:185.00

AB-L-0146
一位开关带调速开关500W
1 gang with speed switch
¥:185.00

AB-L-0147
13A开关带保险丝(带指示灯)
13A switch with fuse(with light)
¥:200.00

AB-L-0148
20A出线柱
20A outgoing post
¥:180.00

AB-L-0149
剃须插座
Shaving socket
¥:450.00

AB-L-0150
USB+电脑插座+无线路由
USB + computer socket,wireless router
¥:750.00

AB-L-0151
蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio + 3.5
+ 2USB + HDMI
¥:5250.00

AB-L-0152
HDMI
¥:270.00

AB-L-0153
USB+TYPE-C
¥:310.00

AB-L-0154
HDMI+USB
¥:270.00

AB-L-0155
HDMI+USB+3.5音频
hemi+USB+3.5
¥:270.00

AB-L-0156
VGA+USB+3.5音频
VGA+USB +3.5
¥:270.00

AB-L-0157
AV+3.5音频
AV +3.5
¥:270.00

AB-L-0158
VGA+AV音频接口
VGA + AV audio interface
¥:270.00

AB-L-0159
HDMI+AV音频接口
HDMI + AV audio interface
¥:270.00

AB-L-0160
二分之一AV音频+卫星
Half AV audio interface+Satellite socket
¥:270.00

AB-L-0161
二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:270.00

AB-L-0162
二分之一VGA+TV
Half VGA+TV
¥:270.00

AB-K1-0163
二分之一VGA+电脑插座
Half VGA+computer socket
¥:270.00

AB-K1-0164
二分之一VGA+USB
Half VGA+USB
¥:270.00

AB-K1-0165
二分之一VGA+HDMI
Half VGA+HDMI
¥:270.00

AB-L-0166
45A出线柱
45A Outlet
¥:200.00

AB-L-0167
空白面板
Blank plate
¥:57.00

AB-L-0168
大板二位双极开关带二位13A方角插座（指示灯）
147 Tow switch and double 13A square comer socket with indicator light
¥:188.00

AB-L-0169
大板二位开关带二位16A多功能插座（带指示灯）
147 Tow switch and double 16A MF socket with light
¥:188.00

AB-L-0170
147 二位开关带二位13A方角插座带二位USB（带指示灯）
147 Tow switch and double 13A square comer socket with two USB and indicator light
¥:288.00

AB-L-0171
大板二位开关带二位16A多功能插座+2USB（带指示灯）
147 Tow switch and double 16A MF socket with 2USB and with light
¥:288.00

AB-L-0172
147型二位开关二位13A方插带灯+USB/Type-c（大板）
147 Tow switch and double 13A square comer socket with USB and indicator light
¥:288.00

AB-L-0173
147二位开关二位13A多功能带灯+USB/Type-c（大板）
147 Tow switch and double 13A MF socket with USB and indicator light
¥:288.00

AB-L-0174
147 二位开关单控 ¥:150.00
147 2 gang 1 way switch
147 二位开关双控 ¥:156.00
147 2 gang 2 way switch

AB-L-0175
147 三位开关单控 ¥:170.00
147 3 gang 1 way switch
147 三位开关双控 ¥:179.00
147 3 gang 2 way switch

AB-L-0176
147型四开单控开关 ¥:190.00
147 4 gang 1 way switch
147型四开双控开关 ¥:202.00
147 4 gang 2 way switch

AB-L-0177
147 五位开关单控 ¥:210.00
147 5 gang 1 way switch
147 五位开关双控 ¥:225.00
147 5 gang 2 way switch

AB-L-0178
147 六位开关单控 ¥:230.00
147 6 gang 1 way switch
147 六位开关双控 ¥:248.00
147 6 gang 2 way switch

AB-L-0179
147 七位开关单控 ¥:250.00
147 7 gang 1 way switch
147 七位开关双控 ¥:271.00
147 7 gang 2 way switch

AB-L-0180
147 八位开关单控 ¥:270.00
147 8 gang 1 way switch
147 八位开关双控 ¥:294.00
147 8 gang 2 way switch

AB-L Stainless steel gold 不锈钢(金色)

AB-L-0181

147 二位16A多功能三极插座
147 Double 16A MF socket
¥:156.00

AB-L-0182

147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:170.00



AB-L-0183

小板147型二位15A美标扁插座
147 Double 15A triode flat Ammerican standard socket
¥:170.00

AB-L-0184

147 二位15A美标三极多功能插座
147 Double 15A triode flat Ammerican standard socket
¥:170.00

AB-L-0185

147 二位13A方角插座
147 Double 13A square comer socket
¥:162.00

AB-L-0186

小板147型二位15A圆角插座
147 Double 15A 3 round pins socket
¥:170.00

AB-L-0187

小板147型二位13A错位多功能二三极插座
147 Double 13A dislocation MF Two three pole socket
¥:190.00

AB-L-0188

147 二位 二三极插座
147 Double position two and three pole socket
¥:152.00

AB-L-0189

147 二位开关带二位13A方角插座
147 Tow switch and double 13A square comer socket
¥:210 .00

AB-L-0190

147 二位开关带二位16A多功能插座
147 Tow switch and double 13A MF 3 pin socket
¥:210.00

AB-L-0191

147二位开关二位13A多功能五孔插座
147 Tow switch and double 13A MF 5 pin socket
¥:260.00

AB-L-0192

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 13A square comer socket with neon
¥:210.00

AB-L-0193

147 二位开关带二位13A多功能插座(带指示灯)
147 Tow switch and double 13A MF socket with light
¥:210.00

AB-L-0194

147二位开关二位13A方插+二位USB（小板）
147 Tow switch and double 13A square comer socket+2USB
¥:280.00

AB-L-0195

147二位开关二位13A多功能+二位USB（小板）
147 Tow switch and double 13A MF socket+2USB
¥:280.00

AB-L-0196

147二位开关二位13A方插+USB/Type-c（小板）
147 two switch double 13A square band lamp+USB/Type-c
¥:280.00

AB-L-0197

147二位开关二位13A多功能+USB/Type-c（小板）
147 two switch double 13A MF 3 pin socket+USB/Type-c
¥:280.00



AB-L-0198

147 二位开关带二位15A圆角插座（带指示灯）
147 Tow switch and double 15A round 3 pin socket with neon
¥:230.00

AB-L-0199

147二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 15A square comer socket with neon
¥:216.00

AB-L-0200

147 四孔剃须插座
147 two shaving socket
¥:583.00

AB-L-0201

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 Kitchen switch
¥:315.00

AB-L-0202

147 45A开关+一位开关13A方角插带指示灯（组合厨房开关）
147 Kitchen switch
¥:315.00

AB-L-0203

147 45A开关+一位开关13A方插带灯（厨房开关）
147 Kitchen switch
¥:315.00

AB-L-0204

147 45A双极开关带指示灯
147 type 45A bipolar switch
¥:260.00

AB-L-0205

147 16A二位德式插座
147 Double German socket
¥:190.00

AB-L-0206

147 16A二位法式插座
147 Double French socket
¥:190.00

AB-L-0207

147 16A二位德式插座
147 Double Geman socket
¥:190.00

AB-L-0208

147 16A二位法式插座
147 Double French socket
¥:190.00

AB-L-0209

147型二位16A德式插座+USB/Type-c(小板）
147 Double 16A German socket +USB/Type - c
¥:370.00

AB-L-0210

147型二位16A法式插座+USB/Type-c(小板）
147 Double 16A French socket+ USB/Type-c
¥:370.00

AB-L-0211

147二位16A德式+二位USB（小板连体）
147 double 16A German standard socket +2USB
¥:340.00

AB-L-0212

147二位16A法式+2USB（小板连体）
147 double 16A French socket +2USB
¥:340.00

AB-L-0213

小板147型四位USB插座
147 4 USB socket
¥:450.00

AB-L-0214

147二位多功能插座+4USB(竖)
147 2-bit multi-function socket + 4USB
¥:370.00

AB-L-0215

147二位13A方角插座+4USB(竖)
147 two bit 13A square socket +4USB
¥:370.00

AB-L-0216

147 一位13A方角插座+二位USB
13A square comer socket and Two USB
¥:318.00

AB-L-0217

147 一位16A多功能插座+二位USB插座
13A square comer socket and two USB socket
¥:318.00

AB-L-0218

147型二位开关带二位多功能五孔插座带双USB
147 Tow switch and double 13A 5 pin MF socket+2USB
¥:370.00

AB-L-0219

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two position switch with two position 13A multifunction Five hole socket + 2 USB (with indicator)
¥:480.00



AB-L-0220

147 二位13A多功能五孔插座+四位USB
147 double 5 pin multi-function socket+4USB
¥:370.00

AB-L-0221

147 二位开关二位13A多功能五孔插座+四位USB
147 two switch double 5 pin multi function socket+4USB
¥:390.00

AB-L-0222

147型二位开关带二位多功能五孔插座带USB+type-c
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:480.00

AB-L-0223

147型二位开关带13A多功能+4USB(带指示灯)
147 two switch with double 13A MF+4USB(with indicator light)
¥:430.00

AB-L-0224

147型二开带二位13A方插带四位USB
147 type two switch two position 13A square inserting band 4 USB
¥:430.00

AB-L-0225

147二位13A方插带四位USB
147 double 13A square inserting +4USB
¥:410.00

AB-L-0226

二位13A多功能带四位USB(带盖板)
147 double 13A multi-function + 4USB(with cover plate)
¥:450.00

AB-L-0227

二位13A方角插座带四位USB(带盖板)
147 double 13A square inserting +4 USB(with cover plate)
¥:450.00

AB-L-0228

147 一开单控开关带多功能五孔插座
147 1 gang 1 way switch with MF 5 pin socket
¥:160.00

AB-L-0229

147 一开单控开关带多功能五孔+双USB
147 1 gang 1 way switch 2 USB with MF 5 pin socket
¥:260.00

AB-L-0230

147型16A多功能+万用五孔插座
147 type 16A MF 3 pin and 5 pin socket
¥:163.00

AB-L-0231

147 四位USB带二位10A二三极插座
147 double 10A 5 pin socket + 4 USB with indicator light
¥:370.00

AB-L-0232

147 二位开关带二位13A多功能+4USB(带指示灯)(竖)
147 two switch with two position 13A 3 pin multi-function socket + 4USB with indicator light
¥:390.00

AB-L-0233

小板147型13A二位方插带4USB带二位小开关
Small board 147 type 13A 2-bit square plug with 4USB with 2-bit small switch
¥:390.00

AB-L-0234

147型二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A German socket+USB/Type-c with neon
¥:470.00

AB-L-0235

147型二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A French socket+USB/Type-c with neon
¥:470.00

AB-L-0236

147型二位开关二位16A德式插座（带指示灯）
147 two switch double 16A German socket with neon
¥:260.00

AB-L-0237

147型二位开关二位16A法式插座（带指示灯）
147 two switch double 16A French socket with neon
¥:260.00

AB-L-0238

147型二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket with neon + 2usb
¥:370.00

AB-L-0239

147型二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch double 16A French socket with neon + 2USB
¥:370. 00

AB-L-0240

147型二位空白面板
147 Blank plate
¥:114.00

AB-L 不锈钢（灰色）
Stainless steel (grey)

304不锈钢
304 stainless steel

PC材质阻燃
PC material
flame retardant

安全防护门
Security door

稳定性
The stability of

语音/APP/轻触机械控制
Voice /APP/ touch mechanical control

情景模式/联动/定时
Scenario mode/Linkage/timing

支持多款AL音响
Support a variety of AL audio

涂鸦无线场景开关
(单火零火通用)
Doodle wireless scene switch
(Single fire and zero fire universal)

ZIGBEE智能按键开关
ZIGBEE Intelligent button switch

Zigbee一开
￥950.00

Zigbee二开
￥1050.00

Zigbee三开
￥1150.00

二三极USB/Type-c+开关
￥215.00

AB-L Stainless steel gray 不锈钢(灰色)

AB-L-0001
大板16A一位开关单控 ￥:68.00
Large panel 16A 1 gang 1 way switch
大板16A一位开关双控 ￥:70.00
Large panel 16A 1 gang 2 way switch
大板16A一位开关多控 ￥:108.00
Large panel 16A 1 gang more way switch

AB-L-0002
大板16A二位开关单控 ￥:86.00
Large panel 16A 2 gang 1 way switch
大板16A二位开关双控 ￥:91.00
Large panel 16A 2 gang 2 way switch
大板16A二位开关多控 ￥:144.00
Large panel 16A 2 gang more way switch

AB-L-0003
大板16A三位开关单控 ￥:104.00
Large panel 16A 3 gang 1 way switch
大板16A三位开关双控 ￥:112.00
Large panel 16A 3 gang 2 way switch

AB-L-0004
大板16A四位开关单控 ￥:122.00
Large panel 16A 4 gang 1 way switch
大板16A四位开关双控 ￥:132.00
Large panel 16A 4 gang 2 way switch

AB-L-0005
大板16A百叶窗升降开关
Large panel louver window lifter switch
￥:126.00

AB-L-0006
大板16A门控开关
Large panel gating switch
￥:86.00

AB-L-0007
大板16A英式门控开关
Large panel British gating switch
￥:86.00

AB-L-0008
大板16A门铃开关
Large panel doorbell switch
￥:86.00

AB-L-0009
大板20A双极开关带指示灯 ￥:133.00
Board 20A bipolar switch with indicator light
大板32A双极开关带指示灯 ￥:142.00
Board 32A bipolar switch with indicator light

AB-L-0010
大板45A双极开关带指示灯
Board 45A bipolar switch with indicator light
￥:160.00

AB-L-0011
大板16A三极插座
16A 3 pole socket
￥:70.00

AB-L-0012
大板16A多功能插座
16A 3 pin universal socket
￥:77.00

AB-L-0013
大板10A二三极插座
10A 5 pole socket
￥:68.00

AB-L-0014
大板10A错位二三极插座
10A Two or three pole socket
￥:79.00

AB-L-0015
大板16A多功能五孔插座
5 pin multi-function socket
￥:77.00

AB-L-0016
大板10A二二三极插座
10A 7 pole socket
￥:84.00

AB-L-0017
大板13A方角插座
13A square corner socket
￥:73.00

AB-L-0018
大板二位USB带16A多功能五孔插座
2 USB with 5 pin multi-function socket
￥:167.00

AB-L-0019
大板16A一位开关单控带16A三极插座
1gang 1 way switch and 16A 3 pole socket
￥:88.00
大板16A一位开关双控带16A三极插座
1gang 2 way switch and 16A 3 pole socket
￥:91.00

AB-L-0020
大板16A一位开关单控带10A二三极插座
1 gang 1 way switch and 5 pole socket
￥:88.00
大板16A一位开关双控带10A二三极插座
1 gang 2 way switch and 5 pole socket
￥:91.00

AB-L-0021
大板10A二位开关单控带二三极插座
2 gang 1 way switch and 5 pole socket
大板10A二位开关双控带二三极插座
2 gang 2 way switch and 5 pole socket
￥:108.00

AB-L-0022
大板一位开关带16A三极多功能插座(带指示灯)
1 gang switch and 16A 3 pin multi-purpose socket with indicator light
￥:97.00

AB-L-0023
大板一位双极开关带13A方角插座(指示灯)
1 gang switch and 13A square pin socket with indicator light
￥:97.00

AB-L-0024
大板一位开关带15A圆角插座(指示灯)
Large board one position switch with 15A round socket (indicator light)
￥:104.00

AB-L-0025
大板一位开关带16A二三极多功能插座(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
￥:115.00

AB-L-0026
大板16A德式插座
Large board 16A German socket
￥:86.00

AB-L-0027
大板16A法式插座
Large plate 16A French socket
￥:86.00

AB-L-0028
大板16A俄式插座
Large board 16A Russian socket
￥:86.00

AB-L-0029
大板16A德标插座带二位USB
German socket+2 USB
￥:185.00

AB-L-0030
大板16A法标插座带二位USB
French socket + 2 USB
￥:185.00

AB-L-0031
大板16A德标插座+USB/type-c
Large board 16A German socket + USB / type-C
￥:185.00

AB-L-0032
大板16A法式插座+USB/Type-c
Large board 16A French socket + USB / type-C
￥:185.00

AB-L-0033
大板一位电视插座
TV socket
￥:81.00

AB-L-0034
大板一位电话插座 ￥:81.00
telephone socket
大板一位电脑插座 ￥:99.00
computer socket
大板一位电脑插座(超六类) ￥:144.00
computer socket(6)

AB-L-0035
大板一位电视电话插座 ￥:108.00
TV + telephone socket
大板一位电视电脑插座 ￥:117.00
TV + computer socket
大板一位电视电脑插座(超六类) ￥:153.00
TV + computer socket(6)

AB-L-0036
大板二位电视插座
Two TV socket
￥:108.00

AB-L-0037
大板二位电话插座 ￥:108.00
Two TV socket
大板二位电脑插座 ￥:135.00
Two computer socket
大板二位电脑插座(超六类) ￥:207.00
Two computer socket(6)
大板电话+电脑插座 ￥:117.00
telephone+computer socket
大板电话+电脑插座(超六类) ￥:153.00
telephone+computer socket(6)

AB-L-0038
大板空白面板
Large plate Blank plate
￥:51.00

AB-L-0039
小板16A一位开关单控 ￥:75.00
16A 1 gang 1 way switch
小板16A一位开关双控 ￥:78.00
16A 1 gang 2 way switch
小板16A一位开关多控 ￥:120.00
16A 1 gang more way switch

AB-L-0040
小板16A二位开关单控 ￥:95.00
16A 2 gang 1 way switch
小板16A二位开关双控 ￥:101.00
16A 2 gang 2 way switch
小板16A二位开关多控 ￥:160.00
16A 2 gang more way switch

AB-L-0041
小板16A三位开关单控 ￥:115.00
16A 3 gang 1 way switch
小板16A三位开关双控 ￥:124.00
16A 3 gang 2 way switch

AB-L-0042
小板16A四位开关单控 ￥:135.00
16A 4 gang 1 way switch
小板16A四位开关双控 ￥:147.00
16A 4 gang 2 way switch

AB-L-0043
小板16A三位开关多控
16A 3 gang 3 way switch
￥:180.00

AB-L-0044
小板16A百叶窗升降开关
louver window lifter switch
￥:140.00

AB-L-0045
小板16A门控开关
gating switch
￥:95.00

AB-L-0046
小板16A英式门控开关
British gating switch
￥:95.00

AB-L-0047
小板16A门铃开关
doorbell switch
￥:95.00

AB-L-0048
小板16A拨动一位开关单控
1 gang 1 way toggle switch
￥:138.00
小板16A拨动一位开关双控
1 gang 2 way toggle switch
￥:148.00

AB-L-0049
小板16A拨动二位开关单控
2 gang 1 way toggle switch
￥:158.00
小板16A拨动二位开关双控
2 gang 2 way toggle switch
￥:170.00

AB-L-0050
小板16A拨动三位开关单控
3 gang 1 way toggle switch
￥:178.00
小板16A拨动三位开关双控
3 gang 2 way toggle switch
￥:196.00

AB-L-0051
小板16A拨动四位开关单控
4 gang 1 way toggle switch
￥:198.00
小板16A拨动四位开关双控
4 gang 2 way toggle switch
￥:222.00

AB-L-0052
小板20A双极开关带指示灯
20A swich with indicator light
￥:148.00
小板45A双极开关带指示灯
45A swich with indicator light
￥:178.00

AB-L-0053
小板45A双极开关带指示灯
45A swich with indicator light
￥:168.00

AB-L-0054
小板16A卷帘门复位开关
Shutter reset switch
￥:170.00

AB-L-0055
小板16A德式插座
German socket
￥:95.00

AB-L-0056
小板16A法式插座
French socket
￥:95.00

AB-L-0057
小板16A俄式插座
Russian socket
￥:95.00

AB-L-0058
小板16A以色列插座
Israel socket
￥:105.00

AB-L-0059
小板16A意大利+德式插座
Italy+German socket
￥:105.00

AB-L-0060
小板10A二极插座
10A 2 pole socket
￥:75.00

AB-L Stainless steel gray 不锈钢(灰色)

AB-L-0061
小板10A二二极插座
10A Double 2 pole socket
¥:83.00

AB-L-0062
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:85.00

AB-L-0063
小板10A一位开关带二二极座
1gang switch and 4 pole socket
¥:95.00

AB-L-0064
小板16A多功能三极插座
16A 3 pin multi-function socket
¥:78.00

AB-L-0065
小板13A二三极多功能插座
5 pin multi-function socket
¥:85.00

AB-L-0066
小板13A错位多功能二三极插座
Dislocation multi 5 pin multi-function socket
¥:95.00

AB-L-0067
小板13A方角插座
13A square corner socket
¥:81.00

AB-L-0068
小板15A圆角插座
15A 3 round pins socket
¥:85.00

AB-L-0069
小板15A美标扁三极插座
15A triode flat American standard socket
¥:85.00

AB-L-0070
小板15A泰式插座
15A Thai socket
¥:85.00

AB-L-0071
小板错位泰式六孔插座
Dislocation Thai 6 pin socket
¥:95.00

AB-L-0072
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:108.00

AB-L-0073
小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pin socket
¥:115.00

AB-L-0074
小板一位开关带16A多功能插座
1 gang switch and 3 pin MF socket
¥:115.00

AB-L-0075
小板一位开关带13A方角插座（带指示灯）
1 gang switch and 13A square pin socket with indicator light
¥:108.00

AB-L-0076
小板一位开关带15A圆孔插座（带指示灯）
1 gang switch and 15A 3 round pins socket with indicator light
¥:115.00

AB-L-0077
小板一位开关带16A多功能插座（带指示灯）
1 gang switch and 16A 3 pin MF socket with light
¥:115.00

AB-L-0078
小板一位开关带13A多功能五孔插座（带指示灯）
1 gang switch and 5 pin multi-function socket with indicator light
¥:128.00

AB-L-0079
小板16A德式插座带二位USB
2 USB with German socket
¥:205.00

AB-L-0080
小板16A法式插座带二位USB
2 USB with Frech socket
¥:205.00

AB-L-0081
小板16A德式插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:205.00

AB-L-0082
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:205.00

AB-L-0083
小板16A一位开关带德式插座
1 gang German socket
¥:110.00

AB-L-0084
小板16A一位开关带法式插座
1 gang French socket
¥:110.00

AB-L-0085
小板16A德式插座带防水
German socket and Waterproof belt
¥:105.00

AB-L-0086
小板16A法式插座带防水
French socket and Waterproof belt
¥:105.00

AB-L-0087
小板二位USB带13A方角插座（横）
2 USB with 13A square corner socket with swich
¥:205.00

AB-L-0088
小板美标+USB/Type-c
American Standard + USB / type-c
¥:205.00

AB-L-0089
小板15A泰式+USB/type-c
15A Thai+ USB / type-c
¥:205.00

AB-L-0090
小板二位USB带13A方角插座（带保护门）
2 USB with 13A square corner socket with flip cover
¥:225.00

AB-L-0091
小板二位USB带13A多功能插座（带保护门）
2 USB with 3 pin multi-purpose socket with flip cover
¥:225.00

AB-L-0092
小板一位开关带二位USB带13A多功能插座（带指示灯）
1 gang switch with two USB and 13A multi-function socket
¥:215.00

AB-L-0093
小板一位开关带二位USB带13A方角插座（带指示灯）
2 USB with 13A a quare comer socket with flip cover
¥:215.00

AB-L-0094
小板13A多功能带Type-c+USB
13A multifunction with type-C + USB
¥:205.00

AB-L-0095
小板13A方角插带Type-c+USB
13A square angle band type-C + USB
¥:205.00

AB-L-0096
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with Type-c+USB(with light)
¥:215.00

AB-L-0097
小板二位USB带13A多功能插座带小开关（竖）
2 USB with Three very multi-purpose socket with switch
¥:195.00

AB-L-0098
小板一位开关13A方插带Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:215.00

AB-L-0099
小板二位USB带13A方角插座带小开关（竖）
2 USB with 13A square corner socket with switch
¥:195.00

AB-L-0100
小板美标+2USB
American Standard + 2USB
¥:185.00

AB-L-0101
小板15A泰式+2USB
15A Thai + 2USB
¥:185.00

AB-L-0102
小板二位USB带13A多功能插座（横）
2 USB with 3 pin multi-purpose socket
¥:205.00

AB-L-0103
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:185.00

AB-L-0104
小板二位USB带10A二三极插座带开关
2 USB and 5 pin socket with switch
¥:195.00

AB-L-0105
小板10五孔插座带USB +Type-c 2.1A
10A 5 pole socket with USB type-C 2.1A
¥:205.00
小板10五孔插座带USB +Type-c 4A
10A 5 pole socket with USB type-c 4A
¥:310.00

AB-L-0106
小板一位开关带13A多功能五孔插座带USB
1 gang switch and 5 pin multi-function socket with USB and indicator light
¥:240.00

AB-L-0107
小板13A二位USB带多功能五孔插座
2 USB with 5 pin multi-function socket
¥:185.00

AB-L-0108
小板13A二位USB带多功能五孔插座带开关
2 USB with 5 pin multi-function socket with switch
¥:195.00

AB-L-0109
小板13A多功能五孔带USB+TYPE-C 2.1A
13A MF 5 pin socket USB+type-C 2.1A
¥:205.00
小板13A多功能五孔带USB+TYPE-C 4A
13A MF 5 pin socket USB+type-C 4A
¥:310.00

AB-L-0110
小板一位电视插座
TV socket
¥:90.00

AB-L-0111
小板一位电话插座 ¥:90.00
telephone socket
小板一位电脑插座 ¥:110.00
computer socket
小板一位电脑插座(超六类) ¥:150.00
computer socket(6)

AB-L-0112
小板双电视插座
Two TV socket
¥:120.00

AB-L-0113
小板双电话插座 ¥:120.00
Two telephone socket
小板双电脑插座 ¥:150.00
Two computer socket
小板双电脑插座（超六类） ¥:200.00
Two computer socket(6)
小板电话电脑插座 ¥:120.00
telephone+computer socket
小板电话电脑插座（超六类） ¥:170.00
telephone+computer socket(6)

AB-L-0114
小板电视电话插座 ¥:110.00
TV + telephone socket
小板电视电脑插座 ¥:120.00
TV + computer socket
小板一位电视电脑插座(超六类) ¥:170.00
TV + computer socket(6)

AB-L-0115
小板一位电话带USB插座 ¥:270.00
TEL + USB socket
小板一位电脑带USB插座 ¥:270.00
computer + USB socket
小板一位电脑带USB插座(超六类) ¥:320.00
computer + USB socket(6)

AB-L-0116
小板一位TV+FM
TV and FM
¥:190.00

AB-L-0117
小板一位卫星插座
Satellite socket
¥:110.00

AB-L-0118
小板二位卫星插座
Double satellite socket
¥:140.00

AB-L-0119
小板卫星+电视插座
Satellite and TV socket
¥:120.00

AB-L-0120
小板卫星带电话插座 ¥:120.00
Satellite and telephone socket
小板卫星带电脑插座 ¥:140.00
Satellite and computer socket
小板卫星带电脑插座(超六类） ¥:190.00
Satellite and computer socket(6)

AB-L Stainless steel gray 不锈钢(灰色)

AB-L-0121
小板二极插座带电视插座
2 pin socket with TV
¥:270.00

AB-L-0122
小板二极插座带电话插座 ¥:270.00
2 pin socket with telephone
小板二极插座带电脑插座 ¥:270.00
2 pin socket with computer
小板二极插座带电脑(超六类) ¥:320.00
2 pin socket with computer

AB-L-0123
小板一位光纤插座
Optical fiber socket
¥:148.00

AB-L-0124
小板二位USB插座
Double USB socket
¥:225.00

AB-L-0125
小板单联音响插座
Single audio socket
¥:153.00

AB-L-0126
小板双联音响插座
Double audio socket
¥:203.00

AB-L-0127
触摸延时开关（节能）
Touch delay delay switch
¥:133.00

AB-L-0128
声光控延时开关（节能）
Sound-light controlled delay switch
¥:133.00

AB-L-0129
红外线人体感应开关
Human body induction
¥:268.00

AB-L-0130
凹型地脚灯（亮光/暖光）
The footlights
¥:173.00

AB-L-0131
凹型红外线人体感应地脚灯
（亮光/暖光）
The human body induction footlights
¥:288.00

AB-L-0132
平面地脚灯（亮光/暖光）
Footlights
¥:173.00

AB-L-0133
叮咚门铃
Ding dong doorbell
¥:221.00

AB-L-0134
机械式40A插卡取电 ¥:260.00
Mechanical card for electricity
感应式低频40A插卡取电 ¥:380.00
Low frequency induction card for electricity
感应式高频40A插卡取电 ¥:440.00
High frequency induction card for electricity

AB-L-0135
紧急呼叫开关
Emergency call switch
¥:183.00

AB-L-0136
请勿打扰请即清理门铃开关
（按键式）
Do not disturb, please namely cleaning please + later doorbell "button"
¥:191.00

AB-L-0137
请勿打扰门铃开关（按键式）
Do not disturb + doorbell "button"
¥:343.00

AB-L-0138
请勿打扰请即清理门铃开关
（按键式）
Do not disturb plese namely cleaning please "button"
¥:343.00

AB-L-0139
智能音乐控制开关
Intelligent music control switch
¥:2750.00

AB-L-0140
小板温度控制调节器
Temperature control switch
¥:710.00

AB-L-0141
小板温度控制调节器
Temperature control switch
¥:800.00

AB-L-0142
调音开关
Tuning switch（fire）
¥:185.00

AB-L-0143
调光开关300W ¥:155.00
Dimming 300W
调光开关600W ¥:195.00
Dimming 600W
调光开关1000W ¥:235.00
Dimming 1000W

AB-L-0144
调速开关300W ¥:155.00
Speed 300W
调速开关600W ¥:195.00
Speed 600W
调速开关1000W ¥:235.00
Speed 1000W

AB-L-0145
一位开关带调光开关500W
1 gang with dimmer switch
¥:185.00

AB-L-0146
一位开关带调速开关500W
1 gang with speed switch
¥:185.00

AB-L-0147
13A开关带保险丝(带指示灯)
13A switch with fuse(with light)
¥:200.00

AB-L-0148
20A出线柱
20A outgoing post
¥:180.00

AB-L-0149
剃须插座
Shaving socket
¥:450.00

AB-L-0150
USB+电脑插座+无线路由
USB + computer socket,wireless router
¥:750.00

AB-L-0151
蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio + 3.5 + 2USB + HDMI
¥:5250.00

AB-L-0152
HDMI
¥:270.00

AB-L-0153
USB+TYPE-C
¥:310.00

AB-L-0154
HDMI+USB
¥:270.00

AB-L-0155
HDMI+USB+3.5音频
hemi+USB+3.5
¥:270.00

AB-L-0156
VGA+USB+3.5音频
VGA+USB +3.5
¥:270.00

AB-L-0157
AV+3.5音频
AV +3.5
¥:270.00

AB-L-0158
VGA+AV音频接口
VGA + AV audio interface
¥:270.00

AB-L-0159
HDMI+AV音频接口
HDMI + AV audio interface
¥:270.00

AB-L-0160
二分之一AV音频+卫星
Half AV audio interface+Satellite socket
¥:270.00

AB-L-0161
二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:270.00

AB-L-0162
二分之一VGA+TV
Half VGA+TV
¥:270.00

AB-K1-0163
二分之一VGA+电脑插座
Half VGA+computer socket
¥:270.00

AB-K1-0164
二分之一VGA+USB
Half VGA+USB
¥:270.00

AB-K1-0165
二分之一VGA+HDMI
Half VGA+HDMI
¥:270.00

AB-L-0166
45A出线柱
45A Outlet
¥:200.00

AB-L-0167
空白面板
Blank plate
¥:57.00

AB-L-0168
大板二位双极开关带二位13A方角插座（指示灯）
147 Tow switch and double 13A square comer socket with indicator light
¥:188.00

AB-L-0169
大板二位开关带二位16A多功能插座（带指示灯）
147 Tow switch and double 16A MF socket with light
¥:188.00

AB-L-0170
147 二位开关带二位13A方角插座带二位USB（带指示灯）
147 Tow switch and double 13A square comer socket with two USB and indicator light
¥:288.00

AB-L-0171
大板二位开关带二位16A多功能插座+2USB（带指示灯）
147 Tow switch and double 16A MF socket with 2USB and with light
¥:288.00

AB-L-0172
147型二位开关二位13A方插带灯+USB/Type-c（大板）
147 Tow switch and double 13A square comer socket with USB and indicator light
¥:288.00

AB-L-0173
147二位开关二位13A多功能带灯+USB/Type-c（大板）
147 Tow switch and double 13A MF socket with USB and indicator light
¥:288.00

AB-L-0174
147 二位开关单控 ¥:150.00
147 2 gang 1 way switch
147 二位开关双控 ¥:156.00
147 2 gang 2 way switch

AB-L-0175
147 三位开关单控 ¥:170.00
147 3 gang 1 way switch
147 三位开关双控 ¥:179.00
147 3 gang 2 way switch

AB-L-0176
147型四开单控开关 ¥:190.00
147 4 gang 1 way switch
147型四开双控开关 ¥:202.00
147 4 gang 2 way switch

AB-L-0177
147 五位开关单控 ¥:210.00
147 5 gang 1 way switch
147 五位开关双控 ¥:225.00
147 5 gang 2 way switch

AB-L-0178
147 六位开关单控 ¥:230.00
147 6 gang 1 way switch
147 六位开关双控 ¥:248.00
147 6 gang 2 way switch

AB-L-0179
147 七位开关单控 ¥:250.00
147 7 gang 1 way switch
147 七位开关双控 ¥:271.00
147 7 gang 2 way switch

AB-L-0180
147 八位开关单控 ¥:270.00
147 8 gang 1 way switch
147 八位开关双控 ¥:294.00
147 8 gang 2 way switch

AB-L Stainless steel gray 不锈钢(灰色)

AB-L-0181

147 二位16A多功能三极插座
147 Double 16A MF socket
¥:156.00

AB-L-0182

147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:170.00

AB-L-0183

小板147型二位15A美标扁插座
147 Double 15A triode flat Ammerican standard socket
¥:170.00

AB-L-0184

147 二位15A美标三极多功能插座
147 Double 15A triode flat Ammerican standard socket
¥:170.00

AB-L-0185

147 二位13A方角插座
147 Double 13A square comer socket
¥:162.00

AB-L-0186

小板147型二位15A圆角插座
147 Double 15A 3 round pins socket
¥:170.00

AB-L-0187

小板147型二位13A错位多功能二三极插座
147 Double 13A dislocation MF Two three pole socket
¥:190.00

AB-L-0188

147 二位 二三极插座
147 Double position two and three pole socket
¥:152.00

AB-L-0189

147 二位开关带二位13A方角插座
147 Tow switch and double 13A square comer socket
¥:210 .00

AB-L-0190

147 二位开关带二位16A多功能插座
147 Tow switch and double 13A MF 3 pin socket
¥:210.00

AB-L-0191

147二位开关二位13A多功能五孔插座
147 Tow switch and double 13A MF 5 pin socket
¥:260.00

AB-L-0192

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 13A square comer socket with neon
¥:210.00

AB-L-0193

147 二位开关带二位13A多功能插座(带指示灯)
147 Tow switch and double 13A MF socket with light
¥:210.00

AB-L-0194

147二位开关二位13A方插+二位USB（小板）
147 Tow switch and double 13A square comer socket+2USB
¥:280.00

AB-L-0195

147二位开关二位13A多功能+二位USB（小板）
147 Tow switch and double 13A MF socket+2USB
¥:280.00

AB-L-0196

147二位开关二位13A方插+USB/Type-c（小板）
147 two switch double 13A square band lamp+USB/Type-c
¥:280.00

AB-L-0197

147二位开关二位13A多功能+USB/Type-c（小板）
147 two switch double 13A MF 3 pin socket+USB/Type-c
¥:280.00

AB-L-0198

147 二位开关带二位15A圆角插座（带指示灯）
147 Tow switch and double 15A round 3 pin socket with neon
¥:230.00

AB-L-0199

147二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 15A square comer socket with neon
¥:216.00

AB-L-0200

147 四孔剃须插座
147 two shaving socket
¥:583.00

AB-L-0201

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 Kitchen switch
¥:315.00

AB-L-0202

147 45A开关+一位开关13A方角插带指示灯（组合厨房开关）
147 Kitchen switch
¥:315.00

AB-L-0203

147 45A开关+一位开关13A方插带灯（厨房开关）
147 Kitchen switch
¥:315.00

AB-L-0204

147 45A双极开关带指示灯
147 type 45A bipolar switch
¥:260.00

AB-L-0205

147 16A二位德式插座
147 Double German socket
¥:190.00

AB-L-0206

147 16A二位法式插座
147 Double French socket
¥:190.00

AB-L-0207

147 16A二位德式插座
147 Double Geman socket
¥:190.00

AB-L-0208

147 16A二位法式插座
147 Double French socket
¥:190.00

AB-L-0209

147型二位16A德式插座+USB/Type-c(小板）
147 Double 16A German socket +USB/Type - c
¥:370.00

AB-L-0210

147型二位16A法式插座+USB/Type-c(小板）
147 Double 16A French socket+ USB/Type-c
¥:370.00

AB-L-0211

147二位16A德式+二位USB（小板连体）
147 double 16A German standard socket +2USB
¥:340.00

AB-L-0212

147二位16A法式+2USB（小板连体）
147 double 16A French socket +2USB
¥:340.00

AB-L-0213

小板147型四位USB插座
147 4 USB socket
¥:450.00

AB-L-0214

147二位多功能插座+4USB(竖)
147 2-bit multi-function socket + 4USB
¥:370.00

AB-L-0215

147二位13A方角插座+4USB(竖)
147 two bit 13A square socket +4USB
¥:370.00

AB-L-0216

147 一位13A方角插座+二位USB
13A square comer socket and Two USB
¥:318.00

AB-L-0217

147 一位16A多功能插座+二位USB插座
13A square comer socket and two USB socket
¥:318.00

AB-L-0218

147型二位开关带二位多功能五孔插座带双USB
147 Tow switch and double 13A 5 pin MF socket+2USB
¥:370.00

AB-L-0219

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two position switch with two position 13A multifunction Five hole socket + 2 USB (with indicator)
¥:480.00

AB-L-0220

147 二位13A多功能五孔插座+四位USB
147 double 5 pin multi-function socket+4USB
¥:370.00

AB-L-0221

147 二位开关二位13A多功能五孔插座+四位USB
147 two switch double 5 pin multi function socket+4USB
¥:390.00

AB-L-0222

147型二位开关带二位多功能五孔插座带USB+type-c
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:480.00

AB-L-0223

147型二位开关带13A多功能+4USB(带指示灯)
147 two switch with double 13A MF+4USB(with indicator light)
¥:430.00

AB-L-0224

147型二开带二位13A方插带四位USB
147 type two switch two position 13A square inserting band 4 USB
¥:430.00

AB-L-0225

147二位13A方插带四位USB
147 double 13A square inserting +4USB
¥:410.00

AB-L-0226

二位13A多功能带四位USB(带盖板)
147 double 13A multi-function + 4USB(with cover plate)
¥:450.00

AB-L-0227

二位13A方角插座带四位USB(带盖板)
147 double 13A square inserting +4 USB(with cover plate)
¥:450.00

AB-L-0228

147 一开单控开关带多功能五孔插座
147 1 gang 1 way switch with MF 5 pin socket
¥:160.00

AB-L-0229

147 一开单控开关带多功能五孔+双USB
147 1 gang 1 way switch 2 USB with MF 5 pin socket
¥:260.00

AB-L-0230

147型16A多功能+万用五孔插座
147 type 16A MF 3 pin and 5 pin socket
¥:163.00

AB-L-0231

147 四位USB带二位10A二三极插座
147 double 10A 5 pin socket + 4 USB with indicator light
¥:370.00

AB-L-0232

147 二位开关带二位13A多功能+4USB(带指示灯)(竖)
147 two switch with two position 13A 3 pin multi-function socket + 4USB with indicator light
¥:390.00

AB-L-0233

小板147型13A二位方插带4USB带二位小开关
Small board 147 type 13A 2-bit square plug with 4USB with 2-bit small switch
¥:390.00

AB-L-0234

147型二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A German socket+USB/Type-c with neon
¥:470.00

AB-L-0235

147型二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A French socket+USB/Type-c with neon
¥:470.00

AB-L-0236

147型二位开关二位16A德式插座（带指示灯）
147 two switch double 16A German socket with neon
¥:260.00

AB-L-0237

147型二位开关二位16A法式插座（带指示灯）
147 two switch double 16A French socket with neon
¥:260.00

AB-L-0238

147型二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket with neon + 2usb
¥:370.00

AB-L-0239

147型二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch double 16A French socket with neon + 2USB
¥:370. 00

AB-L-0240

147型二位空白面板
147 Blank plate
¥:114.00

Zigbee智能按键开关

Zigbee Intelligent button switch

Zigbee一开

￥950.00

语音/APP/轻触机械控制

Voice /APP/ touch mechanical control

Zigbee二开

￥1050.00

情景模式/联动/定时

Scenario mode/Linkage/timing

Zigbee三开

￥1150.00

支持多款AL音响

Support a variety of AL audio

二三极USB/Type-c+开关

￥215.00

涂鸦无线场景开关
(单火零火通用)

Doodle wireless scene switch
(Single fire and zero fire universal)



小角度设计 舒适手感

带来清爽舒适的按压体验
可以有效降低按压使用的噪音

优质银合金触点

黄金比例的锡磷青铜和银镍合金，让导电性和弹性两方面均发挥出色效果。开关摆动件采用高纯度紫铜，插座铜件采用高精度锡磷青铜，防腐防锈，经久耐用。

严选材料

考究的选材严格的标准开关面板选优质PC塑料，经模具注塑而成；色泽纯正，质感好；绝缘性能良好，阻燃性能强，不易变色。

大间距插座 互不干扰

避免插孔因间距小
而无法同时使用

AB-L 铝镁合金(黑色)

Aluminum magnesium alloy(black)

创新不断 拒绝平庸

无框设计,厚实的铜片与钢架，这是工艺之美

Frameless design, thick copper and steel frame,
this is the beauty of the process

AB-L Aluminum magnesium alloy black 铝镁合金(黑色)

AB-L-0001
大板16A一位开关单控 ￥:68.00
Large panel 16A 1 gang 1 way switch
大板16A一位开关双控 ￥:70.00
Large panel 16A 1 gang 2 way switch
大板16A一位开关多控 ￥:108.00
Large panel 16A 1 gang more way switch

AB-L-0002
大板16A二位开关单控 ￥:86.00
Large panel 16A 2 gang 1 way switch
大板16A二位开关双控 ￥:91.00
Large panel 16A 2 gang 2 way switch
大板16A二位开关多控 ￥:144.00
Large panel 16A 2 gang more way switch

AB-L-0003
大板16A三位开关单控 ￥:104.00
Large panel 16A 3 gang 1 way switch
大板16A三位开关双控 ￥:112.00
Large panel 16A 3 gang 2 way switch

AB-L-0004
大板16A四位开关单控 ￥:122.00
Large panel 16A 4 gang 1 way switch
大板16A四位开关双控 ￥:132.00
Large panel 16A 4 gang 2 way switch

AB-L-0005
大板16A百叶窗升降开关
Large panel louver window lifter switch
￥:126.00

AB-L-0006
大板16A门控开关
Large panel gating switch
￥:86.00

AB-L-0007
大板16A英式门控开关
Large panel British gating switch
￥:86.00

AB-L-0008
大板16A门铃开关
Large panel doorbell switch
￥:86.00

AB-L-0009
大板20A双极开关带指示灯 ￥:133.00
Board 20A bipolar switch with indicator light
大板32A双极开关带指示灯 ￥:142.00
Board 32A bipolar switch with indicator light

AB-L-0010
大板45A双极开关带指示灯
Board 45A bipolar switch with indicator light
￥:160.00

AB-L-0011
大板16A三极插座
16A 3 pole socket
￥:70.00

AB-L-0012
大板16A多功能插座
16A 3 pin universal socket
￥:77.00

AB-L-0013
大板10A二三极插座
10A 5 pole socket
￥:68.00

AB-L-0014
大板10A错位二三极插座
10A Two or three pole socket
￥:79.00

AB-L-0015
大板16A多功能五孔插座
5 pin multi-function socket
￥:77.00

AB-L-0016
大板10A二二三极插座
10A 7 pole socket
￥:84.00

AB-L-0017
大板13A方角插座
13A square corner socket
￥:73.00

AB-L-0018
大板二位USB带16A多功能五孔插座
2 USB with 5 pin multi-function socket
￥:167.00

AB-L-0019
大板16A一位开关单控带16A三极插座
1gang 1 way switch and 16A 3 pole socket
￥:88.00
大板16A一位开关双控带16A三极插座
1gang 2 way switch and 16A 3 pole socket
￥:91.00

AB-L-0020
大板16A一位开关单控带10A二三极插座
1 gang 1 way switch and 5 pole socket
￥:88.00
大板16A一位开关双控带10A二三极插座
1 gang 2 way switch and 5 pole socket
￥:91.00

AB-L-0021
大板10A二位开关单控带二三极插座
2 gang 1 way switch and 5 pole socket
大板10A二位开关双控带二三极插座
2 gang 2 way switch and 5 pole socket
￥:108.00

AB-L-0022
大板一位开关带16A三极多功能插座(带指示灯)
1 gang switch and 16A 3 pin multi-purpose socket with indicator light
￥:97.00

AB-L-0023
大板一位双极开关带13A方角插座(指示灯)
1 gang switch and 13A square pin socket with indicator light
￥:97.00

AB-L-0024
大板一位开关带15A圆角插座(指示灯)
Large board one position switch with 15A round socket (indicator light)
￥:104.00

AB-L-0025
大板一位开关带16A二三极多功能插座(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
￥:115.00

AB-L-0026
大板16A德式插座
Large board 16A German socket
￥:86.00

AB-L-0027
大板16A法式插座
Large plate 16A French socket
￥:86.00

AB-L-0028
大板16A俄式插座
Large board 16A Russian socket
￥:86.00

AB-L-0029
大板16A德标插座带二位USB
German socket+2 USB
￥:185.00

AB-L-0030
大板16A法标插座带二位USB
French socket + 2 USB
￥:185.00

AB-L-0031
大板16A德标插座+USB/type-c
Large board 16A German socket + USB / type-C
￥:185.00

AB-L-0032
大板16A法式插座+USB/Type-c
Large board 16A French socket + USB / type-C
￥:185.00

AB-L-0033
大板一位电视插座
TV socket
￥:81.00

AB-L-0034
大板一位电话插座 ￥:81.00
telephone socket
大板一位电脑插座 ￥:99.00
computer socket
大板一位电脑插座(超六类) ￥:144.00
computer socket(6)

AB-L-0035
大板一位电视电话插座 ￥:108.00
TV + telephone socket
大板一位电视电脑插座 ￥:117.00
TV + computer socket
大板一位电视电脑插座(超六类) ￥:153.00
TV + computer socket(6)

AB-L-0036
大板二位电视插座
Two TV socket
￥:108.00

AB-L-0037
大板二位电话插座 ￥:108.00
Two TV socket
大板二位电脑插座 ￥:135.00
Two computer socket
大板二位电脑插座(超六类) ￥:207.00
Two computer socket(6)
大板电话+电脑插座 ￥:117.00
telephone+computer socket
大板电话+电脑插座(超六类) ￥:153.00
telephone+computer socket(6)

AB-L-0038
大板空白面板
Large plate Blank plate
￥:51.00

AB-L-0039
小板16A一位开关单控 ￥:75.00
16A 1 gang 1 way switch
小板16A一位开关双控 ￥:78.00
16A 1 gang 2 way switch
小板16A一位开关多控 ￥:120.00
16A 1 gang more way switch

AB-L-0040
小板16A二位开关单控 ￥:95.00
16A 2 gang 1 way switch
小板16A二位开关双控 ￥:101.00
16A 2 gang 2 way switch
小板16A二位开关多控 ￥:160.00
16A 2 gang more way switch

AB-L-0041
小板16A三位开关单控 ￥:115.00
16A 3 gang 1 way switch
小板16A三位开关双控 ￥:124.00
16A 3 gang 2 way switch

AB-L-0042
小板16A四位开关单控 ￥:135.00
16A 4 gang 1 way switch
小板16A四位开关双控 ￥:147.00
16A 4 gang 2 way switch

AB-L-0043
小板16A三位开关多控
16A 3 gang 3 way switch
￥:180.00

AB-L-0044
小板16A百叶窗升降开关
louver window lifter switch
￥:140.00

AB-L-0045
小板16A门控开关
gating switch
￥:95.00

AB-L-0046
小板16A英式门控开关
British gating switch
￥:95.00

AB-L-0047
小板16A门铃开关
doorbell switch
￥:95.00

AB-L-0048
小板16A拨动一位开关单控
1 gang 1 way toggle switch
￥:138.00
小板16A拨动一位开关双控
1 gang 2 way toggle switch
￥:148.00

AB-L-0049
小板16A拨动二位开关单控
2 gang 1 way toggle switch
￥:158.00
小板16A拨动二位开关双控
2 gang 2 way toggle switch
￥:170.00

AB-L-0050
小板16A拨动三位开关单控
3 gang 1 way toggle switch
￥:178.00
小板16A拨动三位开关双控
3 gang 2 way toggle switch
￥:196.00

AB-L-0051
小板16A拨动四位开关单控
4 gang 1 way toggle switch
￥:198.00
小板16A拨动四位开关双控
4 gang 2 way toggle switch
￥:222.00

AB-L-0052
小板20A双极开关带指示灯
20A swich with indicator light
￥:148.00
小板45A双极开关带指示灯
45A swich with indicator light
￥:178.00

AB-L-0053
小板45A双极开关带指示灯
45A swich with indicator light
￥:168.00

AB-L-0054
小板16A卷帘门复位开关
Shutter reset switch
￥:170.00

AB-L-0055
小板16A德式插座
German socket
￥:95.00

AB-L-0056
小板16A法式插座
French socket
￥:95.00

AB-L-0057
小板16A俄式插座
Russian socket
￥:95.00

AB-L-0058
小板16A以色列插座
Israel socket
￥:105.00

AB-L-0059
小板16A意大利+德式插座
Italy+German socket
￥:105.00

AB-L-0060
小板10A二极插座
10A 2 pole socket
￥:75.00

AB-L Aluminum magnesium alloy black 铝镁合金(黑色)

AB-L-0061
小板10A二二极插座
10A Double 2 pole socket
¥:83.00

AB-L-0062
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:85.00

AB-L-0063
小板10A一位开关带二二极座
1gang switch and 4 pole socket
¥:95.00

AB-L-0064
小板16A多功能三极插座
16A 3 pin multi-function socket
¥:78.00

AB-L-0065
小板13A二三极多功能插座
5 pin multi-function socket
¥:85.00

AB-L-0066
小板13A错位多功能二三极插座
Dislocation multi 5 pin multi-function socket
¥:95.00

AB-L-0067
小板13A方角插座
13A square corner socket
¥:81.00

AB-L-0068
小板15A圆角插座
15A 3 round pins socket
¥:85.00

AB-L-0069
小板15A美标扁三极插座
15A triode flat American standard socket
¥:85.00

AB-L-0070
小板15A泰式插座
15A Thai socket
¥:85.00

AB-L-0071
小板错位泰式六孔插座
Dislocation Thai 6 pin socket
¥:95.00

AB-L-0072
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:108.00

AB-L-0073
小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pin socket
¥:115.00

AB-L-0074
小板一位开关带16A多功能插座
1 gang switch and 3 pin MF socket
¥:115.00

AB-L-0075
小板一位开关带13A方角插座（带指示灯）
1 gang switch and 13A square pin socket with indicator light
¥:108.00

AB-L-0076
小板一位开关带15A圆孔插座（带指示灯）
1 gang switch and 15A 3 round pins socket with indicator light
¥:115.00

AB-L-0077
小板一位开关带16A多功能插座（带指示灯）
1 gang switch and 16A 3 pin MF socket with light
¥:115.00

AB-L-0078
小板一位开关带13A多功能五孔插座（带指示灯）
1 gang switch and 5 pin multi-function socket with indicator light
¥:128.00

AB-L-0079
小板16A德式插座带二位USB
2 USB with German socket
¥:205.00

AB-L-0080
小板16A法式插座带二位USB
2 USB with French socket
¥:205.00

AB-L-0081
小板16A德式插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:205.00

AB-L-0082
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:205.00

AB-L-0083
小板16A一位开关带德式插座
1 gang German socket
¥:110.00

AB-L-0084
小板16A一位开关带法式插座
1 gang French socket
¥:110.00

AB-L-0085
小板16A德式插座带防水
German socket and Waterproof belt
¥:105.00

AB-L-0086
小板16A法式插座带防水
French socket and Waterproof belt
¥:105.00

AB-L-0087
小板二位USB带13A方角插座（横）
2 USB with 13A square corner socket with swich
¥:205.00

AB-L-0088
小板美标+USB/Type-c
American Standard + USB / type-c
¥:205.00

AB-L-0089
小板15A泰式+USB/type-c
15A Thai+ USB / type-c
¥:205.00

AB-L-0090
小板二位USB带13A方角插座（带保护门）
2 USB with 13A square corner socket with flip cover
¥:225.00

AB-L-0091
小板二位USB带13A多功能插座（带保护门）
2 USB with 3 pin multi-purpose socket with flip cover
¥:225.00

AB-L-0092
小板一位开关带二位USB带13A多功能插座（带指示灯）
1 gang switch with two USB and 13A multi-function socket
¥:215.00

AB-L-0093
小板一位开关带二位USB带13A方角插座（带指示灯）
2 USB with 13A a quare comer socket with flip cover
¥:215.00

AB-L-0094
小板13A多功能带Type-c+USB
13A multifunction with type-C + USB
¥:205.00

AB-L-0095
小板13A方角插带Type-c+USB
13A square angle band type-C + USB
¥:205.00

AB-L-0096
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with Type-c+USB(with light)
¥:215.00

AB-L-0097
小板二位USB带13A多功能插座带小开关（竖）
2 USB with Three very multi-purpose socket with switch
¥:195.00

AB-L-0098
小板一位开关13A方插带Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:215.00

AB-L-0099
小板二位USB带13A方角插座带小开关（竖）
2 USB with 13A square corner socket with switch
¥:195.00

AB-L-0100
小板美标+2USB
American Standard + 2USB
¥:185.00

AB-L-0101
小板15A泰式+2USB
15A Thai + 2USB
¥:185.00

AB-L-0102
小板二位USB带13A多功能插座（横）
2 USB with 3 pin multi-purpose socket
¥:205.00

AB-L-0103
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:185.00

AB-L-0104
小板二位USB带10A二三极插座带开关
2 USB and 5 pin socket with switch
¥:195.00

AB-L-0105
小板10五孔插座带USB +Type-c 2.1A
10A 5 pole socket with USB type-C 2.1A
¥:205.00
小板10五孔插座带USB +Type-c 4A
10A 5 pole socket with USB type-c 4A
¥:310.00

AB-L-0106
小板一位开关带13A多功能五孔插座带USB
1 gang switch and 5 pin multi-function socket with USB and indicator light
¥:240.00

AB-L-0107
小板13A二位USB带多功能五孔插座
2 USB with 5 pin multi-function socket
¥:185.00

AB-L-0108
小板13A二位USB带多功能五孔插座带开关
2 USB with 5 pin multi-function socket with switch
¥:195.00

AB-L-0109
小板13A多功能五孔带USB+TYPE-C 2.1A
13A MF 5 pin socket USB+type-C 2.1A
¥:205.00
小板13A多功能五孔带USB+TYPE-C 4A
13A MF 5 pin socket USB+type-C 4A
¥:310.00

AB-L-0110
小板一位电视插座
TV socket
¥:90.00

AB-L-0111
小板一位电话插座 ¥:90.00
telephone socket
小板一位电脑插座 ¥:110.00
computer socket
小板一位电脑插座(超六类) ¥:150.00
computer socket(6)

AB-L-0112
小板双电视插座
Two TV socket
¥:120.00

AB-L-0113
小板双电话插座 ¥:120.00
Two telephone socket
小板双电脑插座 ¥:150.00
Two computer socket
小板双电脑插座（超六类） ¥:200.00
Two computer socket(6)
小板电话电脑插座 ¥:120.00
telephone+computer socket
小板电话电脑插座（超六类） ¥:170.00
telephone+computer socket(6)

AB-L-0114
小板电视电话插座 ¥:110.00
TV + telephone socket
小板电视电脑插座 ¥:120.00
TV + computer socket
小板一位电视电脑插座(超六类) ¥:170.00
TV + computer socket(6)

AB-L-0115
小板一位电话带USB插座 ¥:270.00
TEL + USB socket
小板一位电脑带USB插座 ¥:270.00
computer + USB socket
小板一位电脑带USB插座(超六类) ¥:320.00
computer + USB socket(6)

AB-L-0116
小板一位TV+FM
TV and FM
¥:190.00

AB-L-0117
小板一位卫星插座
Satellite socket
¥:110.00

AB-L-0118
小板二位卫星插座
Double satellite socket
¥:140.00

AB-L-0119
小板卫星+电视插座
Satellite and TV socket
¥:120.00

AB-L-0120
小板卫星带电话插座 ¥:120.00
Satellite and telephone socket
小板卫星带电脑插座 ¥:140.00
Satellite and computer socket
小板卫星带电脑插座(超六类） ¥:190.00
Satellite and computer socket(6)

AB-L Aluminum magnesium alloy black 铝镁合金(黑色)

AB-L-0121
小板二极插座带电视插座
2 pin socket with TV
￥:270.00

AB-L-0122
小板二极插座带电话插座 ￥:270.00
2 pin socket with telephone
小板二极插座带电脑插座 ￥:270.00
2 pin socket with computer
小板二极插座带电脑(超六类) ￥:320.00
2 pin socket with computer

AB-L-0123
小板一位光纤插座
Optical fiber socket
￥:148.00

AB-L-0124
小板二位USB插座
Double USB socket
￥:225.00

AB-L-0125
小板单联音响插座
Single audio socket
￥:153.00

AB-L-0126
小板双联音响插座
Double audio socket
￥:203.00

AB-L-0127
触摸延时开关（节能）
Touch delay delay switch
￥:133.00

AB-L-0128
声光控延时开关（节能）
Sound-light controlled delay switch
￥:133.00

AB-L-0129
红外线人体感应开关
Human body induction
￥:268.00

AB-L-0130
凹型地脚灯（亮光/暖光）
The footlights
￥:173.00

AB-L-0131
凹型红外线人体感应地脚灯
（亮光/暖光）
The human body induction footlights
￥:288.00

AB-L-0132
平面地脚灯（亮光/暖光）
Footlights
￥:173.00

AB-L-0133
叮咚门铃
Ding dong doorbell
￥:221.00

AB-L-0134
机械式40A插卡取电 ￥:260.00
Mechanical card for electricity
感应式低频40A插卡取电 ￥:380.00
Low frequency induction card for electricity
感应式高频40A插卡取电 ￥:440.00
High frequency induction card for electricity

AB-L-0135
紧急呼叫开关
Emergency call switch
￥:183.00

AB-L-0136
请勿打扰请即清理门铃开关
（按键式）
Do not disturb, please namely cleaning please + later doorbell "button"
￥:191.00

AB-L-0137
请勿打扰门铃开关（按键式）
Do not disturb + doorbell "button"
￥:343.00

AB-L-0138
请勿打扰请即清理门铃开关
（按键式）
Do not disturb plese namely cleaning please "button"
￥:343.00

AB-L-0139
智能音乐控制开关
Intelligent music control switch
￥:2750.00

AB-L-0140
小板温度控制调节器
Temperature control switch
￥:710.00

AB-L-0141
小板温度控制调节器
Temperature control switch
￥:800.00

AB-L-0142
调音开关
Tuning switch （fire）
￥:185.00

AB-L-0143
调光开关300W ￥:155.00
Dimming 300W
调光开关600W ￥:195.00
Dimming 600W
调光开关1000W ￥:235.00
Dimming 1000W

AB-L-0144
调速开关300W ￥:155.00
Speed 300W
调速开关600W ￥:195.00
Speed 600W
调速开关1000W ￥:235.00
Speed 1000W

AB-L-0145
一位开关带调光开关500W
1 gang with dimmer switch
￥:185.00

AB-L-0146
一位开关带调速开关500W
1 gang with speed switch
￥:185.00

AB-L-0147
13A开关带保险丝(带指示灯)
13A switch with fuse(with light)
￥:200.00

AB-L-0148
20A出线柱
20A outgoing post
￥:180.00

AB-L-0149
剃须插座
Shaving socket
￥:450.00

AB-L-0150
USB+电脑插座+无线路由
USB + computer socket,wireless router
￥:750.00

AB-L-0151
蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio + 3.5 + 2USB + HDMI
￥:5250.00

AB-L-0152
HDMI
￥:270.00

AB-L-0153
USB+TYPE-C
￥:310.00

AB-L-0154
HDMI+USB
￥:270.00

AB-L-0155
HDMI+USB+3.5音频
hemi+USB+3.5
￥:270.00

AB-L-0156
VGA+USB+3.5音频
VGA+USB +3.5
￥:270.00

AB-L-0157
AV+3.5音频
AV +3.5
￥:270.00

AB-L-0158
VGA+AV音频接口
VGA + AV audio interface
￥:270.00

AB-L-0159
HDMI+AV音频接口
HDMI + AV audio interface
￥:270.00

AB-L-0160
二分之一AV音频+卫星
Half AV audio interface+Satellite socket
￥:270.00

AB-L-0161
二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
￥:270.00

AB-L-0162
二分之一VGA+TV
Half VGA+TV
￥:270.00

AB-K1-0163
二分之一VGA+电脑插座
Half VGA+computer socket
￥:270.00

AB-K1-0164
二分之一VGA+USB
Half VGA+USB
￥:270.00

AB-K1-0165
二分之一VGA+HDMI
Half VGA+HDMI
￥:270.00

AB-L-0166
45A出线柱
45A Outlet
￥:200.00

AB-L-0167
空白面板
Blank plate
￥:57.00

AB-L-0168
大板二位双极开关带二位13A方角插座（指示灯）
147 Tow switch and double 13A square comer socket with indicator light
￥:188.00

AB-L-0169
大板二位开关带二位16A多功能插座（带指示灯）
147 Tow switch and double 16A MF socket with light
￥:188.00

AB-L-0170
147 二位开关带二位13A方角插座带二位USB（带指示灯）
147 Tow switch and double 13A square comer socket with two USB and indicator light
￥:288.00

AB-L-0171
大板二位开关带二位16A多功能插座+2USB（带指示灯）
147 Tow switch and double 16A MF socket with 2USB and with light
￥:288.00

AB-L-0172
147型二位开关二位13A方插带灯+USB/Type-c（大板）
147 Tow switch and double 13A square comer socket with USB and indicator light
￥:288.00

AB-L-0173
147二位开关二位13A多功能带灯+USB/Type-c（大板）
147 Tow switch and double 13A MF socket with USB and indicator light
￥:288.00

AB-L-0174
147 二位开关单控 ￥:150.00
147 2 gang 1 way switch
147 二位开关双控 ￥:156.00
147 2 gang 2 way switch

AB-L-0175
147 三位开关单控 ￥:170.00
147 3 gang 1 way switch
147 三位开关双控 ￥:179.00
147 3 gang 2 way switch

AB-L-0176
147型四开单控开关 ￥:190.00
147 4 gang 1 way switch
147型四开双控开关 ￥:202.00
147 4 gang 2 way switch

AB-L-0177
147 五位开关单控 ￥:210.00
147 5 gang 1 way switch
147 五位开关双控 ￥:225.00
147 5 gang 2 way switch

AB-L-0178
147 六位开关单控 ￥:230.00
147 6 gang 1 way switch
147 六位开关双控 ￥:248.00
147 6 gang 2 way switch

AB-L-0179
147 七位开关单控 ￥:250.00
147 7 gang 1 way switch
147 七位开关双控 ￥:271.00
147 7 gang 2 way switch

AB-L-0180
147 八位开关单控 ￥:270.00
147 8 gang 1 way switch
147 八位开关双控 ￥:294.00
147 8 gang 2 way switch

AB-L Aluminum magnesium alloy black 铝镁合金(黑色)

AB-L-0181

147 二位16A多功能三极插座
147 Double 16A MF socket
¥:156.00

AB-L-0182

147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:170.00

AB-L-0183

小板147型二位15A美标扁插座
147 Double 15A triode flat Ammerican standard socket
¥:170.00

AB-L-0184

147 二位15A美标三极多功能插座
147 Double 15A triode flat Ammerican standard socket
¥:170.00

AB-L-0185

147 二位13A方角插座
147 Double 13A square comer socket
¥:162.00

AB-L-0186

小板147型二位15A圆角插座
147 Double 15A 3 round pins socket
¥:170.00

AB-L-0187

小板147型二位13A错位多功能二三极插座
147 Double 13A dislocation MF Two three pole socket
¥:190.00

AB-L-0188

147 二位 二三极插座
147 Double position two and three pole socket
¥:152.00

AB-L-0189

147 二位开关带二位13A方角插座
147 Tow switch and double 13A square comer socket
¥:210 .00

AB-L-0190

147 二位开关带二位16A多功能插座
147 Tow switch and double 13A MF 3 pin socket
¥:210.00

AB-L-0191

147二位开关二位13A多功能五孔插座
147 Tow switch and double 13A MF 5 pin socket
¥:260.00

AB-L-0192

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 13A square comer socket with neon
¥:210.00

AB-L-0193

147 二位开关带二位13A多功能插座(带指示灯)
147 Tow switch and double 13A MF socket with light
¥:210.00

AB-L-0194

147二位开关二位13A方插+二位USB（小板）
147 Tow switch and double 13A square comer socket+2USB
¥:280.00

AB-L-0195

147二位开关二位13A多功能+二位USB（小板）
147 Tow switch and double 13A MF socket+2USB
¥:280.00

AB-L-0196

147二位开关二位13A方插+USB/Type-c（小板）
147 two switch double 13A square band lamp+USB/Type-c
¥:280.00

AB-L-0197

147二位开关二位13A多功能+USB/Type-c（小板）
147 two switch double 13A MF 3 pin socket+USB/Type-c
¥:280.00

AB-L-0198

147 二位开关带二位15A圆角插座（带指示灯）
147 Tow switch and double 15A round 3 pin socket with neon
¥:230.00

AB-L-0199

147二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 15A square comer socket with neon
¥:216.00

AB-L-0200

147 四孔剃须插座
147 two shaving socket
¥:583.00

AB-L-0201

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 Kitchen switch
¥:315.00

AB-L-0202

147 45A开关+一位开关13A方角插带指示灯（组合厨房开关）
147 Kitchen switch
¥:315.00

AB-L-0203

147 45A开关+一位开关13A方插带灯（厨房开关）
147 Kitchen switch
¥:315.00

AB-L-0204

147 45A双极开关带指示灯
147 type 45A bipolar switch
¥:260.00

AB-L-0205

147 16A二位德式插座
147 Double German socket
¥:190.00

AB-L-0206

147 16A二位法式插座
147 Double French socket
¥:190.00

AB-L-0207

147 16A二位德式插座
147 Double Geman socket
¥:190.00

AB-L-0208

147 16A二位法式插座
147 Double French socket
¥:190.00

AB-L-0209

147型二位16A德式插座+USB/Type-c(小板）
147 Double 16A German socket +USB/Type - c
¥:370.00

AB-L-0210

147型二位16A法式插座+USB/Type-c(小板）
147 Double 16A French socket+ USB/Type-c
¥:370.00

AB-L-0211

147二位16A德式+二位USB（小板连体）
147 double 16A German standard socket +2USB
¥:340.00

AB-L-0212

147二位16A法式+2USB（小板连体）
147 double 16A French socket +2USB
¥:340.00

AB-L-0213

小板147型四位USB插座
147 4 USB socket
¥:450.00

AB-L-0214

147二位多功能插座+4USB(竖)
147 2-bit multi-function socket + 4USB
¥:370.00

AB-L-0215

147二位13A方角插座+4USB(竖)
147 two bit 13A square socket +4USB
¥:370.00

AB-L-0216

147 一位13A方角插座+二位USB
13A square comer socket and Two USB
¥:318.00

AB-L-0217

147 一位16A多功能插座+二位USB插座
13A square comer socket and two USB socket
¥:318.00

AB-L-0218

147型二位开关带二位多功能五孔插座带双USB
147 Tow switch and double 13A 5 pin MF socket+2USB
¥:370.00

AB-L-0219

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two position switch with two position 13A multifunction Five hole socket + 2 USB (with indicator)
¥:480.00

AB-L-0220

147 二位13A多功能五孔插座+四位USB
147 double 5 pin multi-function socket+4USB
¥:370.00

AB-L-0221

147 二位开关二位13A多功能五孔插座+四位USB
147 two switch double 5 pin multi function socket+4USB
¥:390.00

AB-L-0222

147型二位开关带二位多功能五孔插座带USB+type-c
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:480.00

AB-L-0223

147型二位开关带13A多功能+4USB(带指示灯)
147 two switch with double 13A MF+4USB(with indicator light)
¥:430.00

AB-L-0224

147型二开带二位13A方插带四位USB
147 type two switch two position 13A square inserting band 4 USB
¥:430.00

AB-L-0225

147型二位13A方插带四位USB
147 double 13A square inserting +4USB
¥:410.00

AB-L-0226

二位13A多功能带四位USB(带盖板)
147 double 13A multi-function + 4USB(with cover plate)
¥:450.00

AB-L-0227

二位13A方角插座带四位USB(带盖板)
147 double 13A square inserting +4 USB(with cover plate)
¥:450.00

AB-L-0228

147 一开单控开关带多功能五孔插座
147 1 gang 1 way switch with MF 5 pin socket
¥:160.00

AB-L-0229

147 一开单控开关带多功能五孔+双USB
147 1 gang 1 way switch 2 USB with MF 5 pin socket
¥:260.00

AB-L-0230

147型16A多功能+万用五孔插座
147 type 16A MF 3 pin and 5 pin socket
¥:163.00

AB-L-0231

147 四位USB带二位10A二三极插座
147 double 10A 5 pin socket + 4 USB with indicator light
¥:370.00

AB-L-0232

147 二位开关带二位13A多功能+4USB(带指示灯)(竖)
147 two switch with two position 13A 3 pin multi-function socket + 4USB with indicator light
¥:390.00

AB-L-0233

小板147型13A二位方插带4USB带二位小开关
Small board 147 type 13A 2-bit square plug with 4USB with 2-bit small switch
¥:390.00

AB-L-0234

147型二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A German socket+USB/Type-c with neon
¥:470.00

AB-L-0235

147型二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 two switch double 16A French socket+USB/Type-c with neon
¥:470.00

AB-L-0236

147型二位开关二位16A德式插座（带指示灯）
147 two switch double 16A German socket with neon
¥:260.00

AB-L-0237

147型二位开关二位16A法式插座（带指示灯）
147 two switch double 16A French socket with neon
¥:260.00

AB-L-0238

147型二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket with neon + 2usb
¥:370.00

AB-L-0239

147型二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch double 16A French socket with neon + 2USB
¥:370. 00

AB-L-0240

147型二位空白面板
147 Blank plate
¥:114.00

AB-G1

钢化玻璃水晶白
Tempered glass crystal white

设计与房间的良好互动

照明开关清新典雅的设计与房间完美贴合

开关不会淹没在视野之中

其他元素也自然浮现。

Good interaction between design and room

The fresh and elegant design of the lighting switch fits perfectly with the room

The switch will not be submerged in the field of vision

Other elements also naturally emerge.

2.5D玻璃
2.5D glass

强力融合
Plastic base material

塑胶基材
Plastic base material

语音/APP/轻触机械控制
Voice /APP/ touch mechanical control

情景模式/联动/定时
Scenario mode/Linkage/timing

支持多款AL音响
Support a variety of AL audio

涂鸦无线场景开关
(单火零火通用)
Doodle wireless scene switch
(Single fire and zero fire universal)

Zigbee智能按键开关
Zigbee Intelligent button switch

Zigbee一开
¥1150.00

Zigbee二开
¥1250.00

Zigbee三开
¥1350.00

二三极USB/Type-c+开关
¥240.00

联体产品
Conjoined products

二位联体面框
Two-position face frame
塑板/钢板:50.00
Plastic board/Steel plate:50.00

四位联体面框
Four-position face frame
塑板/钢板:90.00
Plastic board/Steel plate:90.00

三位联体面框
Three-position face frame
塑板/钢板:70.00
Plastic board/Steel plate:70.00

五位联体面框
Five-position face frame
塑板/钢板:110.00
Plastic board/Steel plate:110.00

模块颜色 / Module Color

珍珠白
Pearl White

香槟金
Champagne gold

太空灰
Space gray

摩卡黑
Mocha Black

欧珀蓝
Opal blue

AB-G1 Tempered glass crystal white 钢化玻璃水晶白

AB-G1-0001

一位触摸开关(零火线) ¥:400.00
1 gang 1 way touch switch
蓝牙WIFI一位触摸开关(零火版) ¥:500.00
1 gang 1 way touch switch
涂鸦Zigbee一位触摸开关(零火版) ¥:600.00
1 gang 1 way touch switch

AB-G1-0002

二位触摸开关（零火版） ¥:450.00
2 gang 1 way touch switch
蓝牙WIFI二位触摸开关(零火版) ¥:550.00
2 gang 1 way touch switch
涂鸦Zigbee二位触摸开关(零火版) ¥:650.00
2 gang 1 way touch switch

AB-G1-0003

三位触摸开关（零火版） ¥:500.00
3 gang 1 way touch switch
蓝牙WIFI三位触摸开关(零火版) ¥:600.00
3 gang 1 way touch switch
涂鸦Zigbee三位触摸开关(零火版) ¥:700.00
3 gang 1 way touch switch

AB-G1-0004

四位触摸开关（零火版） ¥:550.00
4 gang 1 way touch switch
蓝牙WIFI四位触摸开关(零火版) ¥:650.00
4 gang 1 way touch switch
涂鸦Zigbee四位触摸开关(零火版) ¥:750.00
4 gang 1 way touch switch

AB-G1-0005

大板16A一位开关单控 ¥:86.00
Large panel 16A 1 gang 1 way switch
大板16A一位开关双控 ¥:90.00
Large panel 16A 1 gang 2 way switch
大板16A一位开关多控 ¥:123.00
Large panel 16A 1 gang 3 way switch

AB-G1-0006

大板16A二位开关单控 ¥:109.00
Large panel 16A 2 gang 1 way switch
大板16A二位开关双控 ¥:110.00
Large panel 16A 2 gang 2 way switch
大板16A二位开关多控 ¥:158.00
Large panel 16A 2 gang 3 way switch

AB-G1-0007

大板16A三位开关单控 ¥:139.00
Large panel 16A 3 gang 1 way switch
大板16A三位开关双控 ¥:156.00
Large panel 16A 3 gang 1 way switch

AB-G1-0008

大板16A四位开关单控 ¥:169.00
Large panel 16A 4 gang 1 way switch
大板16A四位开关双控 ¥:183.00
Large panel 16A 4 gang 2 way switch

AB-G1-0009

大板16A百叶窗升降开关
Large panel louver window lifter switch
¥:145.00

AB-G1-0010

大板16A门控开关
Large panel gating switch
¥:109.00

AB-G1-0011

大板16A英式门控开关
Large panel British gating switch
¥:109.00

AB-G1-0012

大板16A门铃开关
Large panel doorbell switch
¥:109.00

AB-G1-0013

大板20A双极开关带指示灯 ¥:168.00
20A bipolar switch with indicator light
大板32A双极开关带指示灯 ¥:186.00
32A bipolar switch with indicator light

AB-G1-0014

大板45A双极开关带指示灯
45A bipolar switch with indicator light
¥:200.00

AB-G1-0015

大板16A三极插座
16A 3 pole socket
¥:109.00

AB-G1-0016

大板16A多功能插座
16A 3 pin universal socket
¥:109.00

AB-G1-0017

大板10A二三极插座
10A 5 pole socket
¥:93.00

AB-G1-0018

大板10A错位二三极插座
10A Two or three pole socket
¥:117.00

AB-G1-0019

大板16A多功能五孔插座
16A MF 5 pin socket
¥:128.00

AB-G1-0020

大板10A二二三极插座
10A 7 pole socket
¥:128.00

AB-G1-0021

大板13A方角插座
13A square corner socket
¥:109.00

AB-G1-0022

大板二位USB带16A多功能五孔插座
2 USB with 5 pin multi-function socket
¥:213.00

AB-G1-0023

大板16A一位开关单控带16A三极插座
1gang1 way swith and 16A 3 pole socket

大板16A一位开关双控带16A三极插座
1gang2 way swith and 16A 3 pole socket
¥:143.00

AB-G1-0024

大板16A一位开关单控带16A三极插座
1gang2 way swith and 16A 3 pole socket
¥:140.00

大板16A一位开关双控带16A三极插座
1gang 2 way switch and 5 pole socket
¥:143.00

AB-G1-0025

大板10A二位开关单控带二三极插座
2 gang 1 way switch and 5 pole socket

大板10A二位开关双控带二三极插座
2 gang 2 way switch and 5 pole socket
¥:167.00

AB-G1-0026

大板一位开关带16A三极多功能插座(带指示灯）
1 gang switch and 16A 3 pin multi-purpose socket with indicator light
¥:146.00

AB-G1-0027

大板一位双极开关带13A方角插座（指示灯）
Large board one position bipolar switch with 13A square angle socket (indicator light)
¥:139.00

AB-G1-0028

大板一位开关带15A圆孔插座(带指示灯）
1 gang weitch and 15A 3 square pin socket with indicator light
¥:146.00

AB-G1-0029

大板一位开关带16A二三极多功能插座(带指示灯）
1 gang swith and 5 pin multi-function socket with indicator light
¥:152.00

AB-G1-0030

大板一位开关带13A多功能插座+二位USB（指示灯）
Large board one position switch with 13A multi-function socket + 2USB (indicator)
¥:295.00

AB-G1-0031

大板一位开关带13A方角插+二位USB（指示灯）
Board one position switch with 13A square angle plug + two position USB (indicator)
¥:295.00

AB-G1-0032

大板16A德式插座
Large board 16A German socket
¥:163.00

AB-G1-0033

大板16A法式插座
Large plate 16A French socket
¥:163.00

AB-G1-0034

大板16A俄式插座
Large board 16A Russian socket
¥:163.00

AB-G1-0035

大板16A德式插座+二位USB
German socket+2 USB
¥:255.00

AB-G1-0036

大板16A法标插座+二位USB
French socket + 2 USB
¥:255.00

AB-G1-0037

大板16A德标插座+USB/Type-c
Large board 16A German socket + USB / type-C
¥:255.00

AB-G1-0038

大板16A法式插座+USB/Type-c
Large board 16A French socket + USB / type-C
¥:255.00

AB-G1-0039

大板一位电视插座
TV socket
¥:128.00

AB-G1-0040

大板一位电话插座 ¥:128.00
telephone socket
大板一位电脑插座 ¥:138.00
computer socket
大板一位电脑插座（超六类） ¥:178.00
computer socket(6)

AB-G1-0041

大板一位电视电话插座 ¥:158.00
TV +telephone socket
大板一位电视电脑插座 ¥:168.00
TV +computer socket
大板一位电视电脑插座（超六类） ¥:208.00
TV +computer socket(6)

AB-G1-0042

大板二位电视插座
Two TV socket
¥:158.00

AB-G1-0043

大板二位电话插座 ¥:158.00
Two TV socket
大板二位电脑插座 ¥:178.00
Two computer socket
大板二位电脑插座（超六类） ¥:258.00
Two computer socket(6)
大板电话+电脑插座 ¥:168.00
telephone+computer socket
大板电话+电脑插座（超六类） ¥:208.00
telephone+computer socket(6)

AB-G1-0044

大板空白面板
Large blank panel
¥:80.00

AB-G1-0045

小板16A一位开关单控 ¥:87.00
16A 1 gang 1 way switch
小板16A一位开关双控 ¥:90.00
16A 1 gang 2 way switch
小板16A一位开关多控 ¥:123.00
16A 1 gang more way switch

AB-G1-0046

小板16A二位开关单控 ¥:109.00
16A 2 gang 1 way switch
小板16A二位开关双控 ¥:110.00
16A 2 gang 2 way switch
小板16A二位开关多控 ¥:158.00
16A 2 gang more way switch

AB-G1-0047

小板16A三位开关单控 ¥:139.00
16A 3 gang 1 way switch
小板16A三位开关双控 ¥:156.00
16A 3 gang 2 way switch

AB-G1-0048

小板16A四位开关单控 ¥:169.00
16A 4 gang 1 way switch
小板16A四位开关双控 ¥:183.00
16A 4 gang 2 way switch

AB-G1-0049

小板16A三位开关多控
16A 3 gang 3 way switch
¥:230.00

AB-G1-0050

小板16A百叶窗升降开关
louver window lifter switch
¥:145.00

AB-G1-0051

小板16A门控开关
gating switch
¥:109.00

AB-G1-0052

小板16A英式门控开关
British gating switch
¥:109.00

AB-G1-0053

小板16A门铃开关
doorbell switch
¥:109.00

AB-G1-0054

小板16A拨动一位开关单控
1 gang 1 way toggle switch
¥:175.00
小板16A拨动一位开关双控
1 gang 2 way toggle switch
¥:180.00

AB-G1-0055

小板16A拨动二位开关单控
2 gang 1 way toggle switch
¥:190.00
小板16A拨动二位开关双控
2 gang 2 way toggle switch
¥:200.00

AB-G1-0056

小板16A拨动三位开关单控
3 gang 1 way toggle switch
¥:205.00
小板16A拨动三位开关双控
3 gang 2 way toggle switch
¥:220.00

AB-G1-0057

小板16A拨动四位开关单控
4 gang 1 way toggle switch
¥:220.00
小板16A拨动四位开关双控
4 gang 2 way toggle switch
¥:240.00

AB-G1-0058

小板20A双极开关带指示灯 ¥:165.00
20A swich with indicator light
小板45A双极开关带指示灯 ¥:185.00
45A swich with indicator light

AB-G1-0059

小板45A双极开关带指示灯
45A swich with indicator light
¥:185.00

AB-G1-0060

小板16A卷帘门复位开关
16A shutter reset switch
¥:195.00

AB-G1 Tempered glass crystal white 钢化玻璃水晶白

AB-G1-0061
小板16A德式插座
German socket
¥:146.00

AB-G1-0062
小板16A法式插座
French socket
¥:146.00

AB-G1-0063
小板16A俄式插座
Russian socket
¥:146.00

AB-G1-0064
小板16A以色列插座
Israel socket
¥:165.00

AB-G1-0065
小板16A意大利+德式插座
Italy+German socket
¥:165.00



AB-G1-0066
小板10A二极插座
10A 2 pole socket
¥:126.00



AB-G1-0067
小板10A二二极插座
10A Double 2 pole socket
¥:139.00



AB-G1-0068
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:139.00



AB-G1-0069
小板10A一位开关带二二极座
1 gang switch and 4 pole socket
¥:146.00

AB-G1-0070
小板16A多功能三极插座
16A MF 3 pin socket
¥:109.00

AB-G1-0071
小板13A二三极多功能插座
5 pin multi-function socket
¥:128.00

AB-G1-0072
小板13A错位多五孔插座
Dislocation multi 5 pin multi function socket
¥:128.00

AB-G1-0073
小板13A方角插座
13A square corner socket
¥:109.00

AB-G1-0074
小板15A圆角插座
15A 3 round pins socket
¥:128.00



AB-G1-0075
小板15A美标扁三极插座
15A triode flat American 3 pin universal socket
¥:128.00

AB-G1-0076
小板15A泰式插座
15A Thai socket
¥:128.00



AB-G1-0077
小板15A泰式六孔插座
Small plate 15A Thai six hole socket
¥:138.00



AB-G1-0078
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:136.00



AB-G1-0079
小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pin socket
¥:143.00

AB-G1-0080
小板一位开关带16A多功能插座
1 gang switch and 3 pin MF socket
¥:143.00



AB-G1-0081
小板一位开关带13A方角插座(带指示灯)
1 gang switch and 13A square pin socket withindicator light
¥:139.00

AB-G1-0082
小板一位开关带15A圆孔插座(带指示灯)
1 gang switch and 15A 3 round pins socket with indicator light
¥:146.00

AB-G1-0083
小板一位开关带16A多功能插座（带指示灯）
1 gang switch and 16A MF 3 pin socket with light
¥:146.00



AB-G1-0084
小板一位开关带13A多功能五孔插座(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
¥:152.00

AB-G1-0085
小板16A德式插座带二位USB
2 USB witch German socket
¥:225.00

AB-G1-0086
小板16A法式插座带二位USB
2 USB witch French socket
¥:225.00

AB-G1-0087
小板16A德式插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:225.00

AB-G1-0088
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:225.00



AB-G1-0089
小板16A一位开关带德式插座
1 gang German socket
¥:165.00

AB-G1-0090
小板16A一位开关带法式插座
1 gang French socket
¥:165.00

AB-G1-0091
小板16A德式插座带防水
German socket and Waterproof belt
¥:155.00

AB-G1-0092
小板16A法式插座带防水
French socket and Waterproof belt
¥:155.00

AB-G1-0093
小板二位USB带13A方角插座（横）
2 USB with 13A square corner socket with swith
¥:225.00

AB-G1-0094
小板15A美式+USB/type-c
15A American Standard + USB / type-C
¥:225.00

AB-G1-0095
小板15A泰式+USB/Type-c
15A Thai + USB / type-C
¥:225.00

AB-G1-0096
小板二位USB带13A方角插座（带保护门）
2 USB with 13A square corner socket with flip cover
¥:225.00



AB-G1-0097
小板二位USB带13A多功能插座（带保护门）
2 USB with 3 pin multi-purpose socket with flip cover
¥:225.00



AB-G1-0098
小板一位开关13A多功能插座带指示灯+二位USB
2 USB with 13A aquare corner socket with flip cover
¥:225.00



AB-G1-0099
小板一位开关13A方角插座带指示灯+二位USB
Small board one position switch 13A square corner socket with indicator light + two position USB
¥:225.00

AB-G1-0100
小板13A多功能带Type-c+USB
13A multifunction with type-C + USB
¥:225.00

AB-G1-0101
小板13A方角插带Type-c+USB
13A square angle band type-C + USB
¥:225.00

AB-G1-0102
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with Type-c+USB(with light)
¥:225.00

AB-G1-0103
小板二位USB带13A多功能插座带小开关（竖）
2 USB with Three very multi-purpose socket with switch
¥:235.00

AB-G1-0104
小板一位开关13A方插带Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:225.00

AB-G1-0105
小板二位USB带13A方角插座带小开关（竖）
2 USB with 13A square corner socket with swith
¥:235.00

AB-G1-0106
小板15A美式扁插+二位USB插座
15A American Standard + 2USB
¥:225.00

AB-G1-0107
小板15A泰式+二位USB插座
15A Thai + 2USB
¥:225.00



AB-G1-0108
小板二位USB带13A多功能插座（横）
2 USB with 3 pin multi-purpose socket
¥:225.00



AB-G1-0109
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:185.00

AB-G1-0110
小板二位USB带10A二三极插座带开关
2 USB and 5 pin socket with switch
¥:195.00

AB-G1-0111
小板10五孔插座带USB +Type-c (10W)
10A 5 pole socket with USB type-C(10W)
¥:185.00
小板10五孔插座带USB +Type-C(18W)
10A 5 pole socket with USB type-C(18W)
¥:290.00

AB-G1-0112
小板一位开关带13A多功能五孔插座带USB
1 gang swich and 5 pin multi-function socket with USB and indicator light
¥:230.00

AB-G1-0113
小板13A二三极多功能插座+二位USB
Small board 13A two three pole multi function socket + 2-bit USB
¥:180.00

AB-G1-0114
小板13A二三极多功能插座+二位USB带小开关
Small board 13A two three pole multi-function socket + 2-bit USB With small switch
¥:190.00

AB-G1-0115
小板13A多功能五孔带USB+Type-C(10W)
13A MF 5 pin socket USB+type-C(10W)
¥:180.00
小板13A多功能五孔带USB+Type-C(18W)
13A MF 5 pin socket USB+type-C(18W)
¥:290.00

AB-G1-0116
小板一位电视插座
TV socket
¥:128.00

AB-G1-0117
小板一位电话插座 ¥:128.00
telephone socket
小板一位电脑插座 ¥:138.00
computer socket
小板一位电脑插座(超六类) ¥:178.00
computer socket(6)

AB-G1-0118
小板双电视插座
Two TV socket
¥:158.00

AB-G1-0119
小板双电话插座 ¥:158.00
Two telephone socket
小板双电脑插座 ¥:178.00
Two computer socket
小板双电脑插座(超六类) ¥:258.00
Two computer socket(6)
小板电话电脑插座 ¥:168.00
telephone+computer socket
小板电话电脑插座(超六类) ¥:208.00
telephone+computer socket(6)

AB-G1-0120
小板电视电话插座 ¥:158.00
TV +telephone socket
小板电视电脑插座 ¥:168.00
TV +computer socket
小板电视电脑插座(超六类) ¥:208.00
TV +computer socket(6)

AB-G1 Tempered glass crystal white 钢化玻璃水晶白

AB-G1-0121

小板一位电话带USB插座 ¥:280.00
TEL+USB socket
小板一位电脑带USB插座 ¥:290.00
computer+USB socket
小板一位电脑带USB插座(超六类) ¥:330.00
computer+USB socket(6)

AB-G1-0122

小板一位TV+FM
TV and FM
¥:198.00

AB-G1-0123

小板一位卫星插座
Satellite socket
¥:148.00

AB-G1-0124

小板二位卫星插座
Double satellite socket
¥:175.00

AB-G1-0125

小板卫星+电视插座
Satellite and TV socket
¥:166.00

AB-G1-0126

小板卫星带电话插座 ¥:166.00
Satellite and telephone socket
小板卫星带电脑插座 ¥:175.00
Satellite and computer socket
小板卫星带电脑插座(超六类) ¥:215.00
Satellite and computer socket(6)

AB-G1-0127

小板二极插座带电视插座
2 pin socket with TV
¥:290.00

AB-G1-0128

小板二极插座带电话插座 ¥:290.00
2 pin socket with telephone
小板二极插座带电脑插座 ¥:290.00
2 pin socket with computer
小板二极插座带电脑插座(超六类) ¥:330.00
2 pin socket with computer

AB-G1-0129

小板一位光纤插座
Optical fiber socket
¥:190.00

AB-G1-0130

小板二位USB插座
Double USB socket
¥:230.00

AB-G1-0131

小板单联音响插座
Single audio socket
¥:202.00

AB-G1-0132

小板双联音响插座
Double audio socket
¥:275.00

AB-G1-0133

触摸延时开关（节能）
Touch delay delay switch
¥:202.00

AB-G1-0134

声光控延时开关（节能）
Sound-light controlled delay switch (energy saving)
¥:202.00

AB-G1-0135

红外线人体感应开关
Human body induction
¥:220.00

AB-G1-0136

凹型地脚灯（亮光/暖光）
The footlights
¥:195.00

AB-G1-0137

凹型红外线人体感应地脚灯
（亮光/暖光）
The human body induction footlights
¥:330.00

AB-G1-0138

平面地脚灯（亮光/暖光）
footlights
¥:195.00

AB-G1-0139

叮咚门铃
Ding dong doorbell
¥:245.00

AB-G1-0140

机械式40A插卡取电 ¥:280.00
Mechanical card for electricity
感应式低频40A插卡取电 ¥:400.00
Low frequency induction card
感应式高频40A插卡取电 ¥:460.00
High freqency induction card for electrcity

AB-G1-0141

紧急呼叫开关
Emergency call seitch
¥:210.00

AB-G1-0142

请勿打扰请即清理门铃开关
（按键式）
Do not disturb plese namely cleaning please+late doorbell "button"
¥:250.00

AB-G1-0143

请勿打扰门铃开关(按键式)
Do not disturb+doorbell "button"
¥:385.00

AB-G1-0144

请勿打扰请即清理门铃开关
(按键式)
Do not disturb plese namely cleaning please "button"
¥:475.00

AB-G1-0145

智能音乐控制开关
intelligent music cintrol seitch
¥:2950.00

AB-G1-0146

温度控制调节开关
Temperature control seitch
¥:800.00

AB-G1-0147

温度控制调节开关
Tuning switchcontrol seitch
¥:850.00

AB-G1-0148

调音开关
Tuning switch
¥:260.00

AB-G1-0149

调光开关300W ¥:198.00
Dimming 300W
调光开关600W ¥:225.00
Dimming 600W
调光开关1000W ¥:252.00
Dimming 1000W

AB-G1-0150

调速开关300W ¥:198.00
Speed 300W
调速开关600W ¥:225.00
Speed 600W
调速开关1000W ¥:252.00
Speed 1000W

AB-G1-0151

一位开关带调光开关500W
1 gang with dimmer switch
¥:212.00

AB-G1-0152

一位开关带调速开关500W
1 gang with speed switch
¥:212.00

AB-G1-0153

13A开关带保险丝（带指示灯）
13A switch with fuse with neon
¥:239.00

AB-G1-0154

小板20A出线柱
20A outgoing post
¥:221.00

AB-G1-0155

剃须插座
Shaving socket
¥:450.00

AB-G1-0156

USB+电脑插座+无线路由
USB+computer socket wireless router
¥:800.00

AB-G1-0157

蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio+3.5+2USB+HDMI
¥:5250.00

AB-G1-0158

HDMI
¥:288.00

AB-G1-0159

USB+Type-c
¥:324.00

AB-G1-0160

HDMI+USB
¥:288.00

AB-G1-0161

HDMI+USB+3.5音频
HDMI+USB+3.5
¥:288.00

AB-G1-0162

VGA+USB+3.5音频
VGA+USB+3.5
¥:288.00



AB-G1-0163

AV+3.5音频
AV +3.5
¥:288.00

AB-G1-0164

VGA+AV音频接口
VGA+AV audio interface
¥:288.00

AB-G1-0165

HDMI+AV音频接口
HDMI+AV audio interface
¥:288.00

AB-G1-0166

二分之一AV音频+卫星
Half AV audio interface+Satellite
¥:288.00

AB-G1-0167

二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:288.00

AB-G1-0168

二分之一VGA+TV
Half VGA+TV
¥:288.00

AB-G1-0169

二分之一VGA+电脑
Half VGA+Computer
¥:288.00

AB-G1-0170

二分之一VGA+USB
Half VGA+USB
¥:288.00

AB-G1-0171

二分之一VGA+HDMI
Half VGA+HDIM
¥:288.00

AB-G1-0172

45A出线柱
45A Outlet
¥:248.00



AB-G1-0173

空白面板
Blank plate
¥:102.00

AB-G1-0174

大板二位双极开关带二位13A方角插座（指示灯）
Large board two position bipolar switch with two position 13A square angle Socket (indicator)
¥:258.00



AB-G1-0175

大板二位开关带二位16A多功能插座（带指示灯）
147 Tow switch and double 16A MF 3pin socket with light
¥:258.00

AB-G1-0176

147 二位开关带二位13A方角插座带二位USB（带指示灯）
147 Tow switch and double 13A square comer socker with two USB and indicator light
¥:358.00

AB-G1-0177

大板二位开关带二位16A多功能插座+双USB（带指示灯）
147 Tow switch and double 16A MF socket + 2USB with light
¥:358.00

AB-G1-0178

大板147型二位开关带二位13A方插+USB/Type-c(指示灯)
Large board 147 two position switch with two position 13A square plug +USB / type-C (indicator)
¥:388.00

AB-G1-0179

大板147型二位开关带二位13A多功能+USB/Type-c(指示灯)
Large plate 147 two position switch with two position 13A multifunction +USB / type-C (indicator)
¥:388.00

AB-G1-0180

147型45A双极开关+一开13A方角插带灯(炉具开关)
147 type 45A bipolar switch + 13A square angle plug With light (stove switch)
¥:310.00

AB-G1 Tempered glass crystal white 钢化玻璃水晶白

AB-G1-0181

147型45A双极开关带指示灯
147 type 45A bipolar switch with indicator light
¥:280.00

AB-G1-0182

147型空白面板
147 blank panel
¥:185.00

AB-G1-0183
小板147型16A二位开关单控
Small plate 147 type 16A two position switch single control
¥:212.00
小板147型16A二位开关双控
Small plate 147 type 16A two position switch double control
¥:218.00

AB-G1-0184
小板147型16A三位开关单控
Small plate 147 type 16A 3 gang 2 way switch
¥:230.00
小板147型16A三位开关双控
Small plate 147 type 16A 3 gang 2 way switch
¥:239.00

AB-G1-0185
小板147型16A四位开关单控
Small plate 147 type 16A 4 gang 1 way switch
¥:248.00
小板147型16A四位开关双控
Small plate 147 type 16A 4 gang 1 way switch
¥:259.00

AB-G1-0186
小板147型16A五位开关单控
Small plate 147 type 16A 5 gang 1 way switch
¥:266.00
小板147型16A五位开关双控
Small plate 147 type 16A 5 gang 2 way switch
¥:280.00

AB-G1-0187
小板147型16A六位开关单控
Small plate 147 type 16A 6 gang 1 way switch
¥:280.00
小板147型16A六位开关双控
Small plate 147 type 16A 6 gang 2 way switch
¥:301.00

AB-G1-0188
小板147型16A七位开关单控
Small plate 147 type 16A 7 gang 1 way switch
¥:302.00
小板147型16A七位开关双控
Small plate 147 type 16A 7 gang 2 way switch
¥:321.00

AB-G1-0189
小板147型16A八位开关单控
Small plate 147 type 16A 8 gang 1 way switch
¥:320.00
小板147型16A八位开关双控
1Small plate 147 type 16A 8 gang 2 way switch
¥:342.00

AB-G1-0190

147 二位16A多功能三极插座
147 Double 13A MF 3 pin socket
¥:248.00

AB-G1-0191

147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:281.00



AB-G1-0192

小板147型二位15A美标扁插座
Small plate 147 two position 15A American standard flat socket
¥:279.00

AB-G1-0193

147 二位15A泰式多功能六孔插座
147 Double 15A Thai MF six-hole socket
¥:279.00



AB-G1-0194

147 二位13A方角插座
147 Double 13A square comer
¥:248.00



AB-G1-0195

147 二位15A圆孔插座
147 Double 15A 3 round pins socket
¥:279.00

AB-G1-0196

小板147型二位13A错位多功能二三极插座
147 type Double 13A dislocation MF 5 pole socket
¥:299.00

AB-G1-0197

147型小板二位10A二三极插座
147 type Double 10A two and three pole socket
¥:225.00

AB-G1-0198

147 二位开关带二位13A方角插座
147 Tow switch and double 13A square comer socket
¥:257.00

AB-G1-0199

147 二位开关带二位13A多功能插座
147 Tow switch and double 13A MF 3 pin socket with light
¥:257.00



AB-G1-0200

小板147二位开关二位13A多功能二三极插座
Small board 147 two position switch two position 13A multi-function two three pole socket
¥:284.00



AB-G1-0201

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 13A square comer socket with indicator light
¥:258.00

AB-G1-0202

147 二位开关带二位13A多功能插座（带指示灯）
147 Tow switch and double 13A MF socket with light
¥:258.00



AB-G1-0203

147 二位开关带二位13A方角插座带二位USB
147 Tow switch and double 13A square comer socket with 2USB
¥:358.00

AB-G1-0204

147 二位开关带二位13A多功能带二位USB
147 Tow switch and double 13A MF socket+2USB
¥:358.00



AB-G1-0205

147二位开关二位13A方插+USB/Type-c（小板）
147 two switch Double 13A square plug+ USB/type-C
¥:358.00

AB-G1-0206

147二位开关二位13A多功能+USB/Type-c（小板）
147 two switch Double 13A MF+USB / type-C
¥:358.00



AB-G1-0207

147 二位开关带二位15A圆角插座（带指示灯）
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:293.00



AB-G1-0208

147 二位开关带二位13A方角插座（带指示灯）
147 two switch and double 13A square Angle socket (with neon)
¥:293.00

AB-G1-0209

147 四孔剃须插座
147 two shaving socket
¥:612.00



AB-G1-0210

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 kitchen switch
¥:346.00

AB-G1-0211

147 45A开关+一位开关13A方角插带指示灯(组合厨房开关)
147 kitchen switch
¥:346.00

AB-G1-0212

147型45A双极开关+一开13A方角插带灯（炉具开关）
147 type 45A bipolar switch +13A square angle plug With light (stove switch)
¥:374.00

AB-G1-0213

147型45A双极开关带指示灯
147 type 45A bipolar switch with indicator light
¥:324.00

AB-G1-0214

147 16A二位德式插座
147 Double Geman socket
¥:293.00



AB-G1-0215

147 16A二位法式插座
147 Double French socket
¥:293.00

AB-G1-0216

小板147型连体二位德标插座
Small plate 147 connected two position German standard socket
¥:293.00

AB-G1-0217

小板147型连体二位法标插座
Small plate 147 connected two position normal socket
¥:293.00

AB-G1-0218

147二位16A德式插座+USB/Type-c(小板）
147 double 16A German with USB/Type-c
¥:390.00

AB-G1-0219

147二位16A法式插座+USB/Type-c(小板）
147 double 16A French with USB/Type-c
¥:390.00

AB-G1-0220

小板147型二位16A德式+二位USB
147 double 16A German+2USB
¥:369.00

AB-G1-0221

小板147型二位16A德式+二位USB
147 Double 16A German+2USB
¥:369.00

AB-G1-0222

147 四位USB插座
147 4 USB socket
¥:477.00

AB-G1-0223

147 二位多功能插座+4USB
147 2-bit multi-function socket + 4USB
¥:414.00

AB-G1-0224

147 二位13A方角插座+4USB
147 two bit 13A square socket +4USB
¥:414.00



AB-G1-0225

小板147型13A方角插座+二位USB
Small board 147 type 13A square corner socket + 2USB
¥:376.00

AB-G1-0226

147 一位16A多功能插座+二位USB插座
147 13A MF 3 pin socket + 2USB socket
¥:376.00

AB-G1-0227

147型二位开关带二位13A多功能五孔+双USB
147 two switch and double 13A MF 5 pin + 2USB
¥:374.00



AB-G1-0228

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two position switch with two position 13A multifunction Five hole socket + 2 USB (with indicator)
¥:522.00

AB-G1-0229

147 二位13A多功能五孔插座+四位USB
147 double 5 pin multi-function socket+4USB
¥:414.00



AB-G1-0230

147型二位13A多功能五孔带4USB+小开关(带指示灯)
147 double 13A MF 5 pin with 4USB+ small switch (w/neon)
¥:432.00

AB-G1-0231

小板147型二位开关二位13A多功能五孔+USB/Type-c
147 two switch and double 13A MF 5 pin + USB / type-C
¥:495.00

AB-G1-0232

小板147型二位开关带二位13A多功能插座+4USB带指示灯
147 two switch and double 13A MF + 4USB (with neon)
¥:432.00



AB-G1-0233

小板147型二位开关带二位13A方角插座+4USB带指示灯
147 two switch and double 13A square Angle Socket +4USB (with neon)
¥:432.00

AB-G1-0234

147型二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 two switch double German socket +USB/Type-c (with neon)
¥:495.00



AB-G1-0235

147型二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 two switch double French socket +USB/Type-c (with neon)
¥:495.00

AB-G1-0236

147型二位开关二位16A德式插座（带指示灯）
147 two switch double German socket (with neon)
¥:329.00



AB-G1-0237

147型二位开关二位16A德式插座（带指示灯）
147 two switch double French socket (with neon)
¥:329.00

AB-G1-0238

147型二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket with neon+ 2USB
¥:405.00

AB-G1-0239

147型二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch with double 16A French socket with 2USB (with neon)
¥:405.00

AB-G1-0240

小板147型空白面板
147 Blank plate
¥:167.00

ZIGBEE智能按键开关

ZIGBEE Intelligent button switch

Zigbee一开
￥1150.00

Zigbee二开
￥1250.00

Zigbee三开
￥1350.00

二三极USB/Type-c+开关
￥240.00

语音/APP/轻触机械控制	情景模式/联动/定时	支持多款AL音响	涂鸦无线场景开关 (单火零火通用)
Voice /APP/ touch mechanical control	Scenario mode/Linkage/timing	Support a variety of AL audio	Doodle wireless scene switch (Single fire and zero fire universal)

AB-G2

钢化玻璃香槟金

Tempered glass champagne gold

AB-G2 Tempered glass champagne gold 钢化玻璃香槟金

AB-G2-0001

一位触摸开关(零火线) ￥:400.00
1 gang 1 way touch switch
蓝牙WIFI一位触摸开关(零火版) ￥:500.00
1 gang 1 way touch switch
涂鸦Zigbee一位触摸开关(零火版) ￥:600.00
1 gang 1 way touch switch

AB-G2-0002

二位触摸开关（零火版） ￥:450.00
2 gang 1 way touch switch
蓝牙WIFI二位触摸开关(零火版) ￥:550.00
2 gang 1 way touch switch
涂鸦Zigbee二位触摸开关(零火版) ￥:650.00
2 gang 1 way touch switch

AB-G2-0003

三位触摸开关（零火版） ￥:500.00
3 gang 1 way touch switch
蓝牙WIFI三位触摸开关(零火版) ￥:600.00
3 gang 1 way touch switch
涂鸦Zigbee三位触摸开关(零火版) ￥:700.00
3 gang 1 way touch switch

AB-G2-0004

四位触摸开关（零火版） ￥:550.00
4 gang 1 way touch switch
蓝牙WIFI四位触摸开关(零火版) ￥:650.00
4 gang 1 way touch switch
涂鸦Zigbee四位触摸开关(零火版) ￥:750.00
4 gang 1 way touch switch

AB-G2-0005

大板16A一位开关单控 ￥:86.00
Large panel 16A 1 gang 1 way switch
大板16A一位开关双控 ￥:90.00
Large panel 16A 1 gang 2 way switch
大板16A一位开关多控 ￥:123.00
Large panel 16A 1 gang 3 way switch

AB-G2-0006

大板16A二位开关单控 ￥:109.00
Large panel 16A 2 gang 1 way switch
大板16A二位开关双控 ￥:110.00
Large panel 16A 2 gang 2 way switch
大板16A二位开关多控 ￥:158.00
Large panel 16A 2 gang 3 way switch

AB-G2-0007

大板16A三位开关单控 ￥:139.00
Large panel 16A 3 gang 1 way switch
大板16A三位开关双控 ￥:156.00
Large panel 16A 3 gang 1 way switch

AB-G2-0008

大板16A四位开关单控 ￥:169.00
Large panel 16A 4 gang 1 way switch
大板16A四位开关双控 ￥:183.00
Large panel 16A 4 gang 2 way switch

AB-G2-0009

大板16A百叶窗升降开关
Large panel louver window lifter switch
￥:145.00

AB-G2-0010

大板16A门控开关
Large panel gating switch
￥:109.00

AB-G2-0011

大板16A英式门控开关
Large panel British gating switch
￥:109.00

AB-G2-0012

大板16A门铃开关
Large panel doorbell switch
￥:109.00

AB-G2-0013

大板20A双极开关带指示灯 ￥:168.00
20A bipolar switch with indicator light
大板32A双极开关带指示灯 ￥:186.00
32A bipolar switch with indicator light

AB-G2-0014

大板45A双极开关带指示灯
45A bipolar switch with indicator light
￥:200.00

AB-G2-0015

大板16A三极插座
16A 3 pole socket
￥:109.00

AB-G2-0016

大板16A多功能插座
16A 3 pin universal socket
￥:109.00

AB-G2-0017

大板10A二三极插座
10A 5 pole socket
￥:93.00

AB-G2-0018

大板10A错位二三极插座
10A Two or three pole socket
￥:117.00

AB-G2-0019

大板16A多功能五孔插座
16A MF 5 pin socket
￥:128.00

AB-G2-0020

大板10A二二三极插座
10A 7 pole socket
￥:128.00

AB-G2-0021

大板13A方角插座
13A square corner socket
￥:109.00

AB-G2-0022

大板二位USB带16A多功能五孔插座
2 USB with 5 pin multi-function socket
￥:213.00

AB-G2-0023

大板16A一位开关单控带16A三极插座
1gang1 way swith and 16A 3 pole socket

大板16A一位开关双控带16A三极插座
1gang2 way swith and 16A 3 pole socket
￥:143.00

AB-G2-0024

大板16A一位开关单控带16A三极插座
1gang2 way swith and 16A 3 pole socket
￥:140.00

大板16A一位开关双控带16A三极插座
1gang 2 way switch and 5 pole socket
￥:143.00

AB-G2-0025

大板10A二位开关单控带二三极插座
2 gang 1 way switch and 5 pole socket

大板10A二位开关双控带二三极插座
2 gang 2 way switch and 5 pole socket
￥:167.00

AB-G2-0026

大板一位开关带16A三极多功能插座(带指示灯）
1 gang switch and 16A 3 pin multi-purpose socket with indicator light
￥:146.00

AB-G2-0027

大板一位双极开关带13A方角插座（指示灯）
Large board one position bipolar switch with 13A square angle socket (indicator light)
￥:139.00

AB-G2-0028

大板一位开关带15A圆孔插座(带指示灯）
1 gang weitch and 15A 3 square pin socket with indicator light
￥:146.00

AB-G2-0029

大板一位开关带16A二三极多功能插座(带指示灯）
1 gang swith and 5 pin multi-function socket with indicator light
￥:152.00

AB-G2-0030

大板一位开关带13A多功能插座+二位USB（指示灯）
Large board one position switch with 13A multi-function socket + 2USB (indicator)
￥:295.00

AB-G2-0031

大板一位开关带13A方角插+二位USB（指示灯）
Board one position switch with 13A square angle plug + two position USB (indicator)
￥:295.00

AB-G2-0032

大板16A德式插座
Large board 16A German socket
￥:163.00

AB-G2-0033

大板16A法式插座
Large plate 16A French socket
￥:163.00

AB-G2-0034

大板16A俄式插座
Large board 16A Russian socket
￥:163.00

AB-G2-0035

大板16A德式插座+二位USB
German socket+2 USB
￥:255.00

AB-G2-0036

大板16A法标插座+二位USB
French socket + 2 USB
￥:255.00

AB-G2-0037

大板16A德标插座+USB/Type-c
Large board 16A German socket + USB / type-C
￥:255.00

AB-G2-0038

大板16A法式插座+USB/Type-c
Large board 16A French socket + USB / type-C
￥:255.00

AB-G2-0039

大板一位电视插座
TV socket
￥:128.00

AB-G2-0040

大板一位电话插座 ￥:128.00
telephone socket
大板一位电脑插座 ￥:138.00
computer socket
大板一位电脑插座（超六类） ￥:178.00
computer socket(6)

AB-G2-0041

大板一位电视电话插座 ￥:158.00
TV +telephone socket
大板一位电视电脑插座 ￥:168.00
TV +computer socket
大板一位电视电脑插座（超六类） ￥:208.00
TV +computer socket(6)

AB-G2-0042

大板二位电视插座
Two TV socket
￥:158.00

AB-G2-0043

大板二位电话插座 ￥:158.00
Two TV socket
大板二位电脑插座 ￥:178.00
Two computer socket
大板二位电脑插座（超六类） ￥:258.00
Two computer socket(6)
大板电话+电脑插座 ￥:168.00
telephone+computer socket
大板电话+电脑插座（超六类） ￥:208.00
telephone+computer socket(6)

AB-G2-0044

大板空白面板
Large blank panel
￥:80.00

AB-G2-0045

小板16A一位开关单控 ￥:87.00
16A 1 gang 1 way switch
小板16A一位开关双控 ￥:90.00
16A 1 gang 2 way switch
小板16A一位开关多控 ￥:123.00
16A 1 gang more way switch

AB-G2-0046

小板16A二位开关单控 ￥:109.00
16A 2 gang 1 way switch
小板16A二位开关双控 ￥:110.00
16A 2 gang 2 way switch
小板16A二位开关多控 ￥:158.00
16A 2 gang more way switch

AB-G2-0047

小板16A三位开关单控 ￥:139.00
16A 3 gang 1 way switch
小板16A三位开关双控 ￥:156.00
16A 3 gang 2 way switch

AB-G2-0048

小板16A四位开关单控 ￥:169.00
16A 4 gang 1 way switch
小板16A四位开关双控 ￥:183.00
16A 4 gang 2 way switch

AB-G2-0049

小板16A三位开关多控
16A 3 gang 3 way switch
￥:230.00

AB-G2-0050

小板16A百叶窗升降开关
louver window lifter switch
￥:145.00

AB-G2-0051

小板16A门控开关
gating switch
￥:109.00

AB-G2-0052

小板16A英式门控开关
British gating switch
￥:109.00

AB-G2-0053

小板16A门铃开关
doorbell switch
￥:109.00

AB-G2-0054

小板16A拨动一位开关单控
1 gang 1 way toggle switch
￥:175.00
小板16A拨动一位开关双控
1 gang 2 way toggle switch
￥:180.00

AB-G2-0055

小板16A拨动二位开关单控
2 gang 1 way toggle switch
￥:190.00
小板16A拨动二位开关双控
2 gang 2 way toggle switch
￥:200.00



AB-G2-0056

小板16A拨动三位开关单控
3 gang 1 way toggle switch
￥:205.00
小板16A拨动三位开关双控
3 gang 2 way toggle switch
￥:220.00

AB-G2-0057

小板16A拨动四位开关单控
4 gang 1 way toggle switch
￥:220.00
小板16A拨动四位开关双控
4 gang 2 way toggle switch
￥:240.00

AB-G2-0058

小板20A双极开关带指示灯 ￥:165.00
20A swich with indicator light
小板45A双极开关带指示灯 ￥:185.00
45A swich with indicator light

AB-G2-0059

小板45A双极开关带指示灯
45A swich with indicator light
￥:185.00

AB-G2-0060

小板16A卷帘门复位开关
16A shutter reset switch
￥:195.00

AB-G2 Tempered glass champagne gold 钢化玻璃香槟金

AB-G2-0061
小板16A德式插座
German socket
¥:146.00

AB-G2-0062
小板16A法式插座
French socket
¥:146.00

AB-G2-0063
小板16A俄式插座
Russian socket
¥:146.00

AB-G2-0064
小板16A以色列插座
Israel socket
¥:165.00

AB-G2-0065
小板16A意大利+德式插座
Italy+German socket
¥:165.00



AB-G2-0066
小板10A二极插座
10A 2 pole socket
¥:126.00



AB-G2-0067
小板10A二二极插座
10A Double 2 pole socket
¥:139.00

AB-G2-0068
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:139.00

AB-G2-0069
小板10A一位开关带二二极座
1 gang switch and 4 pole socket
¥:146.00

AB-G2-0070
小板16A多功能三极插座
16A MF 3 pin socket
¥:109.00

AB-G2-0071
小板13A二三极多功能插座
5 pin multi-function socket
¥:128.00

AB-G2-0072
小板13A错位多五孔插座
Dislocation multi 5 pin multi function socket
¥:128.00

AB-G2-0073
小板13A方角插座
13A square corner socket
¥:109.00

AB-G2-0074
小板15A圆角插座
15A 3 round pins socket
¥:128.00

AB-G2-0075
小板15A美标扁三极插座
15A triode flat American 3 pin universal socket
¥:128.00

AB-G2-0076
小板15A泰式插座
15A Thai socket
¥:128.00

AB-G2-0077
小板15A泰式六孔插座
Small plate 15A Thai six hole socket
¥:138.00

AB-G2-0078
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:136.00

AB-G2-0079
小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pin socket
¥:143.00

AB-G2-0080
小板一位开关带16A多功能插座
1 gang switch and 3 pin MF socket
¥:143.00

AB-G2-0081
小板一位开关带13A方角插座(带指示灯)
1 gang switch and 13A square pin socket withindicator light
¥:139.00

AB-G2-0082
小板一位开关带15A圆孔插座(带指示灯)
1 gang switch and 15A 3 round pins socket with indicator light
¥:146.00

AB-G2-0083
小板一位开关带16A多功能插座（带指示灯）
1 gang switch and 16A MF 3 pin socket with light
¥:146.00

AB-G2-0084
小板一位开关带13A多功能五孔插座(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
¥:152.00

AB-G2-0085
小板16A德式插座带二位USB
2 USB witch German socket
¥:225.00

AB-G2-0086
小板16A法式插座带二位USB
2 USB witch French socket
¥:225.00

AB-G2-0087
小板16A德式插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:225.00

AB-G2-0088
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:225.00

AB-G2-0089
小板16A一位开关带德式插座
1 gang German socket
¥:165.00

AB-G2-0090
小板16A一位开关带法式插座
1 gang French socket
¥:165.00

AB-G2-0091
小板16A德式插座带防水
German socket and Waterproof belt
¥:155.00

AB-G2-0092
小板16A法式插座带防水
French socket and Waterproof belt
¥:155.00

AB-G2-0093
小板二位USB带13A方角插座（横）
2 USB with 13A square corner socket with swith
¥:225.00

AB-G2-0094
小板15A美式+USB/type-c
15A American Standard + USB / type-C
¥:225.00

AB-G2-0095
小板15A泰式+USB/Type-c
15A Thai + USB / type-C
¥:225.00

AB-G2-0096
小板二位USB带13A方角插座（带保护门）
2 USB with 13A square corner socket with flip cover
¥:225.00

AB-G2-0097
小板二位USB带13A多功能插座（带保护门）
2 USB with 3 pin multi-purpose socket with flip cover
¥:225.00

AB-G2-0098
小板一位开关13A多功能插座带指示灯+二位USB
2 USB with 13A aquare comer socket with flip cover
¥:225.00

AB-G2-0099
小板一位开关13A方角插座带指示灯+二位USB
Small board one position switch 13A square corner socket with indicator light + two position USB
¥:225.00

AB-G2-0100
小板13A多功能带Type-c+USB
13A multifunction with type-C + USB
¥:225.00

AB-G2-0101
小板13A方角插带Type-c+USB
13A square angle band type-C + USB
¥:225.00

AB-G2-0102
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with Type-c+USB(with light)
¥:225.00

AB-G2-0103
小板二位USB带13A多功能插座带小开关（竖）
2 USB with Three very multi-purpose socket with switch
¥:235.00

AB-G2-0104
小板一位开关13A方插带Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:225.00

AB-G2-0105
小板二位USB带13A方角插座带小开关（竖）
2 USB with 13A square corner socket with swith
¥:235.00

AB-G2-0106
小板15A美式扁插+二位USB插座
15A American Standard + 2USB
¥:225.00

AB-G2-0107
小板15A泰式+二位USB插座
15A Thai + 2USB
¥:225.00

AB-G2-0108
小板二位USB带13A多功能插座（横）
2 USB with 3 pin multi-purpose socket
¥:225.00

AB-G2-0109
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:185.00

AB-G2-0110
小板二位USB带10A二三极插座带开关
2 USB and 5 pin socket with switch
¥:195.00

AB-G2-0111
小板10五孔插座带USB +Type-c (10W)
10A 5 pole socket with USB type-C(10W)
¥:185.00
小板10五孔插座带USB +Type-C(18W)
10A 5 pole socket with USB type-C(18W)
¥:290.00

AB-G2-0112
小板一位开关带13A多功能五孔插座带USB
1 gang swich and 5 pin multi-function socket with USB and indicator light
¥:230.00

AB-G2-0113
小板13A二三极多功能插座+二位USB
Small board 13A two three pole multi function socket + 2-bit USB
¥:180.00

AB-G2-0114
小板13A二三极多功能插座+二位USB带小开关
Small board 13A two three pole multi-function socket + 2-bit USB With small switch
¥:190.00

AB-G2-0115
小板13A多功能五孔带USB+Type-C(10W)
13A MF 5 pin socket USB+type-C(10W)
¥:180.00
小板13A多功能五孔带USB+Type-C(18W)
13A MF 5 pin socket USB+type-C(18W)
¥:290.00

AB-G2-0116
小板一位电视插座
TV socket
¥:128.00

AB-G2-0117
小板一位电话插座 telephone socket ¥:128.00
小板一位电脑插座 computer socket ¥:138.00
小板一位电脑插座(超六类) computer socket(6) ¥:178.00



AB-G2-0118
小板双电视插座
Two TV socket
¥:158.00

AB-G2-0119
小板双电话插座 Two telephone socket ¥:158.00
小板双电脑插座 Two computer socket ¥:178.00
小板双电脑插座(超六类) Two computer socket(6) ¥:258.00
小板电话电脑插座 telephone+computer socket ¥:168.00
小板电话电脑插座(超六类) telephone+computer socket(6) ¥:208.00

AB-G2-0120
小板电视电话插座 TV +telephone socket ¥:158.00
小板电视电脑插座 TV +computer socket ¥:168.00
小板电视电脑插座(超六类) TV +computer socket(6) ¥:208.00

AB-G2 Tempered glass champagne gold 钢化玻璃香槟金

AB-G2-0121

小板一位电话带USB插座 ¥:280.00
TEL+USB socket
小板一位电脑带USB插座 ¥:290.00
computer+USB socket
小板一位电脑带USB插座(超六类) ¥:330.00
computer+USB socket(6)

AB-G2-0122

小板一位TV+FM
TV and FM
¥:198.00

AB-G2-0123

小板一位卫星插座
Satellite socket
¥:148.00

AB-G2-0124

小板二位卫星插座
Double satellite socket
¥:175.00

AB-G2-0125

小板卫星+电视插座
Satellite and TV socket
¥:166.00

AB-G2-0126

小板卫星带电话插座 ¥:166.00
Satellite and telephone socket
小板卫星带电脑插座 ¥:175.00
Satellite and computer socket
小板卫星带电脑插座(超六类) ¥:215.00
Satellite and computer socket(6)

AB-G2-0127

小板二极插座带电视插座
2 pin socket with TV
¥:290.00

AB-G2-0128

小板二极插座带电话插座 ¥:290.00
2 pin socket with telephone
小板二极插座带电脑插座 ¥:290.00
2 pin socket with computer
小板二极插座带电脑插座(超六类) ¥:330.00
2 pin socket with computer

AB-G2-0129

小板一位光纤插座
Optical fiber socket
¥:190.00

AB-G2-0130

小板二位USB插座
Double USB socket
¥:230.00

AB-G2-0131

小板单联音响插座
Single audio socket
¥:202.00

AB-G2-0132

小板双联音响插座
Double audio socket
¥:275.00

AB-G2-0133

触摸延时开关（节能）
Touch delay delay switch
¥:202.00

AB-G2-0134

声光控延时开关（节能）
Sound-light controlled delay switch (energy saving)
¥:202.00

AB-G2-0135

红外线人体感应开关
Human body induction
¥:220.00

AB-G2-0136

凹型地脚灯（亮光/暖光）
The footlights
¥:195.00

AB-G2-0137

凹型红外线人体感应地脚灯
（亮光/暖光）
The human body induction footlights
¥:330.00

AB-G2-0138

平面地脚灯（亮光/暖光）
footlights
¥:195.00

AB-G2-0139

叮咚门铃
Ding dong doorbell
¥:245.00

AB-G2-0140

机械式40A插卡取电 ¥:280.00
Mechanical card for electricity
感应式低频40A插卡取电 ¥:400.00
Low frequency induction card
感应式高频40A插卡取电 ¥:460.00
High freqency induction card for electricty



AB-G2-0141

紧急呼叫开关
Emergency call seitch
¥:210.00

AB-G2-0142

请勿打扰请即清理门铃开关
（按键式）
Do not disturb plese namely cleaning please+late doorbell "button"
¥:250.00

AB-G2-0143

请勿打扰门铃开关(按键式)
Do not disturb+doorbell "button"
¥:385.00

AB-G2-0144

请勿打扰请即清理门铃开关
(按键式)
Do not disturb plese namely cleaning please "button"
¥:475.00

AB-G2-0145

智能音乐控制开关
intelligent music cintrol seitch
¥:2950.00

AB-G2-0146

温度控制调节开关
Temperature control seitch
¥:800.00

AB-G2-0147

温度控制调节开关
Tuning switchcontrol seitch
¥:850.00

AB-G2-0148

调音开关
Tuning switch
¥:260.00

AB-G2-0149

调光开关300W ¥:198.00
Dimming 300W
调光开关600W ¥:225.00
Dimming 600W
调光开关1000W ¥:252.00
Dimming 1000W

AB-G2-0150

调速开关300W ¥:198.00
Speed 300W
调速开关600W ¥:225.00
Speed 600W
调速开关1000W ¥:252.00
Speed 1000W

AB-G2-0151

一位开关带调光开关500W
1 gang with dimmer switch
¥:212.00

AB-G2-0152

一位开关带调速开关500W
1 gang with speed switch
¥:212.00

AB-G2-0153

13A开关带保险丝（带指示灯）
13A switch with fuse with neon
¥:239.00

AB-G2-0154

小板20A出线柱
20A outgoing post
¥:221.00

AB-G2-0155

剃须插座
Shaving socket
¥:450.00

AB-G2-0156

USB+电脑插座+无线路由
USB+computer socket wireless router
¥:800.00

AB-G2-0157

蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio+3.5+2USB+HDMI
¥:5250.00

AB-G2-0158

HDMI
¥:288.00

AB-G2-0159

USB+Type-c
¥:324.00

AB-G2-0160

HDMI+USB
¥:288.00

AB-G2-0161

HDMI+USB+3.5音频
HDMI+USB+3.5
¥:288.00

AB-G2-0162

VGA+USB+3.5音频
VGA+USB+3.5
¥:288.00

AB-G2-0163

AV+3.5音频
AV +3.5
¥:288.00

AB-G2-0164

VGA+AV音频接口
VGA+AV audio interface
¥:288.00

AB-G2-0165

HDMI+AV音频接口
HDMI+AV audio interface
¥:288.00

AB-G2-0166

二分之一AV音频+卫星
Half AV audio interface+Satellite
¥:288.00

AB-G2-0167

二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:288.00

AB-G2-0168

二分之一VGA+TV
Half VGA+TV
¥:288.00

AB-G2-0169

二分之一VGA+电脑
Half VGA+Computer
¥:288.00

AB-G2-0170

二分之一VGA+USB
Half VGA+USB
¥:288.00

AB-G2-0171

二分之一VGA+HDMI
Half VGA+HDIM
¥:288.00

AB-G2-0172

45A出线柱
45A Outlet
¥:248.00

AB-G2-0173

空白面板
Blank plate
¥:102.00

AB-G2-0174

大板二位双极开关带二位13A方角插座（指示灯）
Large board two position bipolar switch with two position 13A square angle Socket (indicator)
¥:258.00

AB-G2-0175

大板二位开关带二位16A多功能插座（带指示灯）
147 Tow switch and double 16A MF 3pin socket with light
¥:258.00

AB-G2-0176

147 二位开关带二位13A方角插座带二位USB（带指示灯）
147 Tow switch and double 13A square comer socker with two USB and indicator light
¥:358.00

AB-G2-0177

大板二位开关带二位16A多功能插座+双USB（带指示灯）
147 Tow switch and double 16A MF socket + 2USB with light
¥:358.00

AB-G2-0178

大板147型二位开关带二位13A方插+USB/Type-c(指示灯)
Large board 147 two position switch with two position 13A square plug +USB / type-C (indicator)
¥:388.00

AB-G2-0179

大板147型二位开关带二位13A多功能+USB/Type-c(指示灯)
Large plate 147 two position switch with two position 13A multifunction +USB / type-C (indicator)
¥:388.00

AB-G2-0180

147型45A双极开关+一开13A方角插带灯(炉具开关)
147 type 45A bipolar switch + 13A square angle plug With light (stove switch)
¥:310.00

AB-G2 Tempered glass champagne gold 钢化玻璃香槟金



AB-G2-0181

147型45A双极开关带指示灯
147 type 45A bipolar switch with indicator light
¥:280.00

AB-G2-0182

147型空白面板
147 blank panel
¥:185.00

AB-G2-0183

小板147型16A二位开关单控
Small plate 147 type 16A two position switch single control
¥:212.00
小板147型16A二位开关双控
Small plate 147 type 16A two position switch double control
¥:218.00

AB-G2-0184

小板147型16A三位开关单控
Small plate 147 type 16A 3 gang 2 way switch
¥:230.00
小板147型16A三位开关双控
Small plate 147 type 16A 3 gang 2 way switch
¥:239.00

AB-G2-0185

小板147型16A四位开关单控
Small plate 147 type 16A 4 gang 1 way switch
¥:248.00
小板147型16A四位开关双控
Small plate 147 type 16A 4 gang 1 way switch
¥:259.00

AB-G2-0186

小板147型16A五位开关单控
Small plate 147 type 16A 5 gang 1 way switch
¥:266.00
小板147型16A五位开关双控
Small plate 147 type 16A 5 gang 2 way switch
¥:280.00

AB-G2-0187

小板147型16A六位开关单控
Small plate 147 type 16A 6 gang 1 way switch
¥:280.00
小板147型16A六位开关双控
Small plate 147 type 16A 6 gang 2 way switch
¥:301.00

AB-G2-0188

小板147型16A七位开关单控
Small plate 147 type 16A 7 gang 1 way switch
¥:302.00
小板147型16A七位开关双控
Small plate 147 type 16A 7 gang 2 way switch
¥:321.00

AB-G2-0189

小板147型16A八位开关单控
Small plate 147 type 16A 8 gang 1 way switch
¥:320.00
小板147型16A八位开关双控
1Small plate 147 type 16A 8 gang 2 way switch
¥:342.00

AB-G2-0190

147 二位16A多功能三极插座
147 Double 13A MF 3 pin socket
¥:248.00



AB-G2-0191

147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:281.00

AB-G2-0192

小板147型二位15A美标扁插座
Small plate 147 two position 15A American standard flat socket
¥:279.00

AB-G2-0193

147 二位15A泰式多功能六孔插座
147 Double 15A Thai MF six-hole socket
¥:279.00



AB-G2-0194

147 二位13A方角插座
147 Double 13A square comer
¥:248.00



AB-G2-0195

147 二位15A圆孔插座
147 Double 15A 3 round pins socket
¥:279.00



AB-G2-0196

小板147型二位13A错位多功能二三极插座
147 type Double 13A dislocation MF 5 pole socket
¥:299.00



AB-G2-0197

147型小板二位10A二三极插座
147 type Double 10A two and three pole socket
¥:225.00

AB-G2-0198

147 二位开关带二位13A方角插座
147 Tow switch and double 13A square corner socket
¥:257.00

AB-G2-0199

147 二位开关带二位13A多功能插座
147 Tow switch and double 13A MF 3 pin socket with light
¥:257.00

AB-G2-0200

小板147二位开关二位13A多功能二三极插座
Small board 147 two position switch two position 13A multi-function two three pole socket
¥:284.00

AB-G2-0201

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 13A square comer socket with indicator light
¥:258.00

AB-G2-0202

147 二位开关带二位13A多功能插座（带指示灯）
147 Tow switch and double 13A MF socket with light
¥:258.00

AB-G2-0203

147 二位开关带二位13A方角插座带二位USB
147 Tow switch and double 13A square comer socket with 2USB
¥:358.00

AB-G2-0204

147 二位开关带二位13A多功能带二位USB
147 Tow switch and double 13A MF socket+2USB
¥:358.00

AB-G2-0205

147二位开关二位13A方插+USB/Type-c（小板）
147 two switch Double 13A square plug+ USB/type-C
¥:358.00

AB-G2-0206

147二位开关二位13A多功能+USB/Type-c（小板）
147 two switch Double 13A MF+USB / type-C
¥:358.00



AB-G2-0207

147 二位开关带二位15A圆角插座（带指示灯）
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:293.00

AB-G2-0208

147 二位开关带二位13A方角插座（带指示灯）
147 two switch and double 13A square Angle socket (with neon)
¥:293.00

AB-G2-0209

147 四孔剃须插座
147 two shaving socket
¥:612.00

AB-G2-0210

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 kitchen switch
¥:346.00

AB-G2-0211

147 45A开关+一位开关13A方角插带指示灯(组合厨房开关)
147 kitchen switch
¥:346.00

AB-G2-0212

147型45A双极开关+一开13A方角插带灯（炉具开关）
147 type 45A bipolar switch +13A square angle plug With light (stove switch)
¥:374.00

AB-G2-0213

147型45A双极开关带指示灯
147 type 45A bipolar switch with indicator light
¥:324.00

AB-G2-0214

147 16A二位德式插座
147 Double Geman socket
¥:293.00

AB-G2-0215

147 16A二位法式插座
147 Double French socket
¥:293.00

AB-G2-0216

小板147型连体二位德标插座
Small plate 147 connected two position German standard socket
¥:293.00

AB-G2-0217

小板147型连体二位法标插座
Small plate 147 connected two position normal socket
¥:293.00

AB-G2-0218

147二位16A德式插座+USB/Type-c(小板)
147 double 16A German with USB/Type-c
¥:390.00

AB-G2-0219

147二位16A法式插座+USB/Type-c(小板)
147 double 16A French with USB/Type-c
¥:390.00

AB-G2-0220

小板147型二位16A德式+二位USB
147 double 16A German+2USB
¥:369.00

AB-G2-0221

小板147型二位16A德式+二位USB
147 Double 16A German+2USB
¥:369.00

AB-G2-0222

147 四位USB插座
147 4 USB socket
¥:477.00

AB-G2-0223

147 二位多功能插座+4USB
147 2-bit multi-function socket + 4USB
¥:414.00

AB-G2-0224

147 二位13A方角插座+4USB
147 two bit 13A square socket +4USB
¥:414.00



AB-G2-0225

小板147型13A方角插座+二位USB
Small board 147 type 13A square corner socket + 2USB
¥:376.00

AB-G2-0226

147 一位16A多功能插座+二位USB插座
147 13A MF 3 pin socket + 2USB socket
¥:376.00

AB-G2-0227

147型二位开关带二位13A多功能五孔+双USB
147 two switch and double 13A MF 5 pin + 2USB
¥:374.00

AB-G2-0228

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two position switch with two position 13A multifunction Five hole socket + 2 USB (with indicator)
¥:522.00

AB-G2-0229

147 二位13A多功能五孔插座+四位USB
147 double 5 pin multi-function socket+4USB
¥:414.00

AB-G2-0230

147型二位13A多功能五孔带4USB+小开关(带指示灯)
147 double 13A MF 5 pin with 4USB+ small switch (w/neon)
¥:432.00

AB-G2-0231

小板147型二位开关二位13A多功能五孔+USB/Type-c
147 two switch and double 13A MF 5 pin + USB / type-C
¥:495.00

AB-G2-0232

小板147型二位开关带二位13A多功能插座+4USB带指示灯
147 two switch and double 13A MF + 4USB (with neon)
¥:432.00

AB-G2-0233

小板147型二位开关带二位13A方角插座+4USB带指示灯
147 two switch and double 13A square Angle Socket +4USB (with neon)
¥:432.00

AB-G2-0234

147型二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 two switch double German socket +USB/Type-c (with neon)
¥:495.00

AB-G2-0235

147型二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 two switch double French socket +USB/Type-c (with neon)
¥:495.00

AB-G2-0236

147型二位开关二位16A德式插座（带指示灯）
147 two switch double German socket (with neon)
¥:329.00

AB-G2-0237

147型二位开关二位16A德式插座（带指示灯）
147 two switch double French socket (with neon)
¥:329.00

AB-G2-0238

147型二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket with neon+ 2USB
¥:405.00

AB-G2-0239

147型二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch with double 16A French socket with 2USB (with neon)
¥:405.00

AB-G2-0240

小板147型空白面板
147 Blank plate
¥:167.00

智能WIFI插座

WIFI 13A方角英标插座

语音控制 定时功能 远程控制
¥:430.00

WIFI 16A欧标插座

语音控制 定时功能 远程控制
¥:500.00

WIFI美标15A三极扁插

语音控制 定时功能 远程控制
¥:350.00

AB-G3 钢化玻璃爵士黑
Tempered glass jazz black

每一个开关都是艺术品

每一个宝贝,都是我们用心构造而成独树一帜的体验,让家更美

Every switch is a work of art

Every baby is a unique experience constructed by our heart making our home more beautiful

ZIGBEE智能按键开关

ZIGBEE Intelligent button switch

Zigbee一开
¥1150.00

Zigbee二开
¥1250.00

Zigbee三开
¥1350.00

二三极USB/Type-c+开关
¥240.00

网络协议和支持平台

Network protocol and support platform

Powered By tuya Intelligence Inside

google音箱　天猫精灵　小爱音箱　京东叮咚

小度音箱　若琪音箱　亚马逊音箱　腾讯小微

产品参数

Product parameters

颜色分类 Color selection	金色 黑色 白色 灰色 蓝色 Gold black white gray blue
输入方式 Input mode	零火线 Zero fire line
输入电压 input voltage	110V-250VAC 50/60HZ
连网模式 Networking	WIFI+RF双模　自带WIFI模块 WiFi + RF dual mode　With WiFi module
额定功率 Power rating	600W
额定电流 Rated current	10A
使用寿命 service life	10万次 10,0000times
表面材质 Surface material	曲面钢化玻璃 Curved tempered glass
工作温度 Operation Temperature	-20℃ ~ +50℃
防火等级 Fire-protection rating	94-V0
待机功耗 standby power	(Standby power) 0.5W
装箱重量 Shipping weight	10.8KG
无线频率 Radio frequency	2.4GHz
无线标准 Wireless standard	IEEE802.11b/g/n

AB-G3 Tempered glass jazz black 钢化玻璃爵士黑

AB-G3-0001

一位触摸开关(零火线) ￥:400.00
1 gang 1 way touch switch
蓝牙WIFI一位触摸开关(零火版) ￥:500.00
1 gang 1 way touch switch
涂鸦Zigbee一位触摸开关(零火版) ￥:600.00
1 gang 1 way touch switch

AB-G3-0002

二位触摸开关（零火版） ￥:450.00
2 gang 1 way touch switch
蓝牙WIFI二位触摸开关(零火版) ￥:550.00
2 gang 1 way touch switch
涂鸦Zigbee二位触摸开关(零火版) ￥:650.00
2 gang 1 way touch switch

AB-G3-0003

三位触摸开关（零火版） ￥:500.00
3 gang 1 way touch switch
蓝牙WIFI三位触摸开关(零火版) ￥:600.00
3 gang 1 way touch switch
涂鸦Zigbee三位触摸开关(零火版) ￥:700.00
3 gang 1 way touch switch

AB-G3-0004

四位触摸开关（零火版） ￥:550.00
4 gang 1 way touch switch
蓝牙WIFI四位触摸开关(零火版) ￥:650.00
4 gang 1 way touch switch
涂鸦Zigbee四位触摸开关(零火版) ￥:750.00
4 gang 1 way touch switch

AB-G3-0005

大板16A一位开关单控 ￥:86.00
Large panel 16A 1 gang 1 way switch
大板16A一位开关双控 ￥:90.00
Large panel 16A 1 gang 2 way switch
大板16A一位开关多控 ￥:123.00
Large panel 16A 1 gang 3 way switch

AB-G3-0006

大板16A二位开关单控 ￥:109.00
Large panel 16A 2 gang 1 way switch
大板16A二位开关双控 ￥:110.00
Large panel 16A 2 gang 2 way switch
大板16A二位开关多控 ￥:158.00
Large panel 16A 2 gang 3 way switch

AB-G3-0007

大板16A三位开关单控 ￥:139.00
Large panel 16A 3 gang 1 way switch
大板16A三位开关双控 ￥:156.00
Large panel 16A 3 gang 1 way switch

AB-G3-0008

大板16A四位开关单控 ￥:169.00
Large panel 16A 4 gang 1 way switch
大板16A四位开关双控 ￥:183.00
Large panel 16A 4 gang 2 way switch

AB-G3-0009

大板16A百叶窗升降开关
Large panel louver window lifter switch
￥:145.00

AB-G3-0010

大板16A门控开关
Large panel gating switch
￥:109.00

AB-G3-0011

大板16A英式门控开关
Large panel British gating switch
￥:109.00

AB-G3-0012

大板16A门铃开关
Large panel doorbell switch
￥:109.00

AB-G3-0013

大板20A双极开关带指示灯 ￥:168.00
20A bipolar switch with indicator light
大板32A双极开关带指示灯 ￥:186.00
32A bipolar switch with indicator light

AB-G3-0014

大板45A双极开关带指示灯
45A bipolar switch with indicator light
￥:200.00

AB-G3-0015

大板16A三极插座
16A 3 pole socket
￥:109.00

AB-G3-0016

大板16A多功能插座
16A 3 pin universal socket
￥:109.00

AB-G3-0017

大板10A二三极插座
10A 5 pole socket
￥:93.00

AB-G3-0018

大板10A错位二三极插座
10A Two or three pole socket
￥:117.00

AB-G3-0019

大板16A多功能五孔插座
16A MF 5 pin socket
￥:128.00

AB-G3-0020

大板10A二二三极插座
10A 7 pole socket
￥:128.00

AB-G3-0021

大板13A方角插座
13A square corner socket
￥:109.00

AB-G3-0022

大板二位USB带16A多功能五孔插座
2 USB with 5 pin multi-function socket
￥:213.00

AB-G3-0023

大板16A一位开关单控带16A三极插座
1gang1 way swith and 16A 3 pole socket

大板16A一位开关双控带16A三极插座
1gang2 way swith and 16A 3 pole socket
￥:143.00

AB-G3-0024

大板16A一位开关单控带16A三极插座
1gang2 way swith and 16A 3 pole socket
￥:140.00

大板16A一位开关双控带16A三极插座
1gang 2 way switch and 5 pole socket
￥:143.00

AB-G3-0025

大板10A二位开关单控带二三极插座
2 gang 1 way switch and 5 pole socket

大板10A二位开关双控带二三极插座
2 gang 2 way switch and 5 pole socket
￥:167.00

AB-G3-0026

大板一位开关带16A三极多功能插座(带指示灯）
1 gang switch and 16A 3 pin multi-purpose socket with indicator light
￥:146.00

AB-G3-0027

大板一位双极开关带13A方角插座（指示灯）
Large board one position bipolar switch with 13A square angle socket (indicator light)
￥:139.00

AB-G3-0028

大板一位开关带15A圆孔插座(带指示灯）
1 gang weitch and 15A 3 square pin socket with indicator light
￥:146.00

AB-G3-0029

大板一位开关带16A二三极多功能插座(带指示灯）
1 gang swith and 5 pin multi-function socket with indicator light
￥:152.00

AB-G3-0030

大板一位开关带13A多功能插座+二位USB（指示灯）
Large board one position switch with 13A multi-function socket + 2USB (indicator)
￥:295.00

AB-G3-0031

大板一位开关带13A方角插+二位USB（指示灯）
Board one position switch with 13A square angle plug + two position USB (indicator)
￥:295.00

AB-G3-0032

大板16A德式插座
Large board 16A German socket
￥:163.00

AB-G3-0033

大板16A法式插座
Large plate 16A French socket
￥:163.00

AB-G3-0034

大板16A俄式插座
Large board 16A Russian socket
￥:163.00

AB-G3-0035

大板16A德式插座+二位USB
German socket+2 USB
￥:255.00

AB-G3-0036

大板16A法标插座+二位USB
French socket + 2 USB
￥:255.00

AB-G3-0037

大板16A德标插座+USB/Type-c
Large board 16A German socket + USB / type-C
￥:255.00

AB-G3-0038

大板16A法式插座+USB/Type-c
Large board 16A French socket + USB / type-C
￥:255.00

AB-G3-0039

大板一位电视插座
TV socket
￥:128.00

AB-G3-0040

大板一位电话插座 ￥:128.00
telephone socket
大板一位电脑插座 ￥:138.00
computer socket
大板一位电脑插座（超六类） ￥:178.00
computer socket(6)

AB-G3-0041

大板一位电视电话插座 ￥:158.00
TV +telephone socket
大板一位电视电脑插座 ￥:168.00
TV +computer socket
大板一位电视电脑插座（超六类） ￥:208.00
TV +computer socket(6)

AB-G3-0042

大板二位电视插座
Two TV socket
￥:158.00

AB-G3-0043

大板二位电话插座 ￥:158.00
Two TV socket
大板二位电脑插座 ￥:178.00
Two computer socket
大板二位电脑插座（超六类） ￥:258.00
Two computer socket(6)
大板电话+电脑插座 ￥:168.00
telephone+computer socket
大板电话+电脑插座（超六类） ￥:208.00
telephone+computer socket(6)

AB-G3-0044

大板空白面板
Large blank panel
￥:80.00

AB-G3-0045

小板16A一位开关单控 ￥:87.00
16A 1 gang 1 way switch
小板16A一位开关双控 ￥:90.00
16A 1 gang 2 way switch
小板16A一位开关多控 ￥:123.00
16A 1 gang more way switch

AB-G3-0046

小板16A二位开关单控 ￥:109.00
16A 2 gang 1 way switch
小板16A二位开关双控 ￥:110.00
16A 2 gang 2 way switch
小板16A二位开关多控 ￥:158.00
16A 2 gang more way switch

AB-G3-0047

小板16A三位开关单控 ￥:139.00
16A 3 gang 1 way switch
小板16A三位开关双控 ￥:156.00
16A 3 gang 2 way switch

AB-G3-0048

小板16A四位开关单控 ￥:169.00
16A 4 gang 1 way switch
小板16A四位开关双控 ￥:183.00
16A 4 gang 2 way switch

AB-G3-0049

小板16A三位开关多控
16A 3 gang 3 way switch
￥:230.00

AB-G3-0050

小板16A百叶窗升降开关
louver window lifter switch
￥:145.00

AB-G3-0051

小板16A门控开关
gating switch
￥:109.00

AB-G3-0052

小板16A英式门控开关
British gating switch
￥:109.00

AB-G3-0053

小板16A门铃开关
doorbell switch
￥:109.00

AB-G3-0054

小板16A拨动一位开关单控
1 gang 1 way toggle switch
￥:175.00
小板16A拨动一位开关双控
1 gang 2 way toggle switch
￥:180.00

AB-G3-0055

小板16A拨动二位开关单控
2 gang 1 way toggle switch
￥:190.00
小板16A拨动二位开关双控
2 gang 2 way toggle switch
￥:200.00

AB-G3-0056

小板16A拨动三位开关单控
3 gang 1 way toggle switch
￥:205.00
小板16A拨动三位开关双控
3 gang 2 way toggle switch
￥:220.00

AB-G3-0057

小板16A拨动四位开关单控
4 gang 1 way toggle switch
￥:220.00
小板16A拨动四位开关双控
4 gang 2 way toggle switch
￥:240.00

AB-G3-0058

小板20A双极开关带指示灯 ￥:165.00
20A swich with indicator light
小板45A双极开关带指示灯 ￥:185.00
45A swich with indicator light

AB-G3-0059

小板45A双极开关带指示灯
45A swich with indicator light
￥:185.00

AB-G3-0060

小板16A卷帘门复位开关
16A shutter reset switch
￥:195.00

AB-G3 Tempered glass jazz black 钢化玻璃爵士黑

AB-G3-0061
小板16A德式插座
German socket
¥:146.00

AB-G3-0062
小板16A法式插座
French socket
¥:146.00

AB-G3-0063
小板16A俄式插座
Russian socket
¥:146.00

AB-G3-0064
小板16A以色列插座
Israel socket
¥:165.00

AB-G3-0065
小板16A意大利+德式插座
Italy+German socket
¥:165.00

AB-G3-0071
小板13A二三极多功能插座
5 pin multi-function socket
¥:128.00

AB-G3-0072
小板13A错位多五孔插座
Dislocation multi 5 pin multi function socket
¥:128.00

AB-G3-0073
小板13A方角插座
13A square corner socket
¥:109.00

AB-G3-0074
小板15A圆角插座
15A 3 round pins socket
¥:128.00

AB-G3-0075
小板15A美标扁三极插座
15A triode flat American 3 pin universal socket
¥:128.00

AB-G3-0081
小板一位开关带13A方角插座(带指示灯)
1 gang switch and 13A square pin socket withindicator light
¥:139.00

AB-G3-0082
小板一位开关带15A圆孔插座(带指示灯)
1 gang switch and 15A 3 round pins socket with indicator light
¥:146.00

AB-G3-0083
小板一位开关带16A多功能插座（带指示灯）
1 gang switch and 16A MF 3 pin socket with light
¥:146.00

AB-G3-0084
小板一位开关带13A多功能五孔插座(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
¥:152.00

AB-G3-0085
小板16A德式插座带二位USB
2 USB witch German socket
¥:225.00

AB-G3-0066
小板10A二极插座
10A 2 pole socket
¥:126.00

AB-G3-0067
小板10A二二极插座
10A Double 2 pole socket
¥:139.00

AB-G3-0068
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:139.00

AB-G3-0069
小板10A一位开关带二二极座
1 gang switch and 4 pole socket
¥:146.00

AB-G3-0070
小板16A多功能三极插座
16A MF 3 pin socket
¥:109.00

AB-G3-0076
小板15A泰式插座
15A Thai socket
¥:128.00

AB-G3-0077
小板15A泰式六孔插座
Small plate 15A Thai six hole socket
¥:138.00

AB-G3-0078
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:136.00

AB-G3-0079
小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pin socket
¥:143.00

AB-G3-0080
小板一位开关带16A多功能插座
1 gang switch and 3 pin MF socket
¥:143.00

AB-G3-0086
小板16A法式插座带二位USB
2 USB with French socket
¥:225.00

AB-G3-0087
小板16A德式插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:225.00

AB-G3-0088
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:225.00

AB-G3-0089
小板16A一位开关带德式插座
1 gang German socket
¥:165.00

AB-G3-0090
小板16A一位开关带法式插座
1 gang French socket
¥:165.00

AB-G3-0091
小板16A德式插座带防水
German socket and Waterproof belt
¥:155.00

AB-G3-0092
小板16A法式插座带防水
French socket and Waterproof belt
¥:155.00

AB-G3-0093
小板二位USB带13A方角插座（横）
2 USB with 13A square corner socket with swith
¥:225.00

AB-G3-0094
小板15A美式+USB/type-c
15A American Standard + USB / type-C
¥:225.00

AB-G3-0095
小板15A泰式+USB/Type-c
15A Thai + USB / type-C
¥:225.00

AB-G3-0096
小板二位USB带13A方角插座（带保护门）
2 USB with 13A square corner socket with flip cover
¥:225.00

AB-G3-0097
小板二位USB带13A多功能插座（带保护门）
2 USB with 3 pin multi-purpose socket with flip cover
¥:225.00

AB-G3-0098
小板一位开关13A多功能插座带指示灯+二位USB
2 USB with 13A aquare comer socket with flip cover
¥:225.00

AB-G3-0099
小板一位开关13A方角插座带指示灯+二位USB
Small board one position switch 13A square corner socket with indicator light + two position USB
¥:225.00

AB-G3-0100
小板13A多功能带Type-c+USB
13A multifunction with type-C + USB
¥:225.00

AB-G3-0101
小板13A方角插带Type-c+USB
13A square angle band type-C + USB
¥:225.00

AB-G3-0102
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with Type-c+USB(with light)
¥:225.00

AB-G3-0103
小板二位USB带13A多功能插座带小开关（竖）
2 USB with Three very multi-purpose socket with switch
¥:235.00

AB-G3-0104
小板一位开关13A方插带Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:225.00

AB-G3-0105
小板二位USB带13A方角插座带小开关（竖）
2 USB with 13A square corner socket with swith
¥:235.00

AB-G3-0106
小板15A美式扁插+二位USB插座
15A American Standard + 2USB
¥:225.00

AB-G3-0107
小板15A泰式+二位USB插座
15A Thai + 2USB
¥:225.00

AB-G3-0108
小板二位USB带13A多功能插座（横）
2 USB with 3 pin multi-purpose socket
¥:225.00

AB-G3-0109
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:185.00

AB-G3-0110
小板二位USB带10A二三极插座带开关
2 USB and 5 pin socket with switch
¥:195.00

AB-G3-0111
小板10五孔插座带USB +Type-c (10W)
10A 5 pole socket with USB type-C(10W)
¥:185.00
小板10五孔插座带USB +Type-C(18W)
10A 5 pole socket with USB type-C(18W)
¥:290.00

AB-G3-0112
小板一位开关带13A多功能五孔插座带USB
1 gang swich and 5 pin multi-function socket with USB and indicator light
¥:230.00

AB-G3-0113
小板13A二三极多功能插座+二位USB
Small board 13A two three pole multi function socket + 2-bit USB
¥:180.00

AB-G3-0114
小板13A二三极多功能插座+二位USB带小开关
Small board 13A two three pole multi-function socket + 2-bit USB With small switch
¥:190.00

AB-G3-0115
小板13A多功能五孔带USB+Type-C(10W)
13A MF 5 pin socket USB+type-C(10W)
¥:180.00
小板13A多功能五孔带USB+Type-C(18W)
13A MF 5 pin socket USB+type-C(18W)
¥:290.00

AB-G3-0116
小板一位电视插座
TV socket
¥:128.00

AB-G3-0117
小板一位电话插座 telephone socket ¥:128.00
小板一位电脑插座 computer socket ¥:138.00
小板一位电脑插座(超六类) computer socket(6) ¥:178.00

AB-G3-0118
小板双电视插座
Two TV socket
¥:158.00

AB-G3-0119
小板双电话插座 Two telephone socket ¥:158.00
小板双电脑插座 Two computer socket ¥:178.00
小板双电脑插座(超六类) Two computer socket(6) ¥:258.00
小板电话电脑插座 telephone+computer socket ¥:168.00
小板电话电脑插座(超六类) telephone+computer socket(6) ¥:208.00

AB-G3-0120
小板电视电话插座 TV +telephone socket ¥:158.00
小板电视电脑插座 TV +computer socket ¥:168.00
小板电视电脑插座(超六类) TV +computer socket(6) ¥:208.00

AB-G3 Tempered glass jazz black 钢化玻璃爵士黑

AB-G3-0121

小板一位电话带USB插座 ¥:280.00
TEL+USB socket
小板一位电脑带USB插座 ¥:290.00
computer+USB socket
小板一位电脑带USB插座 ¥:330.00
(超六类)
computer+USB socket(6)

AB-G3-0122

小板一位TV+FM
TV and FM
¥:198.00

AB-G3-0123

小板一位卫星插座
Satellite socket
¥:148.00

AB-G3-0124

小板二位卫星插座
Double satellite socket
¥:175.00

AB-G3-0125

小板卫星+电视插座
Satellite and TV socket
¥:166.00

AB-G3-0126

小板卫星带电话插座 ¥:166.00
Satellite and telephone socket
小板卫星带电脑插座 ¥:175.00
Satellite and computer socket
小板卫星带电脑插座(超六类) ¥:215.00
Satellite and computer socket(6)

AB-G3-0127

小板二极插座带电视插座
2 pin socket with TV
¥:290.00

AB-G3-0128

小板二极插座带电话插座 ¥:290.00
2 pin socket with telephone
小板二极插座带电脑插座 ¥:290.00
2 pin socket with computer
小板二极插座带电脑插座 ¥:330.00
(超六类)
2 pin socket with computer

AB-G3-0129

小板一位光纤插座
Optical fiber socket
¥:190.00

AB-G3-0130

小板二位USB插座
Double USB socket
¥:230.00

AB-G3-0131

小板单联音响插座
Single audio socket
¥:202.00

AB-G3-0132

小板双联音响插座
Double audio socket
¥:275.00

AB-G3-0133

触摸延时开关（节能）
Touch delay delay switch
¥:202.00

AB-G3-0134

声光控延时开关（节能）
Sound-light controlled delay switch
(energy saving)
¥:202.00

AB-G3-0135

红外线人体感应开关
Human body induction
¥:220.00

AB-G3-0136

凹型地脚灯（亮光/暖光）
The footlights
¥:195.00

AB-G3-0137

凹型红外线人体感应地脚灯
（亮光/暖光）
The human body induction footlights
¥:330.00

AB-G3-0138

平面地脚灯（亮光/暖光）
footlights
¥:195.00

AB-G3-0139

叮咚门铃
Ding dong doorbell
¥:245.00

AB-G3-0140

机械式40A插卡取电 ¥:280.00
Mechanical card for electricity
感应式低频40A插卡取电 ¥:400.00
Low frequency induction card
感应式高频40A插卡取电 ¥:460.00
High freqency induction card
for electricity

AB-G3-0141

紧急呼叫开关
Emergency call seitch
¥:210.00

AB-G3-0142

请勿打扰请即清理门铃开关
（按键式）
Do not disturb plese namely cleaning
please+late doorbell "button"
¥:250.00

AB-G3-0143

请勿打扰门铃开关(按键式)
Do not disturb+doorbell "button"
¥:385.00

AB-G3-0144

请勿打扰请即清理门铃开关
(按键式)
Do not disturb plese namely cleaning
please "button"
¥:475.00

AB-G3-0145

智能音乐控制开关
intelligent music cintrol seitch
¥:2950.00

AB-G3-0146

温度控制调节开关
Temperature control seitch
¥:800.00

AB-G3-0147

温度控制调节开关
Tuning switchcontrol seitch
¥:850.00

AB-G3-0148

调音开关
Tuning switch
¥:260.00

AB-G3-0149

调光开关300W ¥:198.00
Dimming 300W
调光开关600W ¥:225.00
Dimming 600W
调光开关1000W ¥:252.00
Dimming 1000W

AB-G3-0150

调速开关300W ¥:198.00
Speed 300W
调速开关600W ¥:225.00
Speed 600W
调速开关1000W ¥:252.00
Speed 1000W

AB-G3-0151

一位开关带调光开关500W
1 gang with dimmer switch
¥:212.00

AB-G3-0152

一位开关带调速开关500W
1 gang with speed switch
¥:212.00

AB-G3-0153

13A开关带保险丝（带指示灯）
13A switch with fuse with neon
¥:239.00

AB-G3-0154

小板20A出线柱
20A outgoing post
¥:221.00

AB-G3-0155

剃须插座
Shaving socket
¥:450.00

AB-G3-0156

USB+电脑插座+无线路由
USB+computer socket wireless router
¥:800.00

AB-G3-0157

蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio+3.5+2USB+HDMI
¥:5250.00

AB-G3-0158

HDMI
¥:288.00

AB-G3-0159

USB+Type-c
¥:324.00

AB-G3-0160

HDMI+USB
¥:288.00

AB-G3-0161

HDMI+USB+3.5音频
HDMI+USB+3.5
¥:288.00

AB-G3-0162

VGA+USB+3.5音频
VGA+USB+3.5
¥:288.00

AB-G3-0163

AV+3.5音频
AV +3.5
¥:288.00

AB-G3-0164

VGA+AV音频接口
VGA+AV audio interface
¥:288.00

AB-G3-0165

HDMI+AV音频接口
HDMI+AV audio interface
¥:288.00

AB-G3-0166

二分之一AV音频+卫星
Half AV audio interface+Satellite
¥:288.00

AB-G3-0167

二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:288.00

AB-G3-0168

二分之一VGA+TV
Half VGA+TV
¥:288.00

AB-G3-0169

二分之一VGA+电脑
Half VGA+Computer
¥:288.00

AB-G3-0170

二分之一VGA+USB
Half VGA+USB
¥:288.00

AB-G3-0171

二分之一VGA+HDMI
Half VGA+HDIM
¥:288.00

AB-G3-0172

45A出线柱
45A Outlet
¥:248.00

AB-G3-0173

空白面板
Blank plate
¥:102.00

AB-G3-0174

大板二位双极开关带二位13A方角
插座（指示灯）
Large board two position bipolar switch
with two position 13A square angle
Socket (indicator)
¥:258.00

AB-G3-0175

大板二位开关带二位16A多功能
插座（带指示灯）
147 Tow switch and double 16A MF
3pin socket with light
¥:258.00

AB-G3-0176

147 二位开关带二位13A方角插座
带二位USB（带指示灯）
147 Tow switch and double 13A square
corner socker with two USB and indicator
light
¥:358.00

AB-G3-0177

大板二位开关带二位16A多功能插座
+双USB（带指示灯）
147 Tow switch and double 16A MF
socket + 2USB with light
¥:358.00

AB-G3-0178

大板147型二位开关带二位13A方插
+USB/Type-c(指示灯）
Large board 147 two position switch with
two position 13A square plug
+USB / type-C (indicator)
¥:388.00

AB-G3-0179

大板147型二位开关带二位13A多功能
+USB/Type-c(指示灯）
Large plate 147 two position switch with
two position 13A multifunction
+USB / type-C (indicator)
¥:388.00

AB-G3-0180

147型45A双极开关+一开
13A方角插带灯(炉具开关)
147 type 45A bipolar switch
+ 13A square angle plug With
light (stove switch)
¥:310.00

AB-G3 Tempered glass jazz black 钢化玻璃爵士黑

AB-G3-0181

147型45A双极开关带指示灯
147 type 45A bipolar switch with indicator light
¥:280.00

AB-G3-0182

147型空白面板
147 blank panel
¥:185.00

AB-G3-0183

小板147型16A二位开关单控
Small plate 147 type 16A two position switch single control
¥:212.00
小板147型16A二位开关双控
Small plate 147 type 16A two position switch double control
¥:218.00

AB-G3-0184

小板147型16A三位开关单控
Small plate 147 type 16A 3 gang 2 way switch
¥:230.00
小板147型16A三位开关双控
Small plate 147 type 16A 3 gang 2 way switch
¥:239.00

AB-G3-0185

小板147型16A四位开关单控
Small plate 147 type 16A 4 gang 1 way switch
¥:248.00
小板147型16A四位开关双控
Small plate 147 type 16A 4 gang 1 way switch
¥:259.00

AB-G3-0186

小板147型16A五位开关单控
Small plate 147 type 16A 5 gang 1 way switch
¥:266.00
小板147型16A五位开关双控
Small plate 147 type 16A 5 gang 2 way switch
¥:280.00

AB-G3-0187

小板147型16A六位开关单控
Small plate 147 type 16A 6 gang 1 way switch
¥:280.00
小板147型16A六位开关双控
Small plate 147 type 16A 6 gang 2 way switch
¥:301.00

AB-G3-0188

小板147型16A七位开关单控
Small plate 147 type 16A 7 gang 1 way switch
¥:302.00
小板147型16A七位开关双控
Small plate 147 type 16A 7 gang 2 way switch
¥:321.00

AB-G3-0189

小板147型16A八位开关单控
Small plate 147 type 16A 8 gang 1 way switch
¥:320.00
小板147型16A八位开关双控
1Small plate 147 type 16A 8 gang 2 way switch
¥:342.00

AB-G3-0190

147 二位16A多功能三极插座
147 Double 13A MF 3 pin socket
¥:248.00

AB-G3-0191

147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:281.00

AB-G3-0192

小板147型二位15A美标扁插座
Small plate 147 two position 15A American standard flat socket
¥:279.00

AB-G3-0193

147 二位15A泰式多功能六孔插座
147 Double 15A Thai MF six-hole socket
¥:279.00

AB-G3-0194

147 二位13A方角插座
147 Double 13A square comer
¥:248.00

AB-G3-0195

147 二位15A圆孔插座
147 Double 15A 3 round pins socket
¥:279.00

AB-G3-0196

小板147型二位13A错位多功能二三极插座
147 type Double 13A dislocation MF 5 pole socket
¥:299.00

AB-G3-0197

147型小板二位10A二三极插座
147 type Double 10A two and three pole socket
¥:225.00

AB-G3-0198

147 二位开关带二位13A方角插座
147 Tow switch and double 13A square corner socket
¥:257.00

AB-G3-0199

147 二位开关带二位13A多功能插座
147 Tow switch and double 13A MF 3 pin socket with light
¥:257.00

AB-G3-0200

小板147二位开关二位13A多功能二三极插座
Small board 147 two position switch two position 13A multi-function two three pole socket
¥:284.00

AB-G3-0201

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 13A square comer socket with indicator light
¥:258.00

AB-G3-0202

147 二位开关带二位13A多功能插座（带指示灯）
147 Tow switch and double 13A MF socket with light
¥:258.00

AB-G3-0203

147 二位开关带二位13A方角插座带二位USB
147 Tow switch and double 13A square comer socket with 2USB
¥:358.00

AB-G3-0204

147 二位开关带二位13A多功能带二位USB
147 Tow switch and double 13A MF socket+2USB
¥:358.00

AB-G3-0205

147二位开关二位13A方插+USB/Type-c（小板）
147 two switch Double 13A square plug+ USB/type-C
¥:358.00

AB-G3-0206

147二位开关二位13A多功能+USB/Type-c（小板）
147 two switch Double 13A MF+USB / type-C
¥:358.00

AB-G3-0207

147 二位开关带二位15A圆角插座（带指示灯）
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:293.00

AB-G3-0208

147 二位开关带二位13A方角插座（带指示灯）
147 two switch and double 13A square Angle socket (with neon)
¥:293.00

AB-G3-0209

147 四孔剃须插座
147 two shaving socket
¥:612.00

AB-G3-0210

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 kitchen switch
¥:346.00

AB-G3-0211

147 45A开关+一位开关13A方角插带指示灯(组合厨房开关)
147 kitchen switch
¥:346.00

AB-G3-0212

147型45A双极开关+一开13A方角插带灯（炉具开关）
147 type 45A bipolar switch +13A square angle plug With light (stove switch)
¥:374.00

AB-G3-0213

147型45A双极开关带指示灯
147 type 45A bipolar switch with indicator light
¥:324.00

AB-G3-0214

147 16A二位德式插座
147 Double Geman socket
¥:293.00

AB-G3-0215

147 16A二位法式插座
147 Double French socket
¥:293.00

AB-G3-0216

小板147型连体二位德标插座
Small plate 147 connected two position German standard socket
¥:293.00

AB-G3-0217

小板147型连体二位法标插座
Small plate 147 connected two position normal socket
¥:293.00

AB-G3-0218

147二位16A德式插座+USB/Type-c(小板）
147 double 16A German with USB/Type-c
¥:390.00

AB-G3-0219

147二位16A法式插座+USB/Type-c(小板）
147 double 16A French with USB/Type-c
¥:390.00

AB-G3-0220

小板147型二位16A德式+二位USB
147 double 16A German+2USB
¥:369.00

AB-G3-0221

小板147型二位16A德式+二位USB
147 Double 16A German+2USB
¥:369.00

AB-G3-0222

147 四位USB插座
147 4 USB socket
¥:477.00

AB-G3-0223

147 二位多功能插座+4USB
147 2-bit multi-function socket + 4USB
¥:414.00

AB-G3-0224

147 二位13A方角插座+4USB
147 two bit 13A square socket +4USB
¥:414.00

AB-G3-0225

小板147型13A方角插座+二位USB
Small board 147 type 13A square corner socket + 2USB
¥:376.00

AB-G3-0226

147 一位16A多功能插座+二位USB插座
147 13A MF 3 pin socket + 2USB socket
¥:376.00

AB-G3-0227

147型二位开关带二位13A多功能五孔+双USB
147 two switch and double 13A MF 5 pin + 2USB
¥:374.00

AB-G3-0228

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two position switch with two position 13A multifunction Five hole socket + 2 USB (with indicator)
¥:522.00

AB-G3-0229

147 二位13A多功能五孔插座+四位USB
147 double 5 pin multi-function socket+4USB
¥:414.00

AB-G3-0230

147型二位13A多功能五孔带4USB+小开关(带指示灯)
147 double 13A MF 5 pin with 4USB+ small switch (w/neon)
¥:432.00

AB-G3-0231

小板147型二位开关二位13A多功能五孔+USB/Type-c
147 two switch and double 13A MF 5 pin + USB / type-C
¥:495.00

AB-G3-0232

小板147型二位开关带二位13A多功能插座+4USB带指示灯
147 two switch and double 13A MF + 4USB (with neon)
¥:432.00

AB-G3-0233

小板147型二位开关带二位13A方角插座+4USB带指示灯
147 two switch and double 13A square Angle Socket +4USB (with neon)
¥:432.00

AB-G3-0234

147型二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 two switch double German socket +USB/Type-c (with neon)
¥:495.00

AB-G3-0235

147型二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 two switch double French socket +USB/Type-c (with neon)
¥:495.00

AB-G3-0236

147型二位开关二位16A德式插座（带指示灯）
147 two switch double German socket (with neon)
¥:329.00

AB-G3-0237

147型二位开关二位16A德式插座（带指示灯）
147 two switch double French socket (with neon)
¥:329.00

AB-G3-0238

147型二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket with neon+ 2USB
¥:405.00

AB-G3-0239

147型二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch with double 16A French socket with 2USB (with neon)
¥:405.00

AB-G3-0240

小板147型空白面板
147 Blank plate
¥:167.00

AB-G4 钢化玻璃火山灰
Tempered glass volcanic grey



Zigbee智能按键开关
Zigbee Intelligent button switch

Zigbee一开
￥1150.00

Zigbee二开
￥1250.00

Zigbee三开
￥1350.00

二三极USB/Type-c+开关
￥240.00

语音/APP/轻触机械控制	情景模式/联动/定时	支持多款AL音响	涂鸦无线场景开关 (单火零火通用)
Voice /APP/ touch mechanical control	Scenario mode/Linkage/timing	Support a variety of AL audio	Doodle wireless scene switch (Single fire and zero fire universal)



AB-G4 Tempered glass volcanic grey 钢化玻璃火山灰

AB-G4-0001

一位触摸开关(零火线) ￥:400.00
1 gang 1 way touch switch
蓝牙WIFI一位触摸开关(零火版) ￥:500.00
1 gang 1 way touch switch
涂鸦Zigbee一位触摸开关(零火版) ￥:600.00
1 gang 1 way touch switch

AB-G4-0011

大板16A英式门控开关
Large panel British gating switch
￥:109.00

AB-G4-0021

大板13A方角插座
13A square corner socket
￥:109.00

AB-G4-0002

二位触摸开关（零火版） ￥:450.00
2 gang 1 way touch switch
蓝牙WIFI二位触摸开关(零火版) ￥:550.00
2 gang 1 way touch switch
涂鸦Zigbee二位触摸开关(零火版) ￥:650.00
2 gang 1 way touch switch

AB-G4-0012

大板16A门铃开关
Large panel doorbell switch
￥:109.00

AB-G4-0022

大板二位USB带16A多功能五孔插座
2 USB with 5 pin multi-function socket
￥:213.00

AB-G4-0003

三位触摸开关（零火版） ￥:500.00
3 gang 1 way touch switch
蓝牙WIFI三位触摸开关(零火版) ￥:600.00
3 gang 1 way touch switch
涂鸦Zigbee三位触摸开关(零火版) ￥:700.00
3 gang 1 way touch switch

AB-G4-0013

大板20A双极开关带指示灯 ￥:168.00
20A bipolar switch with indicator light
大板32A双极开关带指示灯 ￥:186.00
32A bipolar switch with indicator light

AB-G4-0023

大板16A一位开关单控带16A三极插座
1gang1 way swith and 16A 3 pole socket

大板16A一位开关双控带16A三极插座
1gang2 way swith and 16A 3 pole socket
￥:143.00

AB-G4-0004

四位触摸开关（零火版） ￥:550.00
4 gang 1 way touch switch
蓝牙WIFI四位触摸开关(零火版) ￥:650.00
4 gang 1 way touch switch
涂鸦Zigbee四位触摸开关(零火版) ￥:750.00
4 gang 1 way touch switch

AB-G4-0014

大板45A双极开关带指示灯
45A bipolar switch with indicator light
￥:200.00

AB-G4-0024

大板16A一位开关单控带16A三极插座
1gang2 way swith and 16A 3 pole socket
￥:140.00

大板16A一位开关双控带16A三极插座
1gang 2 way switch and 5 pole socket
￥:143.00

AB-G4-0005

大板16A一位开关单控 ￥:86.00
Large panel 16A 1 gang 1 way switch
大板16A一位开关双控 ￥:90.00
Large panel 16A 1 gang 2 way switch
大板16A一位开关多控 ￥:123.00
Large panel 16A 1 gang 3 way switch

AB-G4-0015

大板16A三极插座
16A 3 pole socket
￥:109.00

AB-G4-0025

大板10A二位开关单控带二三极插座
2 gang 1 way switch and 5 pole socket

大板10A二位开关双控带二三极插座
2 gang 2 way switch and 5 pole socket
￥:167.00

AB-G4-0006

大板16A二位开关单控 ￥:109.00
Large panel 16A 2 gang 1 way switch
大板16A二位开关双控 ￥:110.00
Large panel 16A 2 gang 2 way switch
大板16A二位开关多控 ￥:158.00
Large panel 16A 2 gang 3 way switch

AB-G4-0016

大板16A多功能插座
16A 3 pin universal socket
￥:109.00

AB-G4-0026

大板一位开关带16A三极多功能插座(带指示灯）
1 gang switch and 16A 3 pin multi-purpose socket with indicator light
￥:146.00

AB-G4-0007

大板16A三位开关单控 ￥:139.00
Large panel 16A 3 gang 1 way switch
大板16A三位开关双控 ￥:156.00
Large panel 16A 3 gang 1 way switch

AB-G4-0017

大板10A二三极插座
10A 5 pole socket
￥:93.00

AB-G4-0027

大板一位双极开关带13A方角插座（指示灯）
Large board one position bipolar switch with 13A square angle socket (indicator light)
￥:139.00

AB-G4-0008

大板16A四位开关单控 ￥:169.00
Large panel 16A 4 gang 1 way switch
大板16A四位开关双控 ￥:183.00
Large panel 16A 4 gang 2 way switch

AB-G4-0018

大板10A错位二三极插座
10A Two or three pole socket
￥:117.00

AB-G4-0028

大板一位开关带15A圆孔插座(带指示灯）
1 gang weitch and 15A 3 square pin socket with indicator light
￥:146.00

AB-G4-0009

大板16A百叶窗升降开关
Large panel louver window lifter switch
￥:145.00

AB-G4-0019

大板16A多功能五孔插座
16A MF 5 pin socket
￥:128.00

AB-G4-0029

大板一位开关带16A二三极多功能插座(带指示灯）
1 gang swith and 5 pin multi-function socket with indicator light
￥:152.00

AB-G4-0010

大板16A门控开关
Large panel gating switch
￥:109.00

AB-G4-0020

大板10A二二三极插座
10A 7 pole socket
￥:128.00

AB-G4-0030

大板一位开关带13A多功能插座+二位USB（指示灯）
Large board one position switch with 13A multi-function socket + 2USB (indicator)
￥:295.00

AB-G4-0031

大板一位开关带13A方角插+二位USB（指示灯）
Board one position switch with 13A square angle plug + two position USB (indicator)
￥:295.00

AB-G4-0032

大板16A德式插座
Large board 16A German socket
￥:163.00

AB-G4-0033

大板16A法式插座
Large plate 16A French socket
￥:163.00

AB-G4-0034

大板16A俄式插座
Large board 16A Russian socket
￥:163.00

AB-G4-0035

大板16A德式插座+二位USB
German socket+2 USB
￥:255.00

AB-G4-0036

大板16A法标插座+二位USB
French socket + 2 USB
￥:255.00

AB-G4-0037

大板16A德标插座+USB/Type-c
Large board 16A German socket + USB / type-C
￥:255.00

AB-G4-0038

大板16A法式插座+USB/Type-c
Large board 16A French socket + USB / type-C
￥:255.00

AB-G4-0039

大板一位电视插座
TV socket
￥:128.00

AB-G4-0040

大板一位电话插座 ￥:128.00
telephone socket
大板一位电脑插座 ￥:138.00
computer socket
大板一位电脑插座（超六类） ￥:178.00
computer socket(6)

AB-G4-0041

大板一位电视电话插座 ￥:158.00
TV +telephone socket
大板一位电视电脑插座 ￥:168.00
TV +computer socket
大板一位电视电脑插座（超六类） ￥:208.00
TV +computer socket(6)

AB-G4-0042

大板二位电视插座
Two TV socket
￥:158.00

AB-G4-0043

大板二位电话插座 ￥:158.00
Two TV socket
大板二位电脑插座 ￥:178.00
Two computer socket
大板二位电脑插座（超六类） ￥:258.00
Two computer socket(6)
大板电话+电脑插座 ￥:168.00
telephone+computer socket
大板电话+电脑插座（超六类） ￥:208.00
telephone+computer socket(6)

AB-G4-0044

大板空白面板
Large blank panel
￥:80.00

AB-G4-0045

小板16A一位开关单控 ￥:87.00
16A 1 gang 1 way switch
小板16A一位开关双控 ￥:90.00
16A 1 gang 2 way switch
小板16A一位开关多控 ￥:123.00
16A 1 gang more way switch

AB-G4-0046

小板16A二位开关单控 ￥:109.00
16A 2 gang 1 way switch
小板16A二位开关双控 ￥:110.00
16A 2 gang 2 way switch
小板16A二位开关多控 ￥:158.00
16A 2 gang more way switch

AB-G4-0047

小板16A三位开关单控 ￥:139.00
16A 3 gang 1 way switch
小板16A三位开关双控 ￥:156.00
16A 3 gang 2 way switch

AB-G4-0048

小板16A四位开关单控 ￥:169.00
16A 4 gang 1 way switch
小板16A四位开关双控 ￥:183.00
16A 4 gang 2 way switch

AB-G4-0049

小板16A三位开关多控
16A 3 gang 3 way switch
￥:230.00

AB-G4-0050

小板16A百叶窗升降开关
louver window lifter switch
￥:145.00

AB-G4-0051

小板16A门控开关
gating switch
￥:109.00

AB-G4-0052

小板16A英式门控开关
British gating switch
￥:109.00

AB-G4-0053

小板16A门铃开关
doorbell switch
￥:109.00

AB-G4-0054

小板16A拨动一位开关单控
1 gang 1 way toggle switch
￥:175.00
小板16A拨动一位开关双控
1 gang 2 way toggle switch
￥:180.00

AB-G4-0055

小板16A拨动二位开关单控
2 gang 1 way toggle switch
￥:190.00
小板16A拨动二位开关双控
2 gang 2 way toggle switch
￥:200.00

AB-G4-0056

小板16A拨动三位开关单控
3 gang 1 way toggle switch
￥:205.00
小板16A拨动三位开关双控
3 gang 2 way toggle switch
￥:220.00

AB-G4-0057

小板16A拨动四位开关单控
4 gang 1 way toggle switch
￥:220.00
小板16A拨动四位开关双控
4 gang 2 way toggle switch
￥:240.00

AB-G4-0058

小板20A双极开关带指示灯 ￥:165.00
20A swich with indicator light
小板45A双极开关带指示灯 ￥:185.00
45A swich with indicator light

AB-G4-0059

小板45A双极开关带指示灯
45A swich with indicator light
￥:185.00

AB-G4-0060

小板16A卷帘门复位开关
16A shutter reset switch
￥:195.00

AB-G4 Tempered glass volcanic grey 钢化玻璃火山灰

AB-G4-0061
小板16A德式插座
German socket
¥:146.00

AB-G4-0062
小板16A法式插座
French socket
¥:146.00

AB-G4-0063
小板16A俄式插座
Russian socket
¥:146.00

AB-G4-0064
小板16A以色列插座
Israel socket
¥:165.00

AB-G4-0065
小板16A意大利+德式插座
Italy+German socket
¥:165.00

AB-G4-0066
小板10A二极插座
10A 2 pole socket
¥:126.00

AB-G4-0067
小板10A二二极插座
10A Double 2 pole socket
¥:139.00

AB-G4-0068
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:139.00

AB-G4-0069
小板10A一位开关带二二极座
1 gang switch and 4 pole socket
¥:146.00

AB-G4-0070
小板16A多功能三极插座
16A MF 3 pin socket
¥:109.00

AB-G4-0071
小板13A二三极多功能插座
5 pin multi-function socket
¥:128.00

AB-G4-0072
小板13A错位多五孔插座
Dislocation multi 5 pin multi function socket
¥:128.00

AB-G4-0073
小板13A方角插座
13A square corner socket
¥:109.00

AB-G4-0074
小板15A圆角插座
15A 3 round pins socket
¥:128.00

AB-G4-0075
小板15A美标扁三极插座
15A triode flat American 3 pin universal socket
¥:128.00

AB-G4-0076
小板15A泰式插座
15A Thai socket
¥:128.00

AB-G4-0077
小板15A泰式六孔插座
Small plate 15A Thai six hole socket
¥:138.00

AB-G4-0078
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:136.00

AB-G4-0079
小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pin socket
¥:143.00

AB-G4-0080
小板一位开关带16A多功能插座
1 gang switch and 3 pin MF socket
¥:143.00

AB-G4-0081
小板一位开关带13A方角插座(带指示灯)
1 gang switch and 13A square pin socket withindicator light
¥:139.00

AB-G4-0082
小板一位开关带15A圆孔插座(带指示灯)
1 gang switch and 15A 3 round pins socket with indicator light
¥:146.00

AB-G4-0083
小板一位开关带16A多功能插座（带指示灯）
1 gang switch and 16A MF 3 pin socket with light
¥:146.00

AB-G4-0084
小板一位开关带13A多功能五孔插座(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
¥:152.00

AB-G4-0085
小板16A德式插座带二位USB
2 USB witch German socket
¥:225.00

AB-G4-0086
小板16A法式插座带二位USB
2 USB witch French socket
¥:225.00

AB-G4-0087
小板16A德式插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:225.00

AB-G4-0088
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:225.00

AB-G4-0089
小板16A一位开关带德式插座
1 gang German socket
¥:165.00

AB-G4-0090
小板16A一位开关带法式插座
1 gang French socket
¥:165.00

AB-G4-0091
小板16A德式插座带防水
German socket and Waterproof belt
¥:155.00

AB-G4-0092
小板16A法式插座带防水
French socket and Waterproof belt
¥:155.00

AB-G4-0093
小板二位USB带13A方角插座（横）
2 USB with 13A square corner socket with swith
¥:225.00

AB-G4-0094
小板15A美式+USB/type-c
15A American Standard + USB / type-C
¥:225.00

AB-G4-0095
小板15A泰式+USB/Type-c
15A Thai + USB / type-C
¥:225.00

AB-G4-0096
小板二位USB带13A方角插座（带保护门）
2 USB with 13A square corner socket with flip cover
¥:225.00

AB-G4-0097
小板二位USB带13A多功能插座（带保护门）
2 USB with 3 pin multi-purpose socket with flip cover
¥:225.00

AB-G4-0098
小板一位开关13A多功能插座带指示灯+二位USB
2 USB with 13A aquare comer socket with flip cover
¥:225.00

AB-G4-0099
小板一位开关13A方角插座带指示灯+二位USB
Small board one position switch 13A square corner socket with indicator light + two position USB
¥:225.00

AB-G4-0100
小板13A多功能带Type-c+USB
13A multifunction with type-C + USB
¥:225.00

AB-G4-0101
小板13A方角插带Type-c+USB
13A square angle band type-C + USB
¥:225.00

AB-G4-0102
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with Type-c+USB(with light)
¥:225.00

AB-G4-0103
小板二位USB带13A多功能插座带小开关（竖）
2 USB with Three very multi-purpose socket with switch
¥:235.00

AB-G4-0104
小板一位开关13A方插带Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:225.00

AB-G4-0105
小板二位USB带13A方角插座带小开关（竖）
2 USB with 13A square corner socket with swith
¥:235.00

AB-G4-0106
小板15A美式扁插+二位USB插座
15A American Standard + 2USB
¥:225.00

AB-G4-0107
小板15A泰式+二位USB插座
15A Thai + 2USB
¥:225.00

AB-G4-0108
小板二位USB带13A多功能插座（横）
2 USB with 3 pin multi-purpose socket
¥:225.00

AB-G4-0109
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:185.00

AB-G4-0110
小板二位USB带10A二三极插座带开关
2 USB and 5 pin socket with switch
¥:195.00

AB-G4-0111
小板10五孔插座带USB +Type-c (10W)
10A 5 pole socket with USB type-C(10W)
¥:185.00
小板10五孔插座带USB +Type-C(18W)
10A 5 pole socket with USB type-C(18W)
¥:290.00

AB-G4-0112
小板一位开关带13A多功能五孔插座带USB
1 gang swich and 5 pin multi-function socket with USB and indicator light
¥:230.00

AB-G4-0113
小板13A二三极多功能插座+二位USB
Small board 13A two three pole multi function socket + 2-bit USB
¥:180.00

AB-G4-0114
小板13A二三极多功能插座+二位USB带小开关
Small board 13A two three pole multi-function socket + 2-bit USB With small switch
¥:190.00

AB-G4-0115
小板13A多功能五孔带USB+Type-C(10W)
13A MF 5 pin socket USB+type-C(10W)
¥:180.00
小板13A多功能五孔带USB+Type-C(18W)
13A MF 5 pin socket USB+type-C(18W)
¥:290.00

AB-G4-0116
小板一位电视插座
TV socket
¥:128.00

AB-G4-0117
小板一位电话插座 telephone socket ¥:128.00
小板一位电脑插座 computer socket ¥:138.00
小板一位电脑插座(超六类) computer socket(6) ¥:178.00

AB-G4-0118
小板双电视插座
Two TV socket
¥:158.00

AB-G4-0119
小板双电话插座 Two telephone socket ¥:158.00
小板双电脑插座 Two computer socket ¥:178.00
小板双电脑插座(超六类) Two computer socket(6) ¥:258.00
小板电话电脑插座 telephone+computer socket ¥:168.00
小板电话电脑插座(超六类) telephone+computer socket(6) ¥:208.00

AB-G4-0120
小板电视电话插座 TV +telephone socket ¥:158.00
小板电视电脑插座 TV +computer socket ¥:168.00
小板电视电脑插座(超六类) TV +computer socket(6) ¥:208.00

AB-G4 Tempered glass volcanic grey 钢化玻璃火山灰

AB-G4-0121

小板一位电话带USB插座 ¥:280.00
TEL+USB socket
小板一位电脑带USB插座 ¥:290.00
computer+USB socket
小板一位电脑带USB插座(超六类) ¥:330.00
computer+USB socket(6)

AB-G4-0122

小板一位TV+FM
TV and FM
¥:198.00

AB-G4-0123

小板一位卫星插座
Satellite socket
¥:148.00

AB-G4-0124

小板二位卫星插座
Double satellite socket
¥:175.00

AB-G4-0125

小板卫星+电视插座
Satellite and TV socket
¥:166.00

AB-G4-0126

小板卫星带电话插座 ¥:166.00
Satellite and telephone socket
小板卫星带电脑插座 ¥:175.00
Satellite and computer socket
小板卫星带电脑插座(超六类) ¥:215.00
Satellite and computer socket(6)

AB-G4-0127

小板二极插座带电视插座
2 pin socket with TV
¥:290.00

AB-G4-0128

小板二极插座带电话插座 ¥:290.00
2 pin socket with telephone
小板二极插座带电脑插座 ¥:290.00
2 pin socket with computer
小板二极插座带电脑插座(超六类) ¥:330.00
2 pin socket with computer

AB-G4-0129

小板一位光纤插座
Optical fiber socket
¥:190.00

AB-G4-0130

小板二位USB插座
Double USB socket
¥:230.00

AB-G4-0131

小板单联音响插座
Single audio socket
¥:202.00

AB-G4-0132

小板双联音响插座
Double audio socket
¥:275.00

AB-G4-0133

触摸延时开关（节能）
Touch delay delay switch
¥:202.00

AB-G4-0134

声光控延时开关（节能）
Sound-light controlled delay switch (energy saving)
¥:202.00

AB-G4-0135

红外线人体感应开关
Human body induction
¥:220.00

AB-G4-0136

凹型地脚灯（亮光/暖光）
The footlights
¥:195.00

AB-G4-0137

凹型红外线人体感应地脚灯
（亮光/暖光）
The human body induction footlights
¥:330.00

AB-G4-0138

平面地脚灯（亮光/暖光）
footlights
¥:195.00

AB-G4-0139

叮咚门铃
Ding dong doorbell
¥:245.00

AB-G4-0140

机械式40A插卡取电 ¥:280.00
Mechanical card for electricity
感应式低频40A插卡取电 ¥:400.00
Low frequency induction card
感应式高频40A插卡取电 ¥:460.00
High freqency induction card for electricity

AB-G4-0141

紧急呼叫开关
Emergency call seitch
¥:210.00

AB-G4-0142

请勿打扰请即清理门铃开关
（按键式）
Do not disturb plese namely cleaning please+late doorbell "button"
¥:250.00

AB-G4-0143

请勿打扰门铃开关(按键式)
Do not disturb+doorbell "button"
¥:385.00

AB-G4-0144

请勿打扰请即清理门铃开关
(按键式)
Do not disturb plese namely cleaning please "button"
¥:475.00

AB-G4-0145

智能音乐控制开关
intelligent music cintrol seitch
¥:2950.00

AB-G4-0146

温度控制调节开关
Temperature control seitch
¥:800.00

AB-G4-0147

温度控制调节开关
Tuning switchcontrol seitch
¥:850.00

AB-G4-0148

调音开关
Tuning switch
¥:260.00

AB-G4-0149

调光开关300W ¥:198.00
Dimming 300W
调光开关600W ¥:225.00
Dimming 600W
调光开关1000W ¥:252.00
Dimming 1000W

AB-G4-0150

调速开关300W ¥:198.00
Speed 300W
调速开关600W ¥:225.00
Speed 600W
调速开关1000W ¥:252.00
Speed 1000W

AB-G4-0151

一位开关带调光开关500W
1 gang with dimmer switch
¥:212.00

AB-G4-0152

一位开关带调速开关500W
1 gang with speed switch
¥:212.00

AB-G4-0153

13A开关带保险丝（带指示灯）
13A switch with fuse with neon
¥:239.00

AB-G4-0154

小板20A出线柱
20A outgoing post
¥:221.00

AB-G4-0155

剃须插座
Shaving socket
¥:450.00

AB-G4-0156

USB+电脑插座+无线路由
USB+computer socket wireless router
¥:800.00

AB-G4-0157

蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio+3.5+2USB+HDMI
¥:5250.00

AB-G4-0158

HDMI
¥:288.00

AB-G4-0159

USB+Type-c
¥:324.00

AB-G4-0160

HDMI+USB
¥:288.00

AB-G4-0161

HDMI+USB+3.5音频
HDMI+USB+3.5
¥:288.00

AB-G4-0162

VGA+USB+3.5音频
VGA+USB+3.5
¥:288.00

AB-G4-0163

AV+3.5音频
AV +3.5
¥:288.00

AB-G4-0164

VGA+AV音频接口
VGA+AV audio interface
¥:288.00

AB-G4-0165

HDMI+AV音频接口
HDMI+AV audio interface
¥:288.00

AB-G4-0166

二分之一AV音频+卫星
Half AV audio interface+Satellite
¥:288.00

AB-G4-0167

二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:288.00

AB-G4-0168

二分之一VGA+TV
Half VGA+TV
¥:288.00

AB-G4-0169

二分之一VGA+电脑
Half VGA+Computer
¥:288.00

AB-G4-0170

二分之一VGA+USB
Half VGA+USB
¥:288.00

AB-G4-0171

二分之一VGA+HDMI
Half VGA+HDIM
¥:288.00

AB-G4-0172

45A出线柱
45A Outlet
¥:248.00

AB-G4-0173

空白面板
Blank plate
¥:102.00

AB-G4-0174

大板二位双极开关带二位13A方角插座（指示灯）
Large board two position bipolar switch with two position 13A square angle Socket (indicator)
¥:258.00

AB-G4-0175

大板二位开关带二位16A多功能插座（带指示灯）
147 Tow switch and double 16A MF 3pin socket with light
¥:258.00

AB-G4-0176

147 二位开关带二位13A方角插座带二位USB（带指示灯）
147 Tow switch and double 13A square corner socker with two USB and indicator light
¥:358.00

AB-G4-0177

大板二位开关带二位16A多功能插座+双USB（带指示灯）
147 Tow switch and double 16A MF socket + 2USB with light
¥:358.00

AB-G4-0178

大板147型二位开关带二位13A方插+USB/Type-c(指示灯)
Large board 147 two position switch with two position 13A square plug +USB / type-C (indicator)
¥:388.00

AB-G4-0179

大板147型二位开关带二位13A多功能+USB/Type-c(指示灯)
Large plate 147 two position switch with two position 13A multifunction +USB / type-C (indicator)
¥:388.00

AB-G4-0180

147型45A双极开关+一开13A方角插带灯(炉具开关)
147 type 45A bipolar switch + 13A square angle plug With light (stove switch)
¥:310.00

AB-G4 Tempered glass volcanic grey 钢化玻璃火山灰

AB-G4-0181

147型45A双极开关带指示灯
147 type 45A bipolar switch with indicator light
¥:280.00

AB-G4-0182

147型空白面板
147 blank panel
¥:185.00

AB-G4-0183

小板147型16A二位开关单控
Small plate 147 type 16A two position switch single control
¥:212.00
小板147型16A二位开关双控
Small plate 147 type 16A two position switch double control
¥:218.00

AB-G4-0184

小板147型16A三位开关单控
Small plate 147 type 16A 3 gang 2 way switch
¥:230.00
小板147型16A三位开关双控
Small plate 147 type 16A 3 gang 2 way switch
¥:239.00

AB-G4-0185

小板147型16A四位开关单控
Small plate 147 type 16A 4 gang 1 way switch
¥:248.00
小板147型16A四位开关双控
Small plate 147 type 16A 4 gang 1 way switch
¥:259.00

AB-G4-0186

小板147型16A五位开关单控
Small plate 147 type 16A 5 gang 1 way switch
¥:266.00
小板147型16A五位开关双控
Small plate 147 type 16A 5 gang 2 way switch
¥:280.00

AB-G4-0187

小板147型16A六位开关单控
Small plate 147 type 16A 6 gang 1 way switch
¥:280.00
小板147型16A六位开关双控
Small plate 147 type 16A 6 gang 2 way switch
¥:301.00

AB-G4-0188

小板147型16A七位开关单控
Small plate 147 type 16A 7 gang 1 way switch
¥:302.00
小板147型16A七位开关双控
Small plate 147 type 16A 7 gang 2 way switch
¥:321.00

AB-G4-0189

小板147型16A八位开关单控
Small plate 147 type 16A 8 gang 1 way switch
¥:320.00
小板147型16A八位开关双控
1Small plate 147 type 16A 8 gang 2 way switch
¥:342.00

AB-G4-0190

147 二位16A多功能三极插座
147 Double 13A MF 3 pin socket
¥:248.00

AB-G4-0191

147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:281.00

AB-G4-0192

小板147型二位15A美标扁插座
Small plate 147 two position 15A American standard flat socket
¥:279.00

AB-G4-0193

147 二位15A泰式多功能六孔插座
147 Double 15A Thai MF six-hole socket
¥:279.00

AB-G4-0194

147 二位13A方角插座
147 Double 13A square comer
¥:248.00

AB-G4-0195

147 二位15A圆孔插座
147 Double 15A 3 round pins socket
¥:279.00

AB-G4-0196

小板147型二位13A错位多功能二三极插座
147 type Double 13A dislocation MF 5 pole socket
¥:299.00

AB-G4-0197

147型小板二位10A二三极插座
147 type Double 10A two and three pole socket
¥:225.00

AB-G4-0198

147 二位开关带二位13A方角插座
147 Tow switch and double 13A square corner socket
¥:257.00

AB-G4-0199

147 二位开关带二位13A多功能插座
147 Tow switch and double 13A MF 3 pin socket with light
¥:257.00

AB-G4-0200

小板147二位开关二位13A多功能二三极插座
Small board 147 two position switch two position 13A multi-function two three pole socket
¥:284.00

AB-G4-0201

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 13A square comer socket with indicator light
¥:258.00

AB-G4-0202

147 二位开关带二位13A多功能插座（带指示灯）
147 Tow switch and double 13A MF socket with light
¥:258.00

AB-G4-0203

147 二位开关带二位13A方角插座带二位USB
147 Tow switch and double 13A square comer socket with 2USB
¥:358.00

AB-G4-0204

147 二位开关带二位13A多功能带二位USB
147 Tow switch and double 13A MF socket+2USB
¥:358.00

AB-G4-0205

147二位开关二位13A方插+USB/Type-c（小板）
147 two switch Double 13A square plug+ USB/type-C
¥:358.00

AB-G4-0206

147二位开关二位13A多功能+USB/Type-c（小板）
147 two switch Double 13A MF+USB / type-C
¥:358.00



AB-G4-0207

147 二位开关带二位15A圆角插座（带指示灯）
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:293.00

AB-G4-0208

147 二位开关带二位13A方角插座（带指示灯）
147 two switch and double 13A square Angle socket (with neon)
¥:293.00

AB-G4-0209

147 四孔剃须插座
147 two shaving socket
¥:612.00

AB-G4-0210

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 kitchen switch
¥:346.00

AB-G4-0211

147 45A开关+一位开关13A方角插带指示灯(组合厨房开关)
147 kitchen switch
¥:346.00

AB-G4-0212

147型45A双极开关+一开13A方角插带灯（炉具开关）
147 type 45A bipolar switch +13A square angle plug With light (stove switch)
¥:374.00

AB-G4-0213

147型45A双极开关带指示灯
147 type 45A bipolar switch with indicator light
¥:324.00

AB-G4-0214

147 16A二位德式插座
147 Double Geman socket
¥:293.00

AB-G4-0215

147 16A二位法式插座
147 Double French socket
¥:293.00

AB-G4-0216

小板147型连体二位德标插座
Small plate 147 connected two position German standard socket
¥:293.00

AB-G4-0217

小板147型连体二位法标插座
Small plate 147 connected two position normal socket
¥:293.00

AB-G4-0218

147二位16A德式插座+USB/Type-c(小板）
147 double 16A German with USB/Type-c
¥:390.00

AB-G4-0219

147二位16A法式插座+USB/Type-c(小板）
147 double 16A French with USB/Type-c
¥:390.00

AB-G4-0220

小板147型二位16A德式+二位USB
147 double 16A German+2USB
¥:369.00

AB-G4-0221

小板147型二位16A德式+二位USB
147 Double 16A German+2USB
¥:369.00

AB-G4-0222

147 四位USB插座
147 4 USB socket
¥:477.00

AB-G4-0223

147 二位多功能插座+4USB
147 2-bit multi-function socket + 4USB
¥:414.00

AB-G4-0224

147 二位13A方角插座+4USB
147 two bit 13A square socket +4USB
¥:414.00

AB-G4-0225

小板147型13A方角插座+二位USB
Small board 147 type 13A square corner socket + 2USB
¥:376.00

AB-G4-0226

147 一位16A多功能插座+二位USB插座
147 13A MF 3 pin socket + 2USB socket
¥:376.00

AB-G4-0227

147型二位开关带二位13A多功能五孔+双USB
147 two switch and double 13A MF 5 pin + 2USB
¥:374.00

AB-G4-0228

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two position switch with two position 13A multifunction Five hole socket + 2 USB (with indicator)
¥:522.00

AB-G4-0229

147 二位13A多功能五孔插座+四位USB
147 double 5 pin multi-function socket+4USB
¥:414.00

AB-G4-0230

147型二位13A多功能五孔带4USB+小开关(带指示灯)
147 double 13A MF 5 pin with 4USB+ small switch (w/neon)
¥:432.00

AB-G4-0231

小板147型二位开关二位13A多功能五孔+USB/Type-c
147 two switch and double 13A MF 5 pin + USB / type-C
¥:495.00

AB-G4-0232

小板147型二位开关带二位13A多功能插座+4USB带指示灯
147 two switch and double 13A MF + 4USB (with neon)
¥:432.00

AB-G4-0233

小板147型二位开关带二位13A方角插座+4USB带指示灯
147 two switch and double 13A square Angle Socket +4USB (with neon)
¥:432.00

AB-G4-0234

147型二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 two switch double German socket +USB/Type-c (with neon)
¥:495.00

AB-G4-0235

147型二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 two switch double French socket +USB/Type-c (with neon)
¥:495.00

AB-G4-0236

147型二位开关二位16A德式插座（带指示灯）
147 two switch double German socket (with neon)
¥:329.00

AB-G4-0237

147型二位开关二位16A德式插座（带指示灯）
147 two switch double French socket (with neon)
¥:329.00

AB-G4-0238

147型二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket with neon+ 2USB
¥:405.00

AB-G4-0239

147型二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch with double 16A French socket with 2USB (with neon)
¥:405.00

AB-G4-0240

小板147型空白面板
147 Blank plate
¥:167.00

Zigbee智能按键开关

Zigbee Intelligent button switch

Zigbee一开

￥1150.00

Zigbee二开

￥1250.00



Zigbee三开

￥1350.00

二三极USB/Type-c+开关

￥240.00

AB-G5 钢化玻璃水晶蓝

Tempered glass crystal blue



时尚玻璃
每面都是惊艳

- 语音/APP/轻触机械控制 Voice /APP/ touch mechanical control
- 情景模式/联动/定时 Scenario mode/Linkage/timing
- 支持多款AL音响 Support a variety of AL audio
- 涂鸦无线场景开关(单火零火通用) Doodle wireless scene switch (Single fire and zero fire universal)

AB-G5 Tempered glass crystal blue 钢化玻璃水晶蓝

AB-G5-0001

一位触摸开关(零火线) ¥:400.00
1 gang 1 way touch switch
蓝牙WIFI一位触摸开关(零火版) ¥:500.00
1 gang 1 way touch switch
涂鸦Zigbee一位触摸开关(零火版) ¥:600.00
1 gang 1 way touch switch

AB-G5-0002

二位触摸开关（零火版） ¥:450.00
2 gang 1 way touch switch
蓝牙WIFI二位触摸开关(零火版) ¥:550.00
2 gang 1 way touch switch
涂鸦Zigbee二位触摸开关(零火版) ¥:650.00
2 gang 1 way touch switch

AB-G5-0003

三位触摸开关（零火版） ¥:500.00
3 gang 1 way touch switch
蓝牙WIFI三位触摸开关(零火版) ¥:600.00
3 gang 1 way touch switch
涂鸦Zigbee三位触摸开关(零火版) ¥:700.00
3 gang 1 way touch switch

AB-G5-0004

四位触摸开关（零火版） ¥:550.00
4 gang 1 way touch switch
蓝牙WIFI四位触摸开关(零火版) ¥:650.00
4 gang 1 way touch switch
涂鸦Zigbee四位触摸开关(零火版) ¥:750.00
4 gang 1 way touch switch

AB-G5-0005

大板16A一位开关单控 ¥:86.00
Large panel 16A 1 gang 1 way switch
大板16A一位开关双控 ¥:90.00
Large panel 16A 1 gang 2 way switch
大板16A一位开关多控 ¥:123.00
Large panel 16A 1 gang 3 way switch

AB-G5-0006

大板16A二位开关单控 ¥:109.00
Large panel 16A 2 gang 1 way switch
大板16A二位开关双控 ¥:110.00
Large panel 16A 2 gang 2 way switch
大板16A二位开关多控 ¥:158.00
Large panel 16A 2 gang 3 way switch

AB-G5-0007

大板16A三位开关单控 ¥:139.00
Large panel 16A 3 gang 1 way switch
大板16A三位开关双控 ¥:156.00
Large panel 16A 3 gang 1 way switch

AB-G5-0008

大板16A四位开关单控 ¥:169.00
Large panel 16A 4 gang 1 way switch
大板16A四位开关双控 ¥:183.00
Large panel 16A 4 gang 2 way switch

AB-G5-0009

大板16A百叶窗升降开关
Large panel louver window lifter switch
¥:145.00

AB-G5-0010

大板16A门控开关
Large panel gating switch
¥:109.00

AB-G5-0011

大板16A英式门控开关
Large panel British gating switch
¥:109.00

AB-G5-0012

大板16A门铃开关
Large panel doorbell switch
¥:109.00

AB-G5-0013

大板20A双极开关带指示灯 ¥:168.00
20A bipolar switch with indicator light
大板32A双极开关带指示灯 ¥:186.00
32A bipolar switch with indicator light

AB-G5-0014

大板45A双极开关带指示灯
45A bipolar switch with indicator light
¥:200.00

AB-G5-0015

大板16A三极插座
16A 3 pole socket
¥:109.00

AB-G5-0016

大板16A多功能插座
16A 3 pin universal socket
¥:109.00

AB-G5-0017

大板10A二三极插座
10A 5 pole socket
¥:93.00

AB-G5-0018

大板10A错位二三极插座
10A Two or three pole socket
¥:117.00

AB-G5-0019

大板16A多功能五孔插座
16A MF 5 pin socket
¥:128.00

AB-G5-0020

大板10A二二三极插座
10A 7 pole socket
¥:128.00

AB-G5-0021

大板13A方角插座
13A square corner socket
¥:109.00

AB-G5-0022

大板二位USB带16A多功能五孔插座
2 USB with 5 pin multi-function socket
¥:213.00

AB-G5-0023

大板16A一位开关单控带16A三极插座
1gang1 way swith and 16A 3 pole socket

大板16A一位开关双控带16A三极插座
1gang2 way swith and 16A 3 pole socket
¥:143.00

AB-G5-0024

大板16A一位开关单控带16A三极插座
1gang2 way swith and 16A 3 pole socket
¥:140.00

大板16A一位开关双控带16A三极插座
1gang 2 way switch and 5 pole socket
¥:143.00

AB-G5-0025

大板10A二位开关单控带二三极插座
2 gang 1 way switch and 5 pole socket

大板10A二位开关双控带二三极插座
2 gang 2 way switch and 5 pole socket
¥:167.00

AB-G5-0026

大板一位开关带16A三极多功能插座(带指示灯）
1 gang switch and 16A 3 pin multi-purpose socket with indicator light
¥:146.00

AB-G5-0027

大板一位双极开关带13A方角插座（指示灯）
Large board one position bipolar switch with 13A square angle socket (indicator light)
¥:139.00

AB-G5-0028

大板一位开关带15A圆孔插座(带指示灯）
1 gang weitch and 15A 3 square pin socket with indicator light
¥:146.00

AB-G5-0029

大板一位开关带16A二三极多功能插座(带指示灯）
1 gang swith and 5 pin multi-function socket with indicator light
¥:152.00

AB-G5-0030

大板一位开关带13A多功能插座+二位USB（指示灯）
Large board one position switch with 13A multi-function socket + 2USB (indicator)
¥:295.00

AB-G5-0031

大板一位开关带13A方角插+二位USB（指示灯）
Board one position switch with 13A square angle plug + two position USB (indicator)
¥:295.00

AB-G5-0032

大板16A德式插座
Large board 16A German socket
¥:163.00

AB-G5-0033

大板16A法式插座
Large plate 16A French socket
¥:163.00

AB-G5-0034

大板16A俄式插座
Large board 16A Russian socket
¥:163.00

AB-G5-0035

大板16A德式插座+二位USB
German socket+2 USB
¥:255.00

AB-G5-0036

大板16A法标插座+二位USB
French socket + 2 USB
¥:255.00

AB-G5-0037

大板16A德标插座+USB/Type-c
Large board 16A German socket + USB / type-C
¥:255.00

AB-G5-0038

大板16A法式插座+USB/Type-c
Large board 16A French socket + USB / type-C
¥:255.00

AB-G5-0039

大板一位电视插座
TV socket
¥:128.00

AB-G5-0040

大板一位电话插座 ¥:128.00
telephone socket
大板一位电脑插座 ¥:138.00
computer socket
大板一位电脑插座（超六类） ¥:178.00
computer socket(6)

AB-G5-0041

大板一位电视电话插座 ¥:158.00
TV +telephone socket
大板一位电视电脑插座 ¥:168.00
TV +computer socket
大板一位电视电脑插座（超六类） ¥:208.00
TV +computer socket(6)

AB-G5-0042

大板二位电视插座
Two TV socket
¥:158.00

AB-G5-0043

大板二位电话插座 ¥:158.00
Two TV socket
大板二位电脑插座 ¥:178.00
Two computer socket
大板二位电脑插座（超六类） ¥:258.00
Two computer socket(6)
大板电话+电脑插座 ¥:168.00
telephone+computer socket
大板电话+电脑插座（超六类） ¥:208.00
telephone+computer socket(6)

AB-G5-0044

大板空白面板
Large blank panel
¥:80.00

AB-G5-0045

小板16A一位开关单控 ¥:87.00
16A 1 gang 1 way switch
小板16A一位开关双控 ¥:90.00
16A 1 gang 2 way switch
小板16A一位开关多控 ¥:123.00
16A 1 gang more way switch

AB-G5-0046

小板16A二位开关单控 ¥:109.00
16A 2 gang 1 way switch
小板16A二位开关双控 ¥:110.00
16A 2 gang 2 way switch
小板16A二位开关多控 ¥:158.00
16A 2 gang more way switch

AB-G5-0047

小板16A三位开关单控 ¥:139.00
16A 3 gang 1 way switch
小板16A三位开关双控 ¥:156.00
16A 3 gang 2 way switch

AB-G5-0048

小板16A四位开关单控 ¥:169.00
16A 4 gang 1 way switch
小板16A四位开关双控 ¥:183.00
16A 4 gang 2 way switch

AB-G5-0049

小板16A三位开关多控
16A 3 gang 3 way switch
¥:230.00

AB-G5-0050

小板16A百叶窗升降开关
louver window lifter switch
¥:145.00

AB-G5-0051

小板16A门控开关
gating switch
¥:109.00

AB-G5-0052

小板16A英式门控开关
British gating switch
¥:109.00

AB-G5-0053

小板16A门铃开关
doorbell switch
¥:109.00

AB-G5-0054

小板16A拨动一位开关单控
1 gang 1 way toggle switch
¥:175.00
小板16A拨动一位开关双控
1 gang 2 way toggle switch
¥:180.00

AB-G5-0055

小板16A拨动二位开关单控
2 gang 1 way toggle switch
¥:190.00
小板16A拨动二位开关双控
2 gang 2 way toggle switch
¥:200.00

AB-G5-0056

小板16A拨动三位开关单控
3 gang 1 way toggle switch
¥:205.00
小板16A拨动三位开关双控
3 gang 2 way toggle switch
¥:220.00

AB-G5-0057

小板16A拨动四位开关单控
4 gang 1 way toggle switch
¥:220.00
小板16A拨动四位开关双控
4 gang 2 way toggle switch
¥:240.00

AB-G5-0058

小板20A双极开关带指示灯 ¥:165.00
20A swich with indicator light
小板45A双极开关带指示灯 ¥:185.00
45A swich with indicator light

AB-G5-0059

小板45A双极开关带指示灯
45A swich with indicator light
¥:185.00

AB-G5-0060

小板16A卷帘门复位开关
16A shutter reset switch
¥:195.00

AB-G5 Tempered glass crystal blue 钢化玻璃水晶蓝

AB-G5-0061
小板16A德式插座
German socket
¥:146.00

AB-G5-0062
小板16A法式插座
French socket
¥:146.00

AB-G5-0063
小板16A俄式插座
Russian socket
¥:146.00

AB-G5-0064
小板16A以色列插座
Israel socket
¥:165.00

AB-G5-0065
小板16A意大利+德式插座
Italy+German socket
¥:165.00

AB-G5-0066
小板10A二极插座
10A 2 pole socket
¥:126.00

AB-G5-0067
小板10A二二极插座
10A Double 2 pole socket
¥:139.00

AB-G5-0068
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:139.00

AB-G5-0069
小板10A一位开关带二二极座
1 gang switch and 4 pole socket
¥:146.00

AB-G5-0070
小板16A多功能三极插座
16A MF 3 pin socket
¥:109.00

AB-G5-0071
小板13A二三极多功能插座
5 pin multi-function socket
¥:128.00

AB-G5-0072
小板13A错位多五孔插座
Dislocation multi 5 pin multi function socket
¥:128.00

AB-G5-0073
小板13A方角插座
13A square corner socket
¥:109.00

AB-G5-0074
小板15A圆角插座
15A 3 round pins socket
¥:128.00

AB-G5-0075
小板15A美标扁三极插座
15A triode flat American 3 pin universal socket
¥:128.00

AB-G5-0076
小板15A泰式插座
15A Thai socket
¥:128.00

AB-G5-0077
小板15A泰式六孔插座
Small plate 15A Thai six hole socket
¥:138.00

AB-G5-0078
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:136.00

AB-G5-0079
小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pin socket
¥:143.00

AB-G5-0080
小板一位开关带16A多功能插座
1 gang switch and 3 pin MF socket
¥:143.00

AB-G5-0081
小板一位开关带13A方角插座(带指示灯)
1 gang switch and 13A square pin socket withindicator light
¥:139.00

AB-G5-0082
小板一位开关带15A圆孔插座(带指示灯)
1 gang switch and 15A 3 round pins socket with indicator light
¥:146.00

AB-G5-0083
小板一位开关带16A多功能插座（带指示灯）
1 gang switch and 16A MF 3 pin socket with light
¥:146.00

AB-G5-0084
小板一位开关带13A多功能五孔插座(带指示灯)
1 gang switch and 5 pin multi-function socket with indicator light
¥:152.00

AB-G5-0085
小板16A德式插座带二位USB
2 USB witch German socket
¥:225.00

AB-G5-0086
小板16A法式插座带二位USB
2 USB witch French socket
¥:225.00

AB-G5-0087
小板16A德式插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:225.00

AB-G5-0088
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:225.00

AB-G5-0089
小板16A一位开关带德式插座
1 gang German socket
¥:165.00

AB-G5-0090
小板16A一位开关带法式插座
1 gang French socket
¥:165.00

AB-G5-0091
小板16A德式插座带防水
German socket and Waterproof belt
¥:155.00

AB-G5-0092
小板16A法式插座带防水
French socket and Waterproof belt
¥:155.00

AB-G5-0093
小板二位USB带13A方角插座（横）
2 USB with 13A square corner socket with swith
¥:225.00

AB-G5-0094
小板15A美式+USB/type-c
15A American Standard + USB / type-C
¥:225.00

AB-G5-0095
小板15A泰式+USB/Type-c
15A Thai + USB / type-C
¥:225.00

AB-G5-0096
小板二位USB带13A方角插座（带保护门）
2 USB with 13A square corner socket with flip cover
¥:225.00

AB-G5-0097
小板二位USB带13A多功能插座（带保护门）
2 USB with 3 pin multi-purpose socket with flip cover
¥:225.00

AB-G5-0098
小板一位开关13A多功能插座带指示灯+二位USB
2 USB with 13A aquare comer socket with flip cover
¥:225.00

AB-G5-0099
小板一位开关13A方角插座带指示灯+二位USB
Small board one position switch 13A square corner socket with indicator light + two position USB
¥:225.00

AB-G5-0100
小板13A多功能带Type-c+USB
13A multifunction with type-C + USB
¥:225.00

AB-G5-0101
小板13A方角插带Type-c+USB
13A square angle band type-C + USB
¥:225.00

AB-G5-0102
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with Type-c+USB(with light)
¥:225.00

AB-G5-0103
小板二位USB带13A多功能插座带小开关（竖）
2 USB with Three very multi-purpose socket with switch
¥:235.00

AB-G5-0104
小板一位开关13A方插带Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:225.00

AB-G5-0105
小板二位USB带13A方角插座带小开关（竖）
2 USB with 13A square corner socket with swith
¥:235.00

AB-G5-0106
小板15A美式扁插+二位USB插座
15A American Standard + 2USB
¥:225.00

AB-G5-0107
小板15A泰式+二位USB插座
15A Thai + 2USB
¥:225.00

AB-G5-0108
小板二位USB带13A多功能插座（横）
2 USB with 3 pin multi-purpose socket
¥:225.00

AB-G5-0109
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:185.00

AB-G5-0110
小板二位USB带10A二三极插座带开关
2 USB and 5 pin socket with switch
¥:195.00

AB-G5-0111
小板10五孔插座带USB +Type-c (10W)
10A 5 pole socket with USB type-C(10W)
¥:185.00
小板10五孔插座带USB +Type-C(18W)
10A 5 pole socket with USB type-C(18W)
¥:290.00

AB-G5-0112
小板一位开关带13A多功能五孔插座带USB
1 gang swich and 5 pin multi-function socket with USB and indicator light
¥:230.00

AB-G5-0113
小板13A二三极多功能插座+二位USB
Small board 13A two three pole multi function socket + 2-bit USB
¥:180.00

AB-G5-0114
小板13A二三极多功能插座+二位USB带小开关
Small board 13A two three pole multi-function socket + 2-bit USB With small switch
¥:190.00

AB-G5-0115
小板13A多功能五孔带USB+Type-C(10W)
13A MF 5 pin socket USB+type-C(10W)
¥:180.00
小板13A多功能五孔带USB+Type-C(18W)
13A MF 5 pin socket USB+type-C(18W)
¥:290.00

AB-G5-0116
小板一位电视插座
TV socket
¥:128.00

AB-G5-0117
小板一位电话插座 telephone socket ¥:128.00
小板一位电脑插座 computer socket ¥:138.00
小板一位电脑插座(超六类) computer socket(6) ¥:178.00

AB-G5-0118
小板双电视插座
Two TV socket
¥:158.00

AB-G5-0119
小板双电话插座 Two telephone socket ¥:158.00
小板双电脑插座 Two computer socket ¥:178.00
小板双电脑插座(超六类) Two computer socket(6) ¥:258.00
小板电话电脑插座 telephone+computer socket ¥:168.00
小板电话电脑插座(超六类) telephone+computer socket(6) ¥:208.00

AB-G5-0120
小板电视电话插座 TV +telephone socket ¥:158.00
小板电视电脑插座 TV +computer socket ¥:168.00
小板电视电脑插座(超六类) TV +computer socket(6) ¥:208.00

AB-G5 Tempered glass crystal blue 钢化玻璃水晶蓝

AB-G5-0121

小板一位电话带USB插座 ¥:280.00
TEL+USB socket
小板一位电脑带USB插座 ¥:290.00
computer+USB socket
小板一位电脑带USB插座(超六类) ¥:330.00
computer+USB socket(6)

AB-G5-0122

小板一位TV+FM
TV and FM
¥:198.00

AB-G5-0123

小板一位卫星插座
Satellite socket
¥:148.00

AB-G5-0124

小板二位卫星插座
Double satellite socket
¥:175.00

AB-G5-0125

小板卫星+电视插座
Satellite and TV socket
¥:166.00

AB-G5-0126

小板卫星带电话插座 ¥:166.00
Satellite and telephone socket
小板卫星带电脑插座 ¥:175.00
Satellite and computer socket
小板卫星带电脑插座(超六类) ¥:215.00
Satellite and computer socket(6)

AB-G5-0127

小板二极插座带电视插座
2 pin socket with TV
¥:290.00

AB-G5-0128

小板二极插座带电话插座 ¥:290.00
2 pin socket with telephone
小板二极插座带电脑插座 ¥:290.00
2 pin socket with computer
小板二极插座带电脑插座(超六类) ¥:330.00
2 pin socket with computer

AB-G5-0129

小板一位光纤插座
Optical fiber socket
¥:190.00

AB-G5-0130

小板二位USB插座
Double USB socket
¥:230.00

AB-G5-0131

小板单联音响插座
Single audio socket
¥:202.00

AB-G5-0132

小板双联音响插座
Double audio socket
¥:275.00

AB-G5-0133

触摸延时开关（节能）
Touch delay delay switch
¥:202.00

AB-G5-0134

声光控延时开关（节能）
Sound-light controlled delay switch (energy saving)
¥:202.00

AB-G5-0135

红外线人体感应开关
Human body induction
¥:220.00

AB-G5-0136

凹型地脚灯（亮光/暖光）
The footlights
¥:195.00

AB-G5-0137

凹型红外线人体感应地脚灯
（亮光/暖光）
The human body induction footlights
¥:330.00

AB-G5-0138

平面地脚灯（亮光/暖光）
footlights
¥:195.00

AB-G5-0139

叮咚门铃
Ding dong doorbell
¥:245.00

AB-G5-0140

机械式40A插卡取电 ¥:280.00
Mechanical card for electricity
感应式低频40A插卡取电 ¥:400.00
Low frequency induction card
感应式高频40A插卡取电 ¥:460.00
High freqency induction card for electricity

AB-G5-0141

紧急呼叫开关
Emergency call seitch
¥:210.00

AB-G5-0142

请勿打扰请即清理门铃开关
（按键式）
Do not disturb plese namely cleaning please+late doorbell "button"
¥:250.00

AB-G5-0143

请勿打扰门铃开关(按键式)
Do not disturb+doorbell "button"
¥:385.00

AB-G5-0144

请勿打扰请即清理门铃开关
(按键式)
Do not disturb plese namely cleaning please "button"
¥:475.00

AB-G5-0145

智能音乐控制开关
intelligent music cintrol seitch
¥:2950.00

AB-G5-0146

温度控制调节开关
Temperature control seitch
¥:800.00

AB-G5-0147

温度控制调节开关
Tuning switchcontrol seitch
¥:850.00

AB-G5-0148

调音开关
Tuning switch
¥:260.00

AB-G5-0149

调光开关300W ¥:198.00
Dimming 300W
调光开关600W ¥:225.00
Dimming 600W
调光开关1000W ¥:252.00
Dimming 1000W

AB-G5-0150

调速开关300W ¥:198.00
Speed 300W
调速开关600W ¥:225.00
Speed 600W
调速开关1000W ¥:252.00
Speed 1000W

AB-G5-0151

一位开关带调光开关500W
1 gang with dimmer switch
¥:212.00

AB-G5-0152

一位开关带调速开关500W
1 gang with speed switch
¥:212.00

AB-G5-0153

13A开关带保险丝（带指示灯）
13A switch with fuse with neon
¥:239.00

AB-G5-0154

小板20A出线柱
20A outgoing post
¥:221.00

AB-G5-0155

剃须插座
Shaving socket
¥:450.00

AB-G5-0156

USB+电脑插座+无线路由
USB+computer socket wireless router
¥:800.00

AB-G5-0157

蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio+3.5+2USB+HDMI
¥:5250.00

AB-G5-0158

HDMI
¥:288.00

AB-G5-0159

USB+Type-c
¥:324.00

AB-G5-0160

HDMI+USB
¥:288.00

AB-G5-0161

HDMI+USB+3.5音频
HDMI+USB+3.5
¥:288.00

AB-G5-0162

VGA+USB+3.5音频
VGA+USB+3.5
¥:288.00

AB-G5-0163

AV+3.5音频
AV +3.5
¥:288.00

AB-G5-0164

VGA+AV音频接口
VGA+AV audio interface
¥:288.00

AB-G5-0165

HDMI+AV音频接口
HDMI+AV audio interface
¥:288.00

AB-G5-0166

二分之一AV音频+卫星
Half AV audio interface+Satellite
¥:288.00

AB-G5-0167

二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:288.00

AB-G5-0168

二分之一VGA+TV
Half VGA+TV
¥:288.00

AB-G5-0169

二分之一VGA+电脑
Half VGA+Computer
¥:288.00

AB-G5-0170

二分之一VGA+USB
Half VGA+USB
¥:288.00

AB-G5-0171

二分之一VGA+HDMI
Half VGA+HDIM
¥:288.00

AB-G5-0172

45A出线柱
45A Outlet
¥:248.00

AB-G5-0173

空白面板
Blank plate
¥:102.00

AB-G5-0174

大板二位双极开关带二位13A方角插座（指示灯）
Large board two position bipolar switch with two position 13A square angle Socket (indicator)
¥:258.00

AB-G5-0175

大板二位开关带二位16A多功能插座（带指示灯）
147 Tow switch and double 16A MF 3pin socket with light
¥:258.00

AB-G5-0176

147 二位开关带二位13A方角插座带二位USB（带指示灯）
147 Tow switch and double 13A square comer socker with two USB and indicator light
¥:358.00

AB-G5-0177

大板二位开关带二位16A多功能插座+双USB（带指示灯）
147 Tow switch and double 16A MF socket + 2USB with light
¥:358.00

AB-G5-0178

大板147型二位开关带二位13A方插+USB/Type-c(指示灯)
Large board 147 two position switch with two position 13A square plug +USB / type-C (indicator)
¥:388.00

AB-G5-0179

大板147型二位开关带二位13A多功能+USB/Type-c(指示灯)
Large plate 147 two position switch with two position 13A multifunction +USB / type-C (indicator)
¥:388.00

AB-G5-0180

147型45A双极开关+一开13A方角插带灯(炉具开关)
147 type 45A bipolar switch + 13A square angle plug With light (stove switch)
¥:310.00

AB-G5 Tempered glass crystal blue 钢化玻璃水晶蓝

AB-G5-0181

147型45A双极开关带指示灯
147 type 45A bipolar switch with indicator light
¥:280.00

AB-G5-0182

147型空白面板
147 blank panel
¥:185.00

AB-G5-0183

小板147型16A二位开关单控
Small plate 147 type 16A two position switch single control
¥:212.00
小板147型16A二位开关双控
Small plate 147 type 16A two position switch double control
¥:218.00

AB-G5-0184

小板147型16A三位开关单控
Small plate 147 type 16A 3 gang 2 way switch
¥:230.00
小板147型16A三位开关双控
Small plate 147 type 16A 3 gang 2 way switch
¥:239.00

AB-G5-0185

小板147型16A四位开关单控
Small plate 147 type 16A 4 gang 1 way switch
¥:248.00
小板147型16A四位开关双控
Small plate 147 type 16A 4 gang 1 way switch
¥:259.00

AB-G5-0186

小板147型16A五位开关单控
Small plate 147 type 16A 5 gang 1 way switch
¥:266.00
小板147型16A五位开关双控
Small plate 147 type 16A 5 gang 2 way switch
¥:280.00

AB-G5-0187

小板147型16A六位开关单控
Small plate 147 type 16A 6 gang 1 way switch
¥:280.00
小板147型16A六位开关双控
Small plate 147 type 16A 6 gang 2 way switch
¥:301.00

AB-G5-0188

小板147型16A七位开关单控
Small plate 147 type 16A 7 gang 1 way switch
¥:302.00
小板147型16A七位开关双控
Small plate 147 type 16A 7 gang 2 way switch
¥:321.00

AB-G5-0189

小板147型16A八位开关单控
Small plate 147 type 16A 8 gang 1 way switch
¥:320.00
小板147型16A八位开关双控
1Small plate 147 type 16A 8 gang 2 way switch
¥:342.00

AB-G5-0190

147 二位16A多功能三极插座
147 Double 13A MF 3 pin socket
¥:248.00

AB-G5-0191

147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:281.00

AB-G5-0192

小板147型二位15A美标扁插座
Small plate 147 two position 15A American standard flat socket
¥:279.00

AB-G5-0193

147 二位15A泰式多功能六孔插座
147 Double 15A Thai MF six-hole socket
¥:279.00

AB-G5-0194

147 二位13A方角插座
147 Double 13A square comer
¥:248.00

AB-G5-0195

147 二位15A圆孔插座
147 Double 15A 3 round pins socket
¥:279.00

AB-G5-0196

小板147型二位13A错位多功能二三极插座
147 type Double 13A dislocation MF 5 pole socket
¥:299.00

AB-G5-0197

147型小板二位10A二三极插座
147 type Double 10A two and three pole socket
¥:225.00

AB-G5-0198

147 二位开关带二位13A方角插座
147 Tow switch and double 13A square corner socket
¥:257.00

AB-G5-0199

147 二位开关带二位13A多功能插座
147 Tow switch and double 13A MF 3 pin socket with light
¥:257.00

AB-G5-0200

小板147二位开关二位13A多功能二三极插座
Small board 147 two position switch two position 13A multi-function two three pole socket
¥:284.00

AB-G5-0201

147 二位开关带二位13A方角插座（带指示灯）
147 Tow switch and double 13A square comer socket with indicator light
¥:258.00

AB-G5-0202

147 二位开关带二位13A多功能插座（带指示灯）
147 Tow switch and double 13A MF socket with light
¥:258.00

AB-G5-0203

147 二位开关带二位13A方角插座带二位USB
147 Tow switch and double 13A square comer socket with 2USB
¥:358.00

AB-G5-0204

147 二位开关带二位13A多功能带二位USB
147 Tow switch and double 13A MF socket+2USB
¥:358.00

AB-G5-0205

147二位开关二位13A方插+USB/Type-c（小板）
147 two switch Double 13A square plug+ USB/type-C
¥:358.00

AB-G5-0206

147二位开关二位13A多功能+USB/Type-c（小板）
147 two switch Double 13A MF+USB / type-C
¥:358.00



AB-G5-0207

147 二位开关带二位15A圆角插座（带指示灯）
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:293.00



AB-G5-0208

147 二位开关带二位13A方角插座（带指示灯）
147 two switch and double 13A square Angle socket (with neon)
¥:293.00

AB-G5-0209

147 四孔剃须插座
147 two shaving socket
¥:612.00



AB-G5-0210

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 kitchen switch
¥:346.00



AB-G5-0211

147 45A开关+一位开关13A方角插带指示灯(组合厨房开关)
147 kitchen switch
¥:346.00

AB-G5-0212

147型45A双极开关+一开13A方角插带灯（炉具开关）
147 type 45A bipolar switch +13A square angle plug With light (stove switch)
¥:374.00

AB-G5-0213

147型45A双极开关带指示灯
147 type 45A bipolar switch with indicator light
¥:324.00

AB-G5-0214

147 16A二位德式插座
147 Double Geman socket
¥:293.00

AB-G5-0215

147 16A二位法式插座
147 Double French socket
¥:293.00

AB-G5-0216

小板147型连体二位德标插座
Small plate 147 connected two position German standard socket
¥:293.00

AB-G5-0217

小板147型连体二位法标插座
Small plate 147 connected two position normal socket
¥:293.00

AB-G5-0218

147二位16A德式插座+USB/Type-c(小板)
147 double 16A German with USB/Type-c
¥:390.00

AB-G5-0219

147二位16A法式插座+USB/Type-c(小板)
147 double 16A French with USB/Type-c
¥:390.00

AB-G5-0220

小板147型二位16A德式+二位USB
147 double 16A German+2USB
¥:369.00

AB-G5-0221

小板147型二位16A德式+二位USB
147 Double 16A German+2USB
¥:369.00

AB-G5-0222

147 四位USB插座
147 4 USB socket
¥:477.00

AB-G5-0223

147 二位多功能插座+4USB
147 2-bit multi-function socket + 4USB
¥:414.00

AB-G5-0224

147 二位13A方角插座+4USB
147 two bit 13A square socket +4USB
¥:414.00

AB-G5-0225

小板147型13A方角插座+二位USB
Small board 147 type 13A square corner socket + 2USB
¥:376.00

AB-G5-0226

147 一位16A多功能插座+二位USB插座
147 13A MF 3 pin socket + 2USB socket
¥:376.00

AB-G5-0227

147型二位开关带二位13A多功能五孔+双USB
147 two switch and double 13A MF 5 pin + 2USB
¥:374.00

AB-G5-0228

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two position switch with two position 13A multifunction Five hole socket + 2 USB (with indicator)
¥:522.00

AB-G5-0229

147 二位13A多功能五孔插座+四位USB
147 double 5 pin multi-function socket+4USB
¥:414.00

AB-G5-0230

147型二位13A多功能五孔带4USB+小开关(带指示灯)
147 double 13A MF 5 pin with 4USB+ small switch (w/neon)
¥:432.00

AB-G5-0231

小板147型二位开关二位13A多功能五孔+USB/Type-c
147 two switch and double 13A MF 5 pin + USB / type-C
¥:495.00

AB-G5-0232

小板147型二位开关带二位13A多功能插座+4USB带指示灯
147 two switch and double 13A MF + 4USB (with neon)
¥:432.00

AB-G5-0233

小板147型二位开关带二位13A方角插座+4USB带指示灯
147 two switch and double 13A square Angle Socket +4USB (with neon)
¥:432.00

AB-G5-0234

147型二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 two switch double German socket +USB/Type-c (with neon)
¥:495.00

AB-G5-0235

147型二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 two switch double French socket +USB/Type-c (with neon)
¥:495.00

AB-G5-0236

147型二位开关二位16A德式插座（带指示灯）
147 two switch double German socket (with neon)
¥:329.00

AB-G5-0237

147型二位开关二位16A德式插座（带指示灯）
147 two switch double French socket (with neon)
¥:329.00

AB-G5-0238

147型二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket with neon+ 2USB
¥:405.00

AB-G5-0239

147型二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch with double 16A French socket with 2USB (with neon)
¥:405.00

AB-G5-0240

小板147型空白面板
147 Blank plate
¥:167.00

F71

Glass crystal white

玻璃水晶白

调光开关
Speed control switch

控制回路：调光开关(零火线)
产品分类：WIFI开关.WIFI+RF开关.ZIGBEE开关
工作电压：100V~240V~,50Hz/60Hz
工作电流：2A Max(纯阻性负载)
负载类型：总负载低于400W
产品材质：钢化玻璃面板+阻燃PC外壳
尺寸(高*宽*厚)：86mm*86mm*34mm
使用环境：温度0℃~40℃,相对湿度小于95%
无线频率：2.4GHz 433.92MHz

Control loop: Speed control switch (zero live line)
Product classification: WiFi switch. WiFi + RF switch. ZigBee switch
Working voltage: 100V ~ 240V ~, 50 Hz / 60 Hz
Working current: 2A max (pure resistive load)
Load type: total load less than 400W
Product material: toughened glass panel + flame retardant PC shell
Size (height * width * thickness): 86mm * 86mm * 34mm
Use environment: temperature 0 ℃ ~ 40 ℃, relative humidity less than 95%
Wireless frequency: 2.4GHz 433.92MHz

147组合演示
147 Combination demo



联体产品
Conjoined products

水晶白 Crystal White

香槟金 Champaign Gold

暗灰色 Dark Gray

爵士黑Jazz Black

F71 Glass crystal white 玻璃水晶白

F71-0001
一位触摸开关(零火线) ¥:400.00
1 gang 1 way touch switch
蓝牙WIFI一位触摸开关(零火版) ¥:500.00
1 gang 1 way touch switch
涂鸦Zigbee一位触摸开关(零火版) ¥:600.00
1 gang 1 way touch switch

F71-0002
二位触摸开关（零火版） ¥:450.00
2 gang 1 way touch switch
蓝牙WIFI二位触摸开关(零火版) ¥:550.00
2 gang 1 way touch switch
涂鸦Zigbee二位触摸开关(零火版) ¥:650.00
2 gang 1 way touch switch

F71-0003
三位触摸开关（零火版） ¥:500.00
3 gang 1 way touch switch
蓝牙WIFI三位触摸开关(零火版) ¥:600.00
3 gang 1 way touch switch
涂鸦Zigbee三位触摸开关(零火版) ¥:700.00
3 gang 1 way touch switch

F71-0004
四位触摸开关（零火版） ¥:550.00
4 gang 1 way touch switch
蓝牙WIFI四位触摸开关(零火版) ¥:650.00
4 gang 1 way touch switch
涂鸦Zigbee四位触摸开关(零火版) ¥:750.00
4 gang 1 way touch switch

F71-0005
调光开关(零火线) ¥:600.00
Dimming switch (zero live wire)
WIFI调光开关 ¥:700.00
WiFi dimming switch
Zigbee调光开关 ¥:800.00
Zigbee dimming switch

F71-0006
调速开关(零火线) ¥:600.00
Speed control switch (zero live line)
WIFI调速开关 ¥:700.00
WiFi speed control switch
Zigbee调速开关 ¥:800.00
Zigbee speed control switch

F71-0007
窗帘开关(零火线) ¥:600.00
Curtain switch (zero live wire)
WIFI窗帘开关 ¥:700.00
WiFi curtain switch
Zigbee窗帘开关 ¥:800.00
Zigbee curtain switch

F71-0008
大板一位开关带16A多功能插座
1 gang switch and 3 pin multi-purpose socket
¥:163.00



F71-0009
大板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:158.00

F71-0010
大板一位开关带16A多功能带二位USB
1 gang switch with 16A 3pin multi-function with 2USB
¥:290.00

F71-0011
一位开关2USB带13A方角插座
1 gang switch and 13A square pin socket
¥:295.00

F71-0012
小板16A一位开关单控 ¥:118. 00
16A 1 gang 1 way switch
小板16A一位开关双控 ¥:121. 00
16A 1 gang 2 way switch
小板16A一位开关多控 ¥:158.00
16A 1 gang more way switch

F71-0013
小板16A二位开关单控 ¥:138.00
16A 2 gang 1 way switch
小板16A二位开关双控 ¥:144.00
16A 2 gang 2 way switch
小板16A二位开关多控 ¥:210.00
16A 2 gang more way switch

F71-0014
小板16A三位开关单控 ¥:158.00
16A 3 gang 1 way switch
小板16A三位开关双控 ¥:167.00
16A 3 gang 2 way switch



F71-0015
小板16A四位开关单控 ¥:178.00
16A 4 gang 1 way switch
小板16A四位开关双控 ¥:190.00
16A 4 gang 2 way switch



F71-0016
小板16A三位开关多控
Small panel 16A 3 gang 3 way switch
¥:230.00

F71-0017
小板16A百叶窗升降开关
louver window lifter switch
¥:175.00

F71-0018
小板16A门控开关
gating switch
¥: 142.00

F71-0019
小板16A英式门控开关
British gating switch
¥:142.00

F71-0020
小板16A门铃开关
doorbell switch
¥:142.00

F71-0021
小板16A拔动一位开关单控 ¥:175.00
1 gang 1 way toggle switch
小板16A拔动一位开关双控 ¥:180.00
1 gang 2 way toggle switch

F71-0022
小板16A拔动二位开关单控 ¥:190.00
2 gang 1 way toggle switch
小板16A拔动二位开关双控 ¥:200.00
2 gang 2 way toggle switch

F71-0023
小板16A拔动三位开关单控 ¥:205.00
3 gang 1 way toggle switch
小板16A拔动三位开关双控 ¥:220.00
3 gang 2 way toggle switch

F71-0024
小板16A拔动四位开关单控 ¥:220.00
4 gang 1 way toggle switch
小板16A拔动四位开关双控 ¥:240.00
4 gang 2 way toggle switch

F71-0025
小板20A双极开关带指示灯 ¥:187.00
20A switch with indicator light
小板45A双极开关带指示灯 ¥:226.00
45A swich with indicator light

F71-0026
小板45A双极开关带指示灯
45A switch with indicator light
¥:226.00

F71-0027
小板16A卷帘门复位开关
Shutter reset switch
¥:195.00

F71-0028
小板16A德式插座
German socket
¥:163.00

F71-0029
小板16A法式插座
French socket
¥:163..00

F71-0030
小板16A俄式插座
Russian socket
¥:163.00

F71-0031
小板16A以色列插座
Israel socket
¥:175.00

F71-0032
小板16A意大利+德式插座
Italy+German socket
¥:175.00

F71-0033
大板16A三极插座
16A 3 pole socket
¥:130.00

F71-0034
大板10A二三极插座
10A 5 pole socket
¥:125.00

F71-0035
大板10A错位二三极插座
10A Two or three pole socket
¥:130.00

F71-0036
大板10A二三极插座
10A 7 pole socket
¥:135.00

F71-0037
小板16A一位开关单控带16A三极插座
1 gang 1 way switch and 16A 3 pole socket
¥:160.00
小板16A一位开关双控带16A三极插座
1 gang 2 way switch and 16A 3 pole socket
¥:163.00

F71-0038
大板一位开关单控带10A二三极插座
1 gang 2 way switch and 5 pole socket
¥:160.00
大板一位开关双控带10A二三极插座
1 gang 2 way switch and 5 pole socket
¥:163.00

F71-0039
小板10A二位开关单控带二三极插座
2 gang 1 way switch and 5 pole socket
¥:180.00
小板10A二位开关双控带二三极插座
2 gang 2 way switch and 5 pole socket
¥:186.00

F71-0040
小板10A二极插座
10A 2 pole socket
¥:140.00



F71-0041
小板10A二二极插座
10A Double 2 pole socket
¥:155.00



F71-0042
小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:155.00



F71-0043
小板10A一位开关带二二极座
1gang switch and 4 pole socket
¥:165.00

F71-0044
小板16A多功能三极插座
16A 3 pin universal socket
¥:138.00

F71-0045
小板13A二三极多功能插座
5 pin multi-function socket
¥:156.00

F71-0046
小板13A二三极错位多功能插座
5 pin multi-function socket
¥:166.00

F71-0047
小板13A方角插座
13A square corner socket
¥:138.00

F71-0048
小板15A圆角插座
15A 3 round pins socket
¥:155.00

F71-0049
小板15A美标扁三极插座
15A triode flat American standard socket
¥:158.00

F71-0050
小板15A泰式多功能三极插座
15A Thai type multi-function 3 pole socket
¥:158.00

F71-0051
小板错位泰式六孔插座
Dislocation Thai 6 pin socket
¥:165.00



F71-0052
小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:158.00



F71-0053
小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pins socket
¥:163.00

F71-0054
小板一位开关带16A多功能插座
1 gang switch and 3 pin MF socket
¥:163.00



F71-0055
小板一位开关带13A方角插座（带指示灯）
1 gang switch and 13A square pin socket
¥:158.00



F71-0056
小板一位开关带15A圆孔插座（带指示灯）
1 gang switch and 15A 3 round pins socket
¥:163.00



F71-0057
小板一位开关带16A多功能插座（带指示灯）
1 gang switch and 3 pin MF socket(with neon)
¥:163.00



F71-0058
小板一位开关带13A多功能五孔插座（带指示灯）
1 gang switch and 5 pin multi-function socket
¥:178.00

F71-0059
小板16A德式插座带二位USB
2 USB with German socket
¥:230.00

F71-0060
小板16A法式插座带二位USB
2 USB with French socket
¥:230.00

F71 Glass crystal white 玻璃水晶白

F71-0061
小板16A德式插座+USB/Type-c
Small board 16A German socket
+ USB / type-c
¥:230.00

F71-0062
小板16A法式插座+USB/Type-c
Small board 16A French socket
+ USB / type-c
¥:230.00

F71-0063
小板16A一位开关带德式插座
1 gang German socket
¥:175.00

F71-0064
小板16A一位开关带法式插座
1 gang French socket
¥:175.00

F71-0065
小板16A德式插座带防水
German socket and Waterproof belt
¥:175.00

F71-0066
小板16A法式插座带防水
French socket and Waterproof belt
¥:175.00

F71-0067
小板二位USB带13A方角插座（横）
2 USB with 13A square corner
socket with switch
¥:230.00

F71-0068
小板15A美标插座带USB+TYPE-C
American Standard with USB+type-C
¥:230.00

F71-0069
小板15A泰式插座带USB+TYPE-C
15A Thai MF socket with USB+type-C
¥:230.00

F71-0070
小板二位USB带13A方角插座
（带保护门）
2 USB with 13A square corner socket
with flip cover
¥:265.00

F71-0071
小板二位USB带13A多功能插座
（带保护门）
2 USB with 3 pin multi-purpose socket
with flip cover
¥:265.00



F71-0072
小板一位开关带二位USB带
13A多功能插座（带指示灯）
1 gang switch with 2USB and
13A multi-function socket
¥:240.00

F71-0073
小板一位开关带二位USB带
13A方角插座（带指示灯）
1 gang switch 13A square socket
with 2USB(with light)
¥:240.00

F71-0074
小板13A多功能带Type-c+USB
13A multi-function with type-C
+ USB
¥:230.00

F71-0075
小板13A方插带Type-c+USB
13A square angle band type-C
+ USB
¥:230.00

F71-0076
小板一位开关13A多功能插座带
Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose
socket with Type-c+USB(with light)
¥:240.00

F71-0077
小板二位USB带13A多功能插座
带小开关（竖）
2 USB with Three very multi-purpose
socket with switch
¥:240.00

F71-0078
小板一位开关13A方插带
Type-c+USB(带指示灯)
1 gang switch 13A square insert belt
Type-c+USB(with light)
¥:240.00

F71-0079
小板二位USB带13A方角插座
带小开关（竖）
2 USB with 13A square corner
socket with switth
¥:240.00

F71-0080
小板15A泰式多功能插座带二
位USB
15A Thai multi-function socket
with 2-bit USB
¥:230.00

F71-0081
小板15A泰式+2USB
15A Thai + 2USB
¥:230.00

F71-0082
小板二位USB带13A多功能插座（横）
2 USB with 3 pin multi-purpose socket
¥:230.00

F71-0083
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:220.00

F71-0084
小板二位USB带10A二三极
插座带开关
2 USB and 5 pin socket with switch
¥:230.00

F71-0085
10A二三极五孔带USB+TYPE-C 2.1A
10A 5 pole socket with USB+type-c 2.1A
¥:240.00
10A二三极五孔带USB+TYPE-C 4A
10A 5 pole socket with USB+type-c 4A
¥:360.00

F71-0086
小板一位开关带13A多功能五孔
插座带USB
1 gang switch and 5 pin multi-function
socket with USB and indicator light
¥:290.00

F71-0087
小板13A二位USB带多功能五孔插座
2 USB with 5 pin multi-function socket
¥:230.00

F71-0088
小板13A二位USB带多功能五孔
插座带开关
2 USB with 5 pin multi-function socket
with switch
¥:240.00

F71-0089
小板13A多功能五孔带USB+Type-c 2.1A
13A MF 5 pin socket with USB+type-c 2.1A
¥:240.00
小板13A多功能五孔带USB+Type-c 4A
13A MF 5 pin socket with USB+type-c 4A
¥:360.00



F71-0090
小板一位电视插座
TV socket
¥:155.00

F71-0091
小板一位电话插座 ¥:155.00
telephone socket
小板一位电脑插座 ¥:165.00
computer socket
小板一位电脑插座(超六类) ¥:218.00
computer socket(6)

F71-0092
小板双电视插座
Two TV socket
¥:175.00

F71-0093
小板双电话插座 ¥:175.00
Two telephone socket
小板双电脑插座 ¥:195.00
Two computer socket
小板双电脑插座(超六类) ¥:245.00
Two computer socket(6)
小板电话电脑插座 ¥:185.00
telephone+computer socket
小板电话电脑插座(超六类) ¥:235.00
telephone+computer socket(6)

F71-0094
小板电视电话插座 ¥:175.00
TV + telephone socket
小板电视电脑插座 ¥:185.00
TV + computer socket
小板电视电脑插座(超六类) ¥:235.00
TV + computer socket(6)

F71-0095
小板电话带USB插座 ¥:320.00
TEL + USB socket
小板电脑带USB插座 ¥:320.00
computer + USB socket
小板电脑带USB插座(超六类) ¥:370.00
computer + USB socket(6)

F71-0096
小板一位TV+FM
TV and FM
¥:230.00

F71-0097
小板一位卫星插座
Satellite socket
¥:165.00

F71-0098
小板二位卫星插座
Double satellite socket
¥:195.00



F71-0099
小板卫星+电视插座
Satellite and TV socket
¥:185.00

F71-0100
小板卫星带电话插座 ¥:185.00
Satellite and telephone socket
小板卫星带电脑插座 ¥:195.00
Satellite and computer socket
小板卫星带电脑插座(超六类) ¥:245.00
Satellite and computer socket(6)

F71-0101
小板二极插座带电视插座
2 pin socket with TV
¥:320.00

F71-0102
小板二极插座带电话插座 ¥:320.00
2 pin socket with telephone
小板二极插座带电脑插座 ¥:320.00
2 pin socket with computer
小板二极插座带电脑插座(超六类) ¥:370.00
2 pin socket with computer

F71-0103
小板一位光纤插座
Optical fiber socket
¥:195.00

F71-0104
小板二位USB插座
Double USB socket
¥:265.00

F71-0105
小板单联音响插座
Single audio socket
¥:225.00



F71-0106
小板双联音响插座
Double audio socket
¥:305.00

F71-0107
触摸延时开关（节能）
Touch delay delay switch
(energy saving)
¥:225.00

F71-0108
声光控延时开关（节能）
Sound-light controlled delay switch
(energy saving)
¥:225.00

F71-0109
红外线人体感应开关
Human body induction
¥:300.00

F71-0110
凹型地脚灯(亮光/暖光)
The footlights
¥:260.00

F71-0111
凹型红外线人体感应地脚灯(亮光/暖光)
The human body induction footlights
¥:330.00

F71-0112
平面地脚灯(亮光/暖光)
Footlights
¥:260.00

F71-0113
叮咚门铃
Ding dong doorbell
¥:291.00

F71-0114
机械式40A插卡取电 ¥:320.00
Mechanical card for electricity
感应式低频40A插卡取电 ¥:490.00
Low frequency induction card
for electricity
感应式高频40A插卡取电 ¥:590.00
High frequency induction card
for electricity

F71-0115
紧急呼叫开关
Emergency call switch
¥:280.00

F71-0116
请勿打扰请即清理门铃开关
（按键式）
Do not disturb, please namely cleaning
please + later doorbell "button"
¥:323.00

F71-0117
请勿打扰门铃开关
(按键式)
Do not disturb + doorbell "button"
¥:475.00

F71-0118
请勿打扰请即清理门铃开关
(按键式)
Do not disterb please
namely cleaning please "button"
¥:475.00

F71-0119
智能音乐控制开关
Intelligent music control switch
¥:750.00

F71-0120
温度控制调节开关
Temperature control switch
¥:780.00

F71 Glass crystal white 玻璃水晶白

F71-0121
温度控制调节开关
Temperature control switch
¥:930.00

F71-0122
调音开关
Tuning switch
¥:300.00

F71-0123
调光开关300W ¥:220.00
Dimming 300W
调光开关600W ¥:250.00
Dimming 600W
调光开关1000W ¥:280.00
Dimming 1000W

F71-0124
调速开关300W ¥:220.00
Speed 300W
调速开关600W ¥:250.00
Speed 600W
调速开关1000W ¥:280.00
Speed 1000W

F71-0125
一位开关带调光开关500W
1 gang with dimmer switch
¥:235.00

F71-0126
一位开关带调速开关500W
1 gang with speed switch
¥:235.00

F71-0127
13A开关带保险丝（带指示灯）
13A switch with fuse(with neon)
¥:265.00

F71-0128
20A出线柱
20A outgoing post
¥:245.00

F71-0129
剃须插座
Shaving socket
¥:500.00

F71-0130
USB+电脑插座+无线路由
USB+computer socket wireless router
¥:900.00

F71-0131
蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio+3.5+2USB+HDMI
¥:5300.00

F71-0132
HDMI
¥:320.00

F71-0133
USB+TYPE-C
¥:360.00

F71-0134
HDMI+USB
¥:320.00

F71-0135
HDMI+USB+3.5音频
HDMI+USB+3.5
¥:320.00

F71-0136
VGA+USB+3.5音频
VGA+USB +3.5
¥:320.00



F71-0137
AV+3.5音频
AV +3.5
¥:320.00

F71-0138
VGA+AV音频接口
VGA + AV audio interface
¥:320.00

F71-0139
HDMI+AV音频接口
HDMI + AV audio interface
¥:320.00



F71-0140
二分之一AV音频+卫星
Half AV audio interface+
Satellite socket
¥:320.00



F71-0141
二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:320.00

F71-0142
二分之一VGA+TV
Half VGA+TV
¥:320.00

F71-0143
二分之一VGA+电脑插座
Half VGA+computer socket
¥:320.00

F71-0144
VGA+USB
¥:320.00

F71-0145
VGA+HDMI
¥:320.00

F71-0146
45A出线柱
45A Outlet
¥:275.00

F71-0147
德式插座带开关（WIFI版）
German socket with switch
(WiFi version)
¥:670.00

F71-0148
法式插座带开关（WIFI版）
French socket with switch
(WiFi version)
¥:670.00

F71-0149
13A多功能插座带开关（WIFI版）
13A multi-functional socket with switch
(WiFi version)
¥:700.00

F71-0150
13A方角插座带开关（WIFI版）
13A square corner socket with switch
(WiFi version)
¥:700.00



F71-0151
空白面板
Blank plate
¥:113.00



F71-0152
大板147型二位双极开关带二位13A方角插座
147 type two position bipolar switch with double 13A square socket
¥:295.00



F71-0153
大板147型二位开关带二位13A多功能插座
147 Tow switch and double 13A multi-purpose socket
¥:295.00

F71-0154
大板147型二开双极开关带13A方插+二位USB
147 two bipolar switch and double 13A square plug + 2USB
¥:435.00



F71-0155
大板147型二位开关带13A多功能+二位USB
147 two switch and double 13A MF+2USB socket
¥:435.00

F71-0156
小板147型二位开关单控
147 2 gang 1 way switch
¥:236.00
小板147型二位开关双控
147 2 gang 2 way switch
¥:242.00

F71-0157
小板147型三位开关单控
147 3 gang 1 way switch
¥:256.00
小板147型三位开关双控
147 3 gang 2 way switch
¥:265.00

F71-0158
小板147型四位开关单控
147 4 gang 1 way switch
¥:276.00
小板147型四位开关双控
147 4 gang 2 way switch
¥:288.00

F71-0159
小板147型五位开关单控
147 5 gang 1 way switch
¥:296.00
小板147型 五位开关双控
147 5 gang 2 way switch
¥:311.00

F71-0160
小板147型六位开关单控
147 6 gang 1 way switch
¥:311.00
小板147型六位开关双控
147 6 gang 2 way switch
¥:334.00

F71-0161
小板147型七位开关单控
147 7 gang 1 way switch
¥:336.00
小板147型七位开关双控
147 7 gang 2 way switch
¥:357.00

F71-0162
小板147型八位开关单控
147 8 gang 1 way switch
¥:356.00
小板147型八位开关双控
147 8 gang 2 way switch
¥:380.00

F71-0163
147 二位16A多功能三极插座
147 Double 16A MF socket
¥:276.00



F71-0164
147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:312.00



F71-0165
小板147型二位15A美标扁插座
147 Double 15A triode flat Ammerican standard socket
¥:310.00



F71-0166
小板147型二位15A泰式三极插座
147 Double 15A triode flat Ammerican standard socket
¥:310.00



F71-0167
147 二位13A方角插座
147 Double 13A square comer
¥:276.00



F71-0168
147 二位15A圆孔插座
147 Double 15A 3 round pins socket
¥:310.00



F71-0169
小板147型二位13A错位多功能五孔插座
147 type Double 13A dislocation multi-function 5 hole socket
¥:332.00

F71-0170
147 二位10A二三极插座
147 Double position two and three pole socket
¥:250.00



F71-0171
147二位开关带二位13A方角插座
147 Tow switch and double 13A square comer socket
¥:285.00



F71-0172
147 二位开关带二位13A多功能插座
147 two switch with double 13A MF socket
¥:285.00



F71-0173
147二位开关带二位五孔多功能插座
147 Tow switch and double 5 pin MF socket
¥:315.00



F71-0174
147 二位开关带二位13A方角插座(带指示灯)
147 Tow switch and double 13A square comer socket with indicator light
¥:295.00



F71-0175
147 二位开关带二位13A多功能插座（带指示灯）
147 Tow switch and double 13A MF socket with light
¥:295.00



F71-0176
147二位开关二位13A方插+二位USB（小板）
147 Tow switch and double 13A square comer socket+2USB
¥:385.00



F71-0177
147二位开关二位13A多功能+二位USB（小板）
147 Tow switch and double 13A MF socket+2USB
¥:385.00

F71-0178
147 二位开关二位13A方插+USB/Type-c
147 two switch double 13A square band lamp+USB/Type-c
¥:385.00

F71-0179
147 二位开关二位13A多功能插带灯+USB/Type-c
147 two switch double 13A MF band lamp+USB/Type-c
¥:385.00



F71-0180
147 二位开关带二位15A圆角插座(带指示灯)
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:326.00

F71 Glass crystal white 玻璃水晶白



F71-0181

小板147型二位开关带二位13A方角插座(带指示灯)
147 two switch with double 13A square angle socket (with indicator light)
¥:326.00

F71-0191

147型二位德式带USB+type-c(模块)
147 double German + USB / type-C (module)
¥:510.00



F71-0201

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two position switch with two position 13A multifunction Five hole socket + 2 USB (with indicator)
¥:580.00

F71-0182

147型二位剃须插座
147 two shaving socket
¥:680.00

F71-0192

147型二位法式带USB+type-c(模块)
147 double French + USB / type-C (module)
¥:510.00

F71-0202

147 二位13A多功能五孔插座+四位USB
147 13A double 5 pin multi-function socket+4USB
¥:460.00



F71-0183

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 kitchen switch
¥:415.00

F71-0193

二位17A德式+二位USB（小板连体）
147 Double German with 2USB
¥:410.00



F71-0203

147 二位开关二位13A多功能五孔插座+四位USB
147 two switch double 5 pin multi function socket+4USB
¥:480.00



F71-0184

14745A开关+一位开关13A方角插带指示灯(组合厨房开关)
147 kitchen switch
¥:415.00

F71-0194

147二位16A法式+2USB（小板连体）
147 Double French with 2USB
¥:410.00



F71-0204

147型二位开关带二位多功能五孔插座带USB+type-c
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:550.00



F71-0185

147 45A开关+一位开关13A方插带灯(厨房开关)
147 Kitchen switch
¥:415.00

F71-0195

147 四位USB插座
147 4 USB socket
¥:530.00



F71-0205

147型二位开关带二位13A多功能带四位USB（带指示灯）
147 two switch and double 13A MF +4USB socket (with indicator light)
¥:480.00

F71-0186

147 45A双极开关带指示灯
147 type 45A bipolar switch
¥:360.00

F71-0196

147 二位多功能插座+4USB
147 2-bit multi-function socket + 4USB
¥:460.00



F71-0206

147型二开带二位13A方插带四位USB
147 type two switch two position 13A square inserting band 4 USB
¥:480.00

F71-0187

147 16A二位德式插座
147 Double German socket
¥:326.00



F71-0197

147 二位13A方角插座+4USB
147 two bit 13A square socket +4USB
¥:460.00

F71-0207

147二位13A方插带四位USB
147 type double position 13A square inserting band 4 USB
¥:460.00

F71-0188

147 16A二位法式插座
147 Double French socket
¥:326.00

F71-0198

147 一位13A方角插座+二位USB
13A square comer socket and Two USB
¥:418.00

F71-0208

147 二位13A多功能+4USB(带盖板)
147 double 13A multi-function + 4USB (with cover plate)
¥:530.00

F71-0189

147 16A二位德式插座
147 Double Geman socket
¥:326.00

F71-0199

147 一位16A多功能插座+二位USB插座
16A MF 3 pin socket and 2USB socket
¥:418.00



F71-0209

147型二位13A方插带四位USB(带盖板)
147 double 13A square inserting +4USB socket
¥:530.00

F71-0190

147 16A二位法式插座
147 Double French socket
¥:326.00

F71-0200

147型二位开关带二位多功能五孔插座带双USB
147 Tow switch and double 13A 5 pin multi-purpose socket+2USB
¥:415.00

F71-0210

147一开单控带13A多功能五孔插座
147 1 gang 1 way switch with 13A 5 pin MF socket
¥:274.00

F71-0211

147 一开单控带13A方角插座+双USB
147 1 gang 1 way socket with 13A square Angle socket +2USB
¥:348.00

F71-0221

147二开单控开关带16A多功能插座
147 two switch single control 16A MF 3 pin socket
¥:276.00

F71-0231

147型 二位电脑插座带16A多功能插座
147 double computer with 16A MF pin socket
¥:333.00

F71-0212

147型一开单控带15A泰式插座
147 one open single control with 15A Thai socket
¥:283. 00



F71-0222

147型二开单控带13A方角插座
147 type double open single control socket with 13A square angle
¥:276.00

F71-0232

147型二位16A德式插座带防水
147 two position 16A German socket with waterproof
¥:350.00

F71-0213

147型一开单控带多功能五孔+双USB插座
147 one open single control and MF 5 pin + 2USB socket
¥:348. 00

F71-0223

147型10A二极带10A二极插座
147 10A two pole with 10A two pole socket
¥:280.00

F71-0233

147型二位16A法式插座带防水
147 two position 16A French socket with waterproof
¥:350.00

F71-0214

147型二位10A二三极五孔带四位USB插座
147 double 10A 5 pin socket + 4 USB with indicator light
¥:440.00

F71-0224

147型二位一开单控带二位16A三极插座
147 type 2 gang 1 way switch double 16A three pole socket
¥:320.00

F71-0234

147二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 double switch double German socket+USB/Type-c with light
¥:550.00



F71-0215

147型二位13A多功能带四位USB带小开关
147 double 13A 3pin multi-function socket + 4USB with small switch
¥:480.00



F71-0225

147型二位一开单控带二位10A二三极插座
147 type 2 gang 1 way switch double 10A 5 pole socket
¥:320.00

F71-0235

147二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 double switch double French socket+USB/Type-c with light
¥:550.00



F71-0216

147型二位13A方插带四位USB带小开关
147 double 13A square plug with 4USB with small switch
¥:480.00

F71-0226

147型二位10A二三极插座 ¥:460.00
带USB+type-c 2.1A
147 type double 10A 5 pole socket USB + type-c 2.1A
147型二位10A二三极插座 ¥:720.00
带USB+type-c 4A
147 type double 10A 5 pole socket USB + type-c 4A

F71-0236

147二位开关二位16A德式插座（带指示灯）
147 two switch double 16A German socket with light
¥:365.00



F71-0217

147 二位一开16A多功能带指示灯
147 Tow switch and double 16A MF 3 pin socket with neon
¥:326.00

F71-0227

147型二位多功能五孔插座 ¥:460.00
带USB+type-c 2.1A
147 type double 5 pin MF socket USB + type-c 2.1A
147型二位多功能五孔插座 ¥:720.00
带USB+type-c 4A
147 type double 5 pin MF socket USB + type-c 4A

F71-0237

147二位开关二位16A法式插座（带指示灯）
147 two switch double 16A French socket with light
¥:365.00

F71-0218

147二位多功能带四位USB
147 type multi-functional 3 pin socket band 4 USB
¥:460.00



F71-0228

147型13A多功能双USB带多五孔插座
147 type 13A multi-function 2USB with 5 pin multi-functional socket
¥:480.00

F71-0238

147二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket + 2usb with light
¥:450.00

F71-0219

147 16A多功能+万用五孔插座
147 16A MF 3 pin +MF 5 pin socket
¥:295.00

F71-0229

147型二位电脑插座带二位USB插座
147 type double computer with 2USB socket
¥:460.00

F71-0239

147二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch double 16A French socket +2USB with light
¥:450.00



F71-0220

147 10A二二二二极插座
10A 8 pole socket
¥:310.00

F71-0230

147型二位电话带二位电脑插座
147 double telephone with double computer socket
¥:390.00

F71-0240

147型二位空白面板
147 Blank plate
¥:185.00

F71 玻璃火山灰
Glass pozzolanic

窗帘开关 Curtain switch

控制回路：窗帘一开(零火线)
产品分类：WIFI开关.WIFI+RF开关.ZIGBEE开关
工作电压：100V~240V~,50Hz/60Hz
工作电流：2A Max(纯阻性负载)
负载类型：总负载低于350W
产品材质：钢化玻璃面板+阻燃PC外壳
尺寸(高*宽*厚)：86mm*86mm*34mm
使用环境：温度0℃~40℃,相对湿度小于95%
无线频率：2.4GHz 433.92MHz

Control loop: curtain opening (zero live line)
Product classification: WiFi switch. WiFi + RF switch. ZigBee switch
Working voltage: 100V ~ 240V ~, 50 Hz / 60 Hz
Working current: 2A max (pure resistive load)
Load type: total load less than 350W
Product material: toughened glass panel + flame retardant PC shell
Size (height * width * thickness): 86mm * 86mm * 34mm
Use environment: temperature 0 ℃ ~ 40 ℃, relative humidity less than 95%
Wireless frequency: 2.4GHz 433.92mhz

天猫直连 Tmall direct link
蓝牙配对 Bluetooth pairing
APP控制 App control
语音控制 Voice control
智能联动 Intelligent linkage

强大综合结构优化升级
Optimization and upgrading of powerful comprehensive structure

- 纯平面板设计 Flat panel design
- 防水玻璃面板 Waterproof glass panel
- 电容触摸屏 Capacitive touch screen
- 柔光LED指示灯 Soft light LED indicator
- 定制图案文字 Custom pattern text
- 触控式操作 Touch operation

F71 Glass pozzolanic 玻璃火山灰

F71-0001

一位触摸开关(零火线) ¥:400.00
1 gang 1 way touch switch
蓝牙WIFI一位触摸开关(零火版) ¥:500.00
1 gang 1 way touch switch
涂鸦Zigbee一位触摸开关(零火版) ¥:600.00
1 gang 1 way touch switch

F71-0002

二位触摸开关（零火版） ¥:450.00
2 gang 1 way touch switch
蓝牙WIFI二位触摸开关(零火版) ¥:550.00
2 gang 1 way touch switch
涂鸦Zigbee二位触摸开关(零火版) ¥:650.00
2 gang 1 way touch switch

F71-0003

三位触摸开关（零火版） ¥:500.00
3 gang 1 way touch switch
蓝牙WIFI三位触摸开关(零火版) ¥:600.00
3 gang 1 way touch switch
涂鸦Zigbee三位触摸开关(零火版) ¥:700.00
3 gang 1 way touch switch

F71-0004

四位触摸开关（零火版） ¥:550.00
4 gang 1 way touch switch
蓝牙WIFI四位触摸开关(零火版) ¥:650.00
4 gang 1 way touch switch
涂鸦Zigbee四位触摸开关(零火版) ¥:750.00
4 gang 1 way touch switch

F71-0005

调光开关(零火线) ¥:600.00
Dimming switch (zero live wire)
WIFI调光开关 ¥:700.00
WiFi dimming switch
Zigbee调光开关 ¥:800.00
Zigbee dimming switch

F71-0006

调速开关(零火线) ¥:600.00
Speed control switch (zero live line)
WIFI调速开关 ¥:700.00
WiFi speed control switch
Zigbee调速开关 ¥:800.00
Zigbee speed control switch

F71-0007

窗帘开关(零火线) ¥:600.00
Curtain switch (zero live wire)
WIFI窗帘开关 ¥:700.00
WiFi curtain switch
Zigbee窗帘开关 ¥:800.00
Zigbee curtain switch

F71-0008

大板一位开关带16A多功能插座
1 gang switch and 3 pin multi-purpose socket
¥:163.00

F71-0009

大板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:158.00

F71-0010

大板一位开关带16A多功能带二位USB
1 gang switch with 16A 3pin multi-function with 2USB
¥:290.00

F71-0011

一位开关2USB带13A方角插座
1 gang switch and 13A square pin socket
¥:295.00

F71-0012

小板16A一位开关单控 ¥:118. 00
16A 1 gang 1 way switch
小板16A一位开关双控 ¥:121. 00
16A 1 gang 2 way switch
小板16A一位开关多控 ¥:158.00
16A 1 gang more way switch

F71-0013

小板16A二位开关单控 ¥:138.00
16A 2 gang 1 way switch
小板16A二位开关双控 ¥:144.00
16A 2 gang 2 way switch
小板16A二位开关多控 ¥:210.00
16A 2 gang more way switch

F71-0014

小板16A三位开关单控 ¥:158.00
16A 3 gang 1 way switch
小板16A三位开关双控 ¥:167.00
16A 3 gang 2 way switch

F71-0015

小板16A四位开关单控 ¥:178.00
16A 4 gang 1 way switch
小板16A四位开关双控 ¥:190.00
16A 4 gang 2 way switch

F71-0016

小板16A三位开关多控
Small panel 16A 3 gang 3 way switch
¥:230.00

F71-0017

小板16A百叶窗升降开关
louver window lifter switch
¥:175.00

F71-0018

小板16A门控开关
gating switch
¥: 142.00

F71-0019

小板16A英式门控开关
British gating switch
¥:142.00

F71-0020

小板16A门铃开关
doorbell switch
¥:142.00

F71-0021

小板16A拔动一位开关单控 ¥:175.00
1 gang 1 way toggle switch
小板16A拔动一位开关双控 ¥:180.00
1 gang 2 way toggle switch

F71-0022

小板16A拔动二位开关单控 ¥:190.00
2 gang 1 way toggle switch
小板16A拔动二位开关双控 ¥:200.00
2 gang 2 way toggle switch

F71-0023

小板16A拔动三位开关单控 ¥:205.00
3 gang 1 way toggle switch
小板16A拔动三位开关双控 ¥:220.00
3 gang 2 way toggle switch

F71-0024

小板16A拔动四位开关单控 ¥:220.00
4 gang 1 way toggle switch
小板16A拔动四位开关双控 ¥:240.00
4 gang 2 way toggle switch

F71-0025

小板20A双极开关带指示灯 ¥:187.00
20A switch with indicator light
小板45A双极开关带指示灯 ¥:226.00
45A swich with indicator light

F71-0026

小板45A双极开关带指示灯
45A switch with indicator light
¥:226.00

F71-0027

小板16A卷帘门复位开关
Shutter reset switch
¥:195.00

F71-0028

小板16A德式插座
German socket
¥:163.00

F71-0029

小板16A法式插座
French socket
¥:163..00



F71-0030

小板16A俄式插座
Russian socket
¥:163.00

F71-0031

小板16A以色列插座
Israel socket
¥:175.00

F71-0032

小板16A意大利+德式插座
Italy+German socket
¥:175.00

F71-0033

大板16A三极插座
16A 3 pole socket
¥:130.00

F71-0034

大板10A二三极插座
10A 5 pole socket
¥:125.00

F71-0035

大板10A错位二三极插座
10A Two or three pole socket
¥:130.00

F71-0036

大板10A二二三极插座
10A 7 pole socket
¥:135.00

F71-0037

小板16A一位开关单控带16A三极插座
1 gang 1 way switch and 16A 3 pole socket
¥:160.00
小板16A一位开关双控带16A三极插座
1 gang 2 way switch and 16A 3 pole socket
¥:163.00

F71-0038

大板一位开关单控带10A二三极插座
1 gang 2 way switch and 5 pole socket
¥:160.00
大板一位开关双控带10A二三极插座
1 gang 2 way switch and 5 pole socket
¥:163.00

F71-0039

小板10A二位开关单控带二三极插座
2 gang 1 way switch and 5 pole socket
¥:180.00
小板10A二位开关双控带二三极插座
2 gang 2 way switch and 5 pole socket
¥:186.00



F71-0040

小板10A二极插座
10A 2 pole socket
¥:140.00

F71-0041

小板10A二二极插座
10A Double 2 pole socket
¥:155.00

F71-0042

小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:155.00

F71-0043

小板10A一位开关带二二极座
1gang switch and 4 pole socket
¥:165.00

F71-0044

小板16A多功能三极插座
16A 3 pin universal socket
¥:138.00

F71-0045

小板13A二三极多功能插座
5 pin multi-function socket
¥:156.00

F71-0046

小板13A二三极错位多功能插座
5 pin multi-function socket
¥:166.00

F71-0047

小板13A方角插座
13A square corner socket
¥:138.00

F71-0048

小板15A圆角插座
15A 3 round pins socket
¥:155.00

F71-0049

小板15A美标扁三极插座
15A triode flat American standard socket
¥:158.00

F71-0050

小板15A泰式多功能三极插座
15A Thai type multi-function 3 pole socket
¥:158.00

F71-0051

小板错位泰式六孔插座
Dislocation Thai 6 pin socket
¥:165.00

F71-0052

小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:158.00

F71-0053

小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pins socket
¥:163.00

F71-0054

小板一位开关带16A多功能插座
1 gang switch and 3 pin MF socket
¥:163.00

F71-0055

小板一位开关带13A方角插座（带指示灯）
1 gang switch and 13A square pin socket
¥:158.00



F71-0056

小板一位开关带15A圆孔插座（带指示灯）
1 gang switch and 15A 3 round pins socket
¥:163.00

F71-0057

小板一位开关带16A多功能插座（带指示灯）
1 gang switch and 3 pin MF socket(with neon)
¥:163.00

F71-0058

小板一位开关带13A多功能五孔插座（带指示灯）
1 gang switch and 5 pin multi-function socket
¥:178.00

F71-0059

小板16A德式插座带二位USB
2 USB with German socket
¥:230.00

F71-0060

小板16A法式插座带二位USB
2 USB with French socket
¥:230.00

F71 Glass pozzolanic 玻璃火山灰

F71-0061
小板16A德式插座+USB/Type-c
Small board 16A German socket
+ USB / type-c
¥:230.00

F71-0062
小板16A法式插座+USB/Type-c
Small board 16A French socket
+ USB / type-c
¥:230.00

F71-0063
小板16A一位开关带德式插座
1 gang German socket
¥:175.00

F71-0064
小板16A一位开关带法式插座
1 gang French socket
¥:175.00

F71-0065
小板16A德式插座带防水
German socket and Waterproof belt
¥:175.00

F71-0066
小板16A法式插座带防水
French socket and Waterproof belt
¥:175.00

F71-0067
小板二位USB带13A方角插座（横）
2 USB with 13A square corner
socket with switch
¥:230.00

F71-0068
小板15A美标插座带USB+TYPE-C
American Standard with USB+type-C
¥:230.00

F71-0069
小板15A泰式插座带USB+TYPE-C
15A Thai MF socket with USB+type-C
¥:230.00

F71-0070
小板二位USB带13A方角插座
（带保护门）
2 USB with 13A square corner socket
with flip cover
¥:265.00

F71-0071
小板二位USB带13A多功能插座
（带保护门）
2 USB with 3 pin multi-purpose socket
with flip cover
¥:265.00

F71-0072
小板一位开关带二位USB带
13A多功能插座（带指示灯）
1 gang switch with two USB and
13A multi-function socket
¥:240.00

F71-0073
小板一位开关带二位USB带
13A方角插座（带指示灯）
2 USB with 13A a quare comer
socket with flip cover
¥:240.00

F71-0074
小板13A多功能带Type-c+USB
13A multifunction with type-C
+ USB
¥:230.00

F71-0075
小板13A方插带Type-c+USB
13A square angle band type-C
+ USB
¥:230.00

F71-0076
小板一位开关13A多功能插座带
Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose
socket with Type-c+USB(with light)
¥:240.00

F71-0077
小板二位USB带13A多功能插座
带小开关（竖）
2 USB with Three very multi-purpose
socket with switch
¥:240.00

F71-0078
小板一位开关13A方插带
Type-c+USB(带指示灯)
1 gang switch 13A square insert belt
Type-c+USB(with light)
¥:240.00

F71-0079
小板二位USB带13A方角插座
带小开关（竖）
2 USB with 13A square corner
socket with switth
¥:240.00

F71-0080
小板15A泰式多功能插座带二
位USB
15A Thai multi-function socket
with 2-bit USB
¥:230.00

F71-0081
小板15A泰式+2USB
15A Thai + 2USB
¥:230.00

F71-0082
小板二位USB带13A多功能插座（横）
2 USB with 3 pin multi-purpose socket
¥:230.00

F71-0083
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:220.00

F71-0084
小板二位USB带10A二三极
插座带开关
2 USB and 5 pin socket with switch
¥:230.00

F71-0085
10A二三极五孔带USB+TYPE-C 2.1A
10A 5 pole socket with USB+type-c 2.1A
¥:240.00
10A二三极五孔带USB+TYPE-C 4A
10A 5 pole socket with USB+type-c 4A
¥:360.00

F71-0086
小板一位开关带13A多功能五孔
插座带USB
1 gang switch and 5 pin multi-function
socket with USB and indicator light
¥:290.00

F71-0087
小板13A二位USB带多功能五孔插座
2 USB with 5 pin multi-function socket
¥:230.00

F71-0088
小板13A二位USB带多功能五孔
插座带开关
2 USB with 5 pin multi-function socket
with switch
¥:240.00

F71-0089
小板13A多功能五孔带USB+Type-c 2.1A
13A MF 5 pin socket with USB+type-c 2.1A
¥:240.00
小板13A多功能五孔带USB+Type-c 4A
13A MF 5 pin socket with USB+type-c 4A
¥:360.00

F71-0090
小板一位电视插座
TV socket
¥:155.00

F71-0091
小板一位电话插座 ¥:155.00
telephone socket
小板一位电脑插座 ¥:165.00
computer socket
小板一位电脑插座(超六类) ¥:218.00
computer socket(6)

F71-0092
小板双电视插座
Two TV socket
¥:175.00

F71-0093
小板双电话插座 ¥:175.00
Two telephone socket
小板双电脑插座 ¥:195.00
Two computer socket
小板双电脑插座(超六类) ¥:245.00
Two computer socket(6)
小板电话电脑插座 ¥:185.00
telephone+computer socket
小板电话电脑插座(超六类) ¥:235.00
telephone+computer socket(6)

F71-0094
小板电视电话插座 ¥:175.00
TV + telephone socket
小板电视电脑插座 ¥:185.00
TV + computer socket
小板电视电脑插座(超六类) ¥:235.00
TV + computer socket(6)

F71-0095
小板电话带USB插座 ¥:320.00
TEL + USB socket
小板电脑带USB插座 ¥:320.00
computer + USB socket
小板电脑带USB插座(超六类) ¥:370.00
computer + USB socket(6)

F71-0096
小板一位TV+FM
TV and FM
¥:230.00

F71-0097
小板一位卫星插座
Satellite socket
¥:165.00

F71-0098
小板二位卫星插座
Double satellite socket
¥:195.00

F71-0099
小板卫星+电视插座
Satellite and TV socket
¥:185.00

F71-0100
小板卫星带电话插座 ¥:185.00
Satellite and telephone socket
小板卫星带电脑插座 ¥:195.00
Satellite and computer socket
小板卫星带电脑插座(超六类) ¥:245.00
Satellite and computer socket(6)

F71-0101
小板二极插座带电视插座
2 pin socket with TV
¥:320.00

F71-0102
小板二极插座带电话插座 ¥:320.00
2 pin socket with telephone
小板二极插座带电脑插座 ¥:320.00
2 pin socket with computer
小板二极插座带电脑插座(超六类) ¥:370.00
2 pin socket with computer

F71-0103
小板一位光纤插座
Optical fiber socket
¥:195.00

F71-0104
小板二位USB插座
Double USB socket
¥:265.00

F71-0105
小板单联音响插座
Single audio socket
¥:225.00

F71-0106
小板双联音响插座
Double audio socket
¥:305.00

F71-0107
触摸延时开关（节能）
Touch delay delay switch
(energy saving)
¥:225.00

F71-0108
声光控延时开关（节能）
Sound-light controlled delay switch
(energy saving)
¥:225.00

F71-0109
红外线人体感应开关
Human body induction
¥:300.00

F71-0110
凹型地脚灯(亮光/暖光)
The footlights
¥:260.00

F71-0111
凹型红外线人体感应地脚灯(亮光/暖光)
The human body induction footlights
¥:330.00

F71-0112
平面地脚灯(亮光/暖光)
Footlights
¥:260.00

F71-0113
叮咚门铃
Ding dong doorbell
¥:291.00

F71-0114
机械式40A插卡取电 ¥:320.00
Mechanical card for electricity
感应式低频40A插卡取电 ¥:490.00
Low frequency induction card
for electricity
感应式高频40A插卡取电 ¥:590.00
High frequency induction card
for electricity

F71-0115
紧急呼叫开关
Emergency call switch
¥:280.00

F71-0116
请勿打扰请即清理门铃开关
（按键式）
Do not disturb, please namely cleaning
please + later doorbell "button"
¥:323.00

F71-0117
请勿打扰门铃开关
(按键式)
Do not disturb + doorbell "button"
¥:475.00

F71-0118
请勿打扰请即清理门铃开关
(按键式)
Do not disterb please
namely cleaning please "button"
¥:475.00

F71-0119
智能音乐控制开关
Intelligent music control switch
¥:750.00

F71-0120
温度控制调节开关
Temperature control switch
¥:780.00

F71 Glass pozzolanic 玻璃火山灰

F71-0121

温度控制调节开关
Temperature control switch
¥:930.00

F71-0122

调音开关
Tuning switch
¥:300.00

F71-0123

调光开关300W ¥:220.00
Dimming 300W
调光开关600W ¥:250.00
Dimming 600W
调光开关1000W ¥:280.00
Dimming 1000W

F71-0124

调速开关300W ¥:220.00
Speed 300W
调速开关600W ¥:250.00
Speed 600W
调速开关1000W ¥:280.00
Speed 1000W

F71-0125

一位开关带调光开关500W
1 gang with dimmer switch
¥:235.00

F71-0126

一位开关带调速开关500W
1 gang with speed switch
¥:235.00

F71-0127

13A开关带保险丝（带指示灯）
13A switch with fuse(with neon)
¥:265.00

F71-0128

20A出线柱
20A outgoing post
¥:245.00

F71-0129

剃须插座
Shaving socket
¥:500.00

F71-0130

USB+电脑插座+无线路由
USB+computer socket wireless router
¥:900.00

F71-0131

蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio+3.5+2USB+HDMI
¥:5300.00

F71-0132

HDMI
¥:320.00

F71-0133

USB+TYPE-C
¥:360.00

F71-0134

HDMI+USB
¥:320.00

F71-0135

HDMI+USB+3.5音频
HDMI+USB+3.5
¥:320.00

F71-0136

VGA+USB+3.5音频
VGA+USB +3.5
¥:320.00

F71-0137

AV+3.5音频
AV +3.5
¥:320.00

F71-0138

VGA+AV音频接口
VGA + AV audio interface
¥:320.00

F71-0139

HDMI+AV音频接口
HDMI + AV audio interface
¥:320.00

F71-0140

二分之一AV音频+卫星
Half AV audio interface+
Satellite socket
¥:320.00

F71-0141

二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:320.00

F71-0142

二分之一VGA+TV
Half VGA+TV
¥:320.00

F71-0143

二分之一VGA+电脑插座
Half VGA+computer socket
¥:320.00

F71-0144

VGA+USB
¥:320.00

F71-0145

VGA+HDMI
¥:320.00

F71-0146

45A出线柱
45A Outlet
¥:275.00

F71-0147

德式插座带开关（WIFI版）
German socket with switch
(WiFi version)
¥:670.00

F71-0148

法式插座带开关（WIFI版）
French socket with switch
(WiFi version)
¥:670.00

F71-0149

13A多功能插座带开关（WIFI版）
13A multi-functional socket with switch
(WiFi version)
¥:700.00

F71-0150

13A方角插座带开关（WIFI版）
13A square corner socket with switch
(WiFi version)
¥:700.00

F71-0151

空白面板
Blank plate
¥:113.00



F71-0152

大板147型二位双极开关带二位13A方角插座
147 type two position bipolar switch with double 13A square socket
¥:295.00



F71-0153

大板147型二位开关带二位13A多功能插座
147 Tow switch and double 13A multi-purpose socket
¥:295.00



F71-0154

大板147型二开双极开关带13A方插+二位USB
147 two bipolar switch and double 13A square plug + 2USB
¥:435.00



F71-0155

大板147型二位开关带13A多功能+二位USB
147 two switch and double 13A MF+2USB socket
¥:435.00

F71-0156

小板147型二位开关单控
147 2 gang 1 way switch
¥:236.00
小板147型二位开关双控
147 2 gang 2 way switch
¥:242.00

F71-0157

小板147型三位开关单控
147 3 gang 1 way switch
¥:256.00
小板147型三位开关双控
147 3 gang 2 way switch
¥:265.00

F71-0158

小板147型四位开关单控
147 4 gang 1 way switch
¥:276.00
小板147型四位开关双控
147 4 gang 2 way switch
¥:288.00

F71-0159

小板147型五位开关单控
147 5 gang 1 way switch
¥:296.00
小板147型 五位开关双控
147 5 gang 2 way switch
¥:311.00

F71-0160

小板147型六位开关单控
147 6 gang 1 way switch
¥:311.00
小板147型六位开关双控
147 6 gang 2 way switch
¥:334.00

F71-0161

小板147型七位开关单控
147 7 gang 1 way switch
¥:336.00
小板147型七位开关双控
147 7 gang 2 way switch
¥:357.00

F71-0162

小板147型八位开关单控
147 8 gang 1 way switch
¥:356.00
小板147型八位开关双控
147 8 gang 2 way switch
¥:380.00

F71-0163

147 二位16A多功能三极插座
147 Double 16A MF socket
¥:276.00

F71-0164

147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:312.00



F71-0165

小板147型二位15A美标扁插座
147 Double 15A triode flat Ammerican standard socket
¥:310.00

F71-0166

小板147型二位15A泰式三极插座
147 Double 15A triode flat Ammerican standard socket
¥:310.00

F71-0167

147 二位13A方角插座
147 Double 13A square comer
¥:276.00

F71-0168

147 二位15A圆孔插座
147 Double 15A 3 round pins socket
¥:310.00

F71-0169

小板147型二位13A错位多功能五孔插座
147 type Double 13A dislocation multi-function 5 hole socket
¥:332.00

F71-0170

147 二位10A二三极插座
147 Double position two and three pole socket
¥:250.00

F71-0171

147二位开关带二位13A方角插座
147 Tow switch and double 13A square comer socket
¥:285.00

F71-0172

147 二位开关带二位13A多功能插座
147 two switch with double 13A MF socket
¥:285.00

F71-0173

147二位开关带二位五孔多功能插座
147 Tow switch and double 5 pin MF socket
¥:315.00

F71-0174

147 二位开关带二位13A方角插座(带指示灯)
147 Tow switch and double 13A square comer socket with indicator light
¥:295.00



F71-0175

147 二位开关带二位13A多功能插座（带指示灯）
147 Tow switch and double 13A MF socket with light
¥:295.00

F71-0176

147二位开关二位13A方插+二位USB（小板）
147 Tow switch and double 13A square comer socket+2USB
¥:385.00

F71-0177

147二位开关二位13A多功能+二位USB（小板）
147 Tow switch and double 13A MF socket+2USB
¥:385.00

F71-0178

147 二位开关二位13A方插+USB/Type-c
147 two switch double 13A square band lamp+USB/Type-c
¥:385.00

F71-0179

147 二位开关二位13A多功能插带灯+USB/Type-c
147 two switch double 13A MF band lamp+USB/Type-c
¥:385.00

F71-0180

147 二位开关带二位15A圆角插座(带指示灯)
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:326.00

F71 Glass pozzolanic 玻璃火山灰

F71-0181

小板147型二位开关带二位13A方角插座(带指示灯)
147 two switch with double 13A square angle socket (with indicator light)
¥:326.00

F71-0182

147型二位剃须插座
147 two shaving socket
¥:680.00

F71-0183

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 kitchen switch
¥:415.00

F71-0184

14745A开关+一位开关13A方角插带指示灯(组合厨房开关)
147 kitchen switch
¥:415.00

F71-0185

147 45A开关+一位开关13A方插带灯(厨房开关)
147 Kitchen switch
¥:415.00

F71-0186

147 45A双极开关带指示灯
147 type 45A bipolar switch
¥:360.00

F71-0187

147 16A二位德式插座
147 Double German socket
¥:326.00

F71-0188

147 16A二位法式插座
147 Double French socket
¥:326.00

F71-0189

147 16A二位德式插座
147 Double Geman socket
¥:326.00

F71-0190

147 16A二位法式插座
147 Double French socket
¥:326.00

F71-0191

147型二位德式带USB+type-c(模块)
147 double German + USB / type-C (module)
¥:510.00

F71-0192

147型二位法式带USB+type-c(模块)
147 double French + USB / type-C (module)
¥:510.00

F71-0193

二位17A德式+二位USB（小板连体）
147 Double German with 2USB
¥:410.00

F71-0194

147二位16A法式+2USB（小板连体）
147 Double French with 2USB
¥:410.00

F71-0195

147 四位USB插座
147 4 USB socket
¥:530.00

F71-0196

147 二位多功能插座+4USB
147 2-bit multi-function socket + 4USB
¥:460.00

F71-0197

147 二位13A方角插座+4USB
147 two bit 13A square socket +4USB
¥:460.00

F71-0198

147 一位13A方角插座+二位USB
13A square comer socket and Two USB
¥:418.00

F71-0199

147 一位16A多功能插座+二位USB插座
16A MF 3 pin socket and 2USB socket
¥:418.00

F71-0200

147型二位开关带二位多功能五孔插座带双USB
147 Tow switch and double 13A 5 pin multi-purpose socket+2USB
¥:415.00

F71-0201

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two position switch with two position 13A multifunction Five hole socket + 2 USB (with indicator)
¥:580.00

F71-0202

147 二位13A多功能五孔插座+四位USB
147 13A double 5 pin multi-function socket+4USB
¥:460.00

F71-0203

147 二位开关二位13A多功能五孔插座+四位USB
147 two switch double 5 pin multi function socket+4USB
¥:480.00

F71-0204

147型二位开关带二位多功能五孔插座带USB+type-c
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:550.00

F71-0205

147型二位开关带二位13A多功能带四位USB（带指示灯）
147 two switch and double 13A MF +4USB socket (with indicator light)
¥:480.00

F71-0206

147型二开带二位13A方插带四位USB
147 type two switch two position 13A square inserting band 4 USB
¥:480.00

F71-0207

147二位13A方插带四位USB
147 type double position 13A square inserting band 4 USB
¥:460.00

F71-0208

147 二位13A多功能+4USB(带盖板)
147 double 13A multi-function + 4USB (with cover plate)
¥:530.00

F71-0209

147型二位13A方插带四位USB(带盖板)
147 double 13A square inserting +4USB socket
¥:530.00

F71-0210

147一开单控带13A多功能五孔插座
147 1 gang 1 way switch with 13A 5 pin MF socket
¥:274.00

F71-0211

147 一开单控带13A方角插座+双USB
147 1 gang 1 way socket with 13A square Angle socket +2USB
¥:348.00

F71-0212

147型一开单控带15A泰式插座
147 one open single control with 15A Thai socket
¥:283. 00

F71-0213

147型一开单控带多功能五孔+双USB插座
147 one open single control and MF 5 pin + 2USB socket
¥:348. 00

F71-0214

147型二位10A二三极五孔带四位USB插座
147 double 10A 5 pin socket + 4 USB with indicator light
¥:440.00

F71-0215

147型二位13A多功能带四位USB带小开关
147 double 13A 3pin multi-function socket + 4USB with small switch
¥:480.00

F71-0216

147型二位13A方插带四位USB带小开关
147 double 13A square plug with 4USB with small switch
¥:480.00

F71-0217

147 二位一开16A多功能带指示灯
147 Tow switch and double 16A MF 3 pin socket with neon
¥:326.00

F71-0218

147二位多功能带四位USB
147 type multi-functional 3 pin socket band 4 USB
¥:460.00

F71-0219

147 16A多功能+万用五孔插座
147 16A MF 3 pin +MF 5 pin socket
¥:295.00

F71-0220

147 10A二二二二极插座
10A 8 pole socket
¥:310.00

F71-0221

147二开单控开关带16A多功能插座
147 two switch single control 16A MF 3 pin socket
¥:276.00

F71-0222

147型二开单控带13A方角插座
147 type double open single control socket with 13A square angle
¥:276.00

F71-0223

147型10A二极带10A二极插座
147 10A two pole with 10A two pole socket
¥:280.00

F71-0224

147型二位一开单控带二位16A三极插座
147 type 2 gang 1 way switch double 16A three pole socket
¥:320.00

F71-0225

147型二位一开单控带二位10A二三极插座
147 type 2 gang 1 way switch double 10A 5 pole socket
¥:320.00

F71-0226

147型二位10A二三极插座 ¥:460.00
带USB+type-c 2.1A
147 type double 10A 5 pole socket USB + type-c 2.1A
147型二位10A二三极插座 ¥:720.00
带USB+type-c 4A
147 type double 10A 5 pole socket USB + type-c 4A

F71-0227

147型二位多功能五孔插座 ¥:460.00
带USB+type-c 2.1A
147 type double 5 pin MF socket USB + type-c 2.1A
147型二位多功能五孔插座 ¥:720.00
带USB+type-c 4A
147 type double 5 pin MF socket USB + type-c 4A

F71-0228

147型13A多功能双USB带多五孔插座
147 type 13A multi-function 2USB with 5 pin multi-functional socket
¥:480.00

F71-0229

147型二位电脑插座带二位USB插座
147 type double computer with 2USB socket
¥:460.00

F71-0230

147型二位电话带二位电脑插座
147 double telephone with double computer socket
¥:390.00

F71-0231

147型 二位电脑插座带16A多功能插座
147 double computer with 16A MF pin socket
¥:333.00

F71-0232

147型二位16A德式插座带防水
147 two position 16A German socket with waterproof
¥:350.00

F71-0233

147型二位16A法式插座带防水
147 two position 16A French socket with waterproof
¥:350.00

F71-0234

147二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 double switch double German socket+USB/Type-c with light
¥:550.00

F71-0235

147二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 double switch double French socket+USB/Type-c with light
¥:550.00

F71-0236

147二位开关二位16A德式插座（带指示灯）
147 two switch double 16A German socket with light
¥:365.00

F71-0237

147二位开关二位16A法式插座（带指示灯）
147 two switch double 16A French socket with light
¥:365.00

F71-0238

147二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket + 2usb with light
¥:450.00

F71-0239

147二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch double 16A French socket +2USB with light
¥:450.00

F71-0240

147型二位空白面板
147 Blank plate
¥:185.00

F71 玻璃香槟金
Glass champagne gold



调速开关 Speed control switch

控制回路：调速一开(零火线)
产品分类：WIFI开关.WIFI+RF开关.ZIGBEE开关
工作电压：100V~240V~,50Hz/60Hz
工作电流：2A Max(纯阻性负载)
负载类型：总负载低于400W
产品材质：钢化玻璃面板+阻燃PC外壳
尺寸(高*宽*厚)：86mm*86mm*34mm
使用环境：温度0℃~40℃,相对湿度小于95%
无线频率：2.4GHz 433.92MHz

Control loop: Speed regulation one open (zero live line)
Product classification: WiFi switch. WiFi + RF switch. ZigBee switch
Working voltage: 100V ~ 240V ~, 50 Hz / 60 Hz
Working current: 2A max (pure resistive load)
Load type: total load less than 400W
Product material: toughened glass panel + flame retardant PC shell
Size (height * width * thickness): 86mm * 86mm * 34mm
Use environment: temperature 0 ℃ ~ 40 ℃, relative humidity less than 95%
Wireless frequency: 2.4GHz 433.92MHz

F71 Glass champagne gold 玻璃香槟金

F71-0001

一位触摸开关(零火线) ¥:400.00
1 gang 1 way touch switch
蓝牙WIFI一位触摸开关(零火版) ¥:500.00
1 gang 1 way touch switch
涂鸦Zigbee一位触摸开关(零火版) ¥:600.00
1 gang 1 way touch switch

F71-0002

二位触摸开关（零火版） ¥:450.00
2 gang 1 way touch switch
蓝牙WIFI二位触摸开关(零火版) ¥:550.00
2 gang 1 way touch switch
涂鸦Zigbee二位触摸开关(零火版) ¥:650.00
2 gang 1 way touch switch

F71-0003

三位触摸开关（零火版） ¥:500.00
3 gang 1 way touch switch
蓝牙WIFI三位触摸开关(零火版) ¥:600.00
3 gang 1 way touch switch
涂鸦Zigbee三位触摸开关(零火版) ¥:700.00
3 gang 1 way touch switch

F71-0004

四位触摸开关（零火版） ¥:550.00
4 gang 1 way touch switch
蓝牙WIFI四位触摸开关(零火版) ¥:650.00
4 gang 1 way touch switch
涂鸦Zigbee四位触摸开关(零火版) ¥:750.00
4 gang 1 way touch switch

F71-0005

调光开关(零火线) ¥:600.00
Dimming switch (zero live wire)
WIFI调光开关 ¥:700.00
WiFi dimming switch
Zigbee调光开关 ¥:800.00
Zigbee dimming switch

F71-0006

调速开关(零火线) ¥:600.00
Speed control switch (zero live line)
WIFI调速开关 ¥:700.00
WiFi speed control switch
Zigbee调速开关 ¥:800.00
Zigbee speed control switch

F71-0007

窗帘开关(零火线) ¥:600.00
Curtain switch (zero live wire)
WIFI窗帘开关 ¥:700.00
WiFi curtain switch
Zigbee窗帘开关 ¥:800.00
Zigbee curtain switch

F71-0008

大板一位开关带16A多功能插座
1 gang switch and 3 pin multi-purpose socket
¥:163.00

F71-0009

大板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:158.00

F71-0010

大板一位开关带16A多功能带二位USB
1 gang switch with 16A 3pin multi-function with 2USB
¥:290.00

F71-0011

一位开关2USB带13A方角插座
1 gang switch and 13A square pin socket
¥:295.00

F71-0012

小板16A一位开关单控 ¥:118. 00
16A 1 gang 1 way switch
小板16A一位开关双控 ¥:121. 00
16A 1 gang 2 way switch
小板16A一位开关多控 ¥:158.00
16A 1 gang more way switch

F71-0013

小板16A二位开关单控 ¥:138.00
16A 2 gang 1 way switch
小板16A二位开关双控 ¥:144.00
16A 2 gang 2 way switch
小板16A二位开关多控 ¥:210.00
16A 2 gang more way switch

F71-0014

小板16A三位开关单控 ¥:158.00
16A 3 gang 1 way switch
小板16A三位开关双控 ¥:167.00
16A 3 gang 2 way switch

F71-0015

小板16A四位开关单控 ¥:178.00
16A 4 gang 1 way switch
小板16A四位开关双控 ¥:190.00
16A 4 gang 2 way switch

F71-0016

小板16A三位开关多控
Small panel 16A 3 gang 3 way switch
¥:230.00

F71-0017

小板16A百叶窗升降开关
louver window lifter switch
¥:175.00

F71-0018

小板16A门控开关
gating switch
¥: 142.00

F71-0019

小板16A英式门控开关
British gating switch
¥:142.00

F71-0020

小板16A门铃开关
doorbell switch
¥:142.00

F71-0021

小板16A拔动一位开关单控 ¥:175.00
1 gang 1 way toggle switch
小板16A拔动一位开关双控 ¥:180.00
1 gang 2 way toggle switch

F71-0022

小板16A拔动二位开关单控 ¥:190.00
2 gang 1 way toggle switch
小板16A拔动二位开关双控 ¥:200.00
2 gang 2 way toggle switch

F71-0023

小板16A拔动三位开关单控 ¥:205.00
3 gang 1 way toggle switch
小板16A拔动三位开关双控 ¥:220.00
3 gang 2 way toggle switch

F71-0024

小板16A拔动四位开关单控 ¥:220.00
4 gang 1 way toggle switch
小板16A拔动四位开关双控 ¥:240.00
4 gang 2 way toggle switch

F71-0025

小板20A双极开关带指示灯 ¥:187.00
20A switch with indicator light
小板45A双极开关带指示灯 ¥:226.00
45A swich with indicator light

F71-0026

小板45A双极开关带指示灯
45A switch with indicator light
¥:226.00

F71-0027

小板16A卷帘门复位开关
Shutter reset switch
¥:195.00

F71-0028

小板16A德式插座
German socket
¥:163.00

F71-0029

小板16A法式插座
French socket
¥:163..00

F71-0030

小板16A俄式插座
Russian socket
¥:163.00

F71-0031

小板16A以色列插座
Israel socket
¥:175.00

F71-0032

小板16A意大利+德式插座
Italy+German socket
¥:175.00

F71-0033

大板16A三极插座
16A 3 pole socket
¥:130.00

F71-0034

大板10A二三极插座
10A 5 pole socket
¥:125.00

F71-0035

大板10A错位二三极插座
10A Two or three pole socket
¥:130.00

F71-0036

大板10A二三极插座
10A 7 pole socket
¥:135.00

F71-0037

小板16A一位开关单控带16A三极插座
1 gang 1 way switch and 16A 3 pole socket
¥:160.00
小板16A一位开关双控带16A三极插座
1 gang 2 way switch and 16A 3 pole socket
¥:163.00

F71-0038

大板一位开关单控带10A二三极插座
1 gang 2 way switch and 5 pole socket
¥:160.00
大板一位开关双控带10A二三极插座
1 gang 2 way switch and 5 pole socket
¥:163.00

F71-0039

小板10A二位开关单控带二三极插座
2 gang 1 way switch and 5 pole socket
¥:180.00
小板10A二位开关双控带二三极插座
2 gang 2 way switch and 5 pole socket
¥:186.00

F71-0040

小板10A二极插座
10A 2 pole socket
¥:140.00

F71-0041

小板10A二二极插座
10A Double 2 pole socket
¥:155.00

F71-0042

小板10A一位开关带二极插座
1 gang switch and 2 pole socket
¥:155.00

F71-0043

小板10A一位开关带二二极座
1gang switch and 4 pole socket
¥:165.00

F71-0044

小板16A多功能三极插座
16A 3 pin universal socket
¥:138.00

F71-0045

小板13A二三极多功能插座
5 pin multi-function socket
¥:156.00

F71-0046

小板13A二三极错位多功能插座
5 pin multi-function socket
¥:166.00

F71-0047

小板13A方角插座
13A square corner socket
¥:138.00

F71-0048

小板15A圆角插座
15A 3 round pins socket
¥:155.00

F71-0049

小板15A美标扁三极插座
15A triode flat American standard socket
¥:158.00

F71-0050

小板15A泰式多功能三极插座
15A Thai type multi-function 3 pole socket
¥:158.00

F71-0051

小板错位泰式六孔插座
Dislocation Thai 6 pin socket
¥:165.00

F71-0052

小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
¥:158.00



F71-0053

小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pins socket
¥:163.00

F71-0054

小板一位开关带16A多功能插座
1 gang switch and 3 pin MF socket
¥:163.00



F71-0055

小板一位开关带13A方角插座（带指示灯）
1 gang switch and 13A square pin socket
¥:158.00



F71-0056

小板一位开关带15A圆孔插座（带指示灯）
1 gang switch and 15A 3 round pins socket
¥:163.00

F71-0057

小板一位开关带16A多功能插座（带指示灯）
1 gang switch and 3 pin MF socket(with neon)
¥:163.00

F71-0058

小板一位开关带13A多功能五孔插座（带指示灯）
1 gang switch and 5 pin multi-function socket
¥:178.00

F71-0059

小板16A德式插座带二位USB
2 USB with German socket
¥:230.00

F71-0060

小板16A法式插座带二位USB
2 USB with French socket
¥:230.00

F71 Glass champagne gold 玻璃香槟金

F71-0061
小板16A德式插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:230.00

F71-0062
小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:230.00

F71-0063
小板16A一位开关带德式插座
1 gang German socket
¥:175.00

F71-0064
小板16A一位开关带法式插座
1 gang French socket
¥:175.00

F71-0065
小板16A德式插座带防水
German socket and Waterproof belt
¥:175.00

F71-0066
小板16A法式插座带防水
French socket and Waterproof belt
¥:175.00

F71-0067
小板二位USB带13A方角插座（横）
2 USB with 13A square corner socket with switch
¥:230.00

F71-0068
小板15A美标插座带USB+TYPE-C
American Standard with USB+type-C
¥:230.00

F71-0069
小板15A泰式插座带USB+TYPE-C
15A Thai MF socket with USB+type-C
¥:230.00

F71-0070
小板二位USB带13A方角插座（带保护门）
2 USB with 13A square corner socket with flip cover
¥:265.00

F71-0071
小板二位USB带13A多功能插座（带保护门）
2 USB with 3 pin multi-purpose socket with flip cover
¥:265.00

F71-0072
小板一位开关带二位USB带13A多功能插座（带指示灯）
1 gang switch with two USB and 13A multi-function socket
¥:240.00

F71-0073
小板一位开关带二位USB带13A方角插座（带指示灯）
2 USB with 13A a quare comer socket with flip cover
¥:240.00

F71-0074
小板13A多功能带Type-c+USB
13A multifunction with type-C + USB
¥:230.00

F71-0075
小板13A方插带Type-c+USB
13A square angle band type-C + USB
¥:230.00

F71-0076
小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with Type-c+USB(with light)
¥:240.00

F71-0077
小板二位USB带13A多功能插座带小开关（竖）
2 USB with Three very multi-purpose socket with switch
¥:240.00

F71-0078
小板一位开关13A方插带Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:240.00

F71-0079
小板二位USB带13A方角插座带小开关（竖）
2 USB with 13A square corner socket with swittch
¥:240.00

F71-0080
小板15A泰式多功能插座带二位USB
15A Thai multi-function socket with 2-bit USB
¥:230.00

F71-0081
小板15A泰式+2USB
15A Thai + 2USB
¥:230.00

F71-0082
小板二位USB带13A多功能插座（横）
2 USB with 3 pin multi-purpose socket
¥:230.00

F71-0083
小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:220.00

F71-0084
小板二位USB带10A二三极插座带开关
2 USB and 5 pin socket with switch
¥:230.00

F71-0085
10A二三极五孔带USB+TYPE-C 2.1A
10A 5 pole socket with USB+type-c 2.1A
¥:240.00
10A二三极五孔带USB+TYPE-C 4A
10A 5 pole socket with USB+type-c 4A
¥:360.00

F71-0086
小板一位开关带13A多功能五孔插座带USB
1 gang switch and 5 pin multi-function socket with USB and indicator light
¥:290.00

F71-0087
小板13A二位USB带多功能五孔插座
2 USB with 5 pin multi-function socket
¥:230.00

F71-0088
小板13A二位USB带多功能五孔插座带开关
2 USB with 5 pin multi-function socket with switch
¥:240.00

F71-0089
小板13A多功能五孔带USB+Type-c 2.1A
13A MF 5 pin socket with USB+type-c 2.1A
¥:240.00
小板13A多功能五孔带USB+Type-c 4A
13A MF 5 pin socket with USB+type-c 4A
¥:360.00

F71-0090
小板一位电视插座
TV socket
¥:155.00

F71-0091
小板一位电话插座 ¥:155.00
telephone socket
小板一位电脑插座 ¥:165.00
computer socket
小板一位电脑插座(超六类) ¥:218.00
computer socket(6)

F71-0092
小板双电视插座
Two TV socket
¥:175.00

F71-0093
小板双电话插座 ¥:175.00
Two telephone socket
小板双电脑插座 ¥:195.00
Two computer socket
小板双电脑插座(超六类) ¥:245.00
Two computer socket(6)
小板电话电脑插座 ¥:185.00
telephone+computer socket
小板电话电脑插座(超六类) ¥:235.00
telephone+computer socket(6)

F71-0094
小板电视电话插座 ¥:175.00
TV + telephone socket
小板电视电脑插座 ¥:185.00
TV + computer socket
小板电视电脑插座(超六类) ¥:235.00
TV + computer socket(6)

F71-0095
小板电话带USB插座 ¥:320.00
TEL + USB socket
小板电脑带USB插座 ¥:320.00
computer + USB socket
小板电脑带USB插座(超六类) ¥:370.00
computer + USB socket(6)

F71-0096
小板一位TV+FM
TV and FM
¥:230.00

F71-0097
小板一位卫星插座
Satellite socket
¥:165.00

F71-0098
小板二位卫星插座
Double satellite socket
¥:195.00

F71-0099
小板卫星+电视插座
Satellite and TV socket
¥:185.00

F71-0100
小板卫星带电话插座 ¥:185.00
Satellite and telephone socket
小板卫星带电脑插座 ¥:195.00
Satellite and computer socket
小板卫星带电脑插座(超六类) ¥:245.00
Satellite and computer socket(6)

F71-0101
小板二极插座带电视插座
2 pin socket with TV
¥:320.00

F71-0102
小板二极插座带电话插座 ¥:320.00
2 pin socket with telephone
小板二极插座带电脑插座 ¥:320.00
2 pin socket with computer
小板二极插座带电脑插座(超六类) ¥:370.00
2 pin socket with computer

F71-0103
小板一位光纤插座
Optical fiber socket
¥:195.00

F71-0104
小板二位USB插座
Double USB socket
¥:265.00

F71-0105
小板单联音响插座
Single audio socket
¥:225.00

F71-0106
小板双联音响插座
Double audio socket
¥:305.00

F71-0107
触摸延时开关（节能）
Touch delay delay switch (energy saving)
¥:225.00

F71-0108
声光控延时开关（节能）
Sound-light controlled delay switch (energy saving)
¥:225.00

F71-0109
红外线人体感应开关
Human body induction
¥:300.00

F71-0110
凹型地脚灯(亮光/暖光)
The footlights
¥:260.00

F71-0111
凹型红外线人体感应地脚灯(亮光/暖光)
The human body induction footlights
¥:330.00

F71-0112
平面地脚灯(亮光/暖光)
Footlights
¥:260.00

F71-0113
叮咚门铃
Ding dong doorbell
¥:291.00

F71-0114
机械式40A插卡取电 ¥:320.00
Mechanical card for electricity
感应式低频40A插卡取电 ¥:490.00
Low frequency induction card for electricity
感应式高频40A插卡取电 ¥:590.00
High frequency induction card for electricity



F71-0115
紧急呼叫开关
Emergency call switch
¥:280.00

F71-0116
请勿打扰请即清理门铃开关（按键式）
Do not disturb, please namely cleaning please + later doorbell "button"
¥:323.00

F71-0117
请勿打扰门铃开关(按键式)
Do not disturb + doorbell "button"
¥:475.00

F71-0118
请勿打扰请即清理门铃开关(按键式)
Do not disterb please namely cleaning please "button"
¥:475.00

F71-0119
智能音乐控制开关
Intelligent music control switch
¥:750.00

F71-0120
温度控制调节开关
Temperature control switch
¥:780.00

F71 Glass champagne gold 玻璃香槟金

F71-0121
温度控制调节开关
Temperature control switch
¥:930.00

F71-0122
调音开关
Tuning switch
¥:300.00

F71-0123
调光开关300W ¥:220.00
Dimming 300W
调光开关600W ¥:250.00
Dimming 600W
调光开关1000W ¥:280.00
Dimming 1000W

F71-0124
调速开关300W ¥:220.00
Speed 300W
调速开关600W ¥:250.00
Speed 600W
调速开关1000W ¥:280.00
Speed 1000W

F71-0125
一位开关带调光开关500W
1 gang with dimmer switch
¥:235.00

F71-0126
一位开关带调速开关500W
1 gang with speed switch
¥:235.00

F71-0127
13A开关带保险丝（带指示灯）
13A switch with fuse(with neon)
¥:265.00

F71-0128
20A出线柱
20A outgoing post
¥:245.00

F71-0129
剃须插座
Shaving socket
¥:500.00

F71-0130
USB+电脑插座+无线路由
USB+computer socket wireless router
¥:900.00

F71-0131
蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio+3.5+2USB+HDMI
¥:5300.00

F71-0132
HDMI
¥:320.00

F71-0133
USB+TYPE-C
¥:360.00

F71-0134
HDMI+USB
¥:320.00

F71-0135
HDMI+USB+3.5音频
HDMI+USB+3.5
¥:320.00

F71-0136
VGA+USB+3.5音频
VGA+USB +3.5
¥:320.00

F71-0137
AV+3.5音频
AV +3.5
¥:320.00

F71-0138
VGA+AV音频接口
VGA + AV audio interface
¥:320.00

F71-0139
HDMI+AV音频接口
HDMI + AV audio interface
¥:320.00

F71-0140
二分之一AV音频+卫星
Half AV audio interface+
Satellite socket
¥:320.00

F71-0141
二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:320.00

F71-0142
二分之一VGA+TV
Half VGA+TV
¥:320.00

F71-0143
二分之一VGA+电脑插座
Half VGA+computer socket
¥:320.00

F71-0144
VGA+USB
¥:320.00



F71-0145
VGA+HDMI
¥:320.00

F71-0146
45A出线柱
45A Outlet
¥:275.00

F71-0147
德式插座带开关（WIFI版）
German socket with switch
(WiFi version)
¥:670.00

F71-0148
法式插座带开关（WIFI版）
French socket with switch
(WiFi version)
¥:670.00

F71-0149
13A多功能插座带开关（WIFI版）
13A multi-functional socket with switch
(WiFi version)
¥:700.00

F71-0150
13A方角插座带开关（WIFI版）
13A square corner socket with switch
(WiFi version)
¥:700.00

F71-0151
空白面板
Blank plate
¥:113.00

F71-0152
大板147型二位双极开关带二位13A方角插座
147 type two position bipolar switch with double 13A square socket
¥:295.00



F71-0153
大板147型二位开关带二位13A多功能插座
147 Tow switch and double 13A multi-purpose socket
¥:295.00

F71-0154
大板147型二开双极开关带13A方插+二位USB
147 two bipolar switch and double 13A square plug + 2USB
¥:435.00

F71-0155
大板147型二位开关带13A多功能+二位USB
147 two switch and double 13A MF+2USB socket
¥:435.00

F71-0156
小板147型二位开关单控
147 2 gang 1 way switch
¥:236.00
小板147型二位开关双控
147 2 gang 2 way switch
¥:242.00

F71-0157
小板147型三位开关单控
147 3 gang 1 way switch
¥:256.00
小板147型三位开关双控
147 3 gang 2 way switch
¥:265.00

F71-0158
小板147型四位开关单控
147 4 gang 1 way switch
¥:276.00
小板147型四位开关双控
147 4 gang 2 way switch
¥:288.00

F71-0159
小板147型五位开关单控
147 5 gang 1 way switch
¥:296.00
小板147型 五位开关双控
147 5 gang 2 way switch
¥:311.00

F71-0160
小板147型六位开关单控
147 6 gang 1 way switch
¥:311.00
小板147型六位开关双控
147 6 gang 2 way switch
¥:334.00

F71-0161
小板147型七位开关单控
147 7 gang 1 way switch
¥:336.00
小板147型七位开关双控
147 7 gang 2 way switch
¥:357.00



F71-0162
小板147型八位开关单控
147 8 gang 1 way switch
¥:356.00
小板147型八位开关双控
147 8 gang 2 way switch
¥:380.00

F71-0163
147 二位16A多功能三极插座
147 Double 16A MF socket
¥:276.00

F71-0164
147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:312.00



F71-0165
小板147型二位15A美标扁插座
147 Double 15A triode flat Ammerican standard socket
¥:310.00



F71-0166
小板147型二位15A泰式三极插座
147 Double 15A triode flat Ammerican standard socket
¥:310.00

F71-0167
147 二位13A方角插座
147 Double 13A square comer
¥:276.00



F71-0168
147 二位15A圆孔插座
147 Double 15A 3 round pins socket
¥:310.00



F71-0169
小板147型二位13A错位多功能五孔插座
147 type Double 13A dislocation multi-function 5 hole socket
¥:332.00

F71-0170
147 二位10A二三极插座
147 Double position two and three pole socket
¥:250.00

F71-0171
147二位开关带二位13A方角插座
147 Tow switch and double 13A square comer socket
¥:285.00

F71-0172
147 二位开关带二位13A多功能插座
147 two switch with double 13A MF socket
¥:285.00

F71-0173
147二位开关带二位五孔多功能插座
147 Tow switch and double 5 pin MF socket
¥:315.00

F71-0174
147 二位开关带二位13A方角插座(带指示灯)
147 Tow switch and double 13A square comer socket with indicator light
¥:295.00



F71-0175
147 二位开关带二位13A多功能插座（带指示灯）
147 Tow switch and double 13A MF socket with light
¥:295.00

F71-0176
147二位开关二位13A方插+二位USB（小板）
147 Tow switch and double 13A square comer socket+2USB
¥:385.00

F71-0177
147二位开关二位13A多功能+二位USB（小板）
147 Tow switch and double 13A MF socket+2USB
¥:385.00

F71-0178
147 二位开关二位13A方插+USB/Type-c
147 two switch double 13A square band lamp+USB/Type-c
¥:385.00

F71-0179
147 二位开关二位13A多功能插带灯+USB/Type-c
147 two switch double 13A MF band lamp+USB/Type-c
¥:385.00



F71-0180
147 二位开关带二位15A圆角插座(带指示灯)
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:326.00

F71 Glass champagne gold 玻璃香槟金



F71-0181

小板147型二位开关带二位13A方角插座(带指示灯)
147 two switch with double 13A square angle socket (with indicator light)
¥:326.00

F71-0182

147型二位剃须插座
147 two shaving socket
¥:680.00

F71-0183

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 kitchen switch
¥:415.00

F71-0184

14745A开关+一位开关13A方角插带指示灯(组合厨房开关)
147 kitchen switch
¥:415.00

F71-0185

147 45A开关+一位开关13A方插带灯(厨房开关)
147 Kitchen switch
¥:415.00

F71-0186

147 45A双极开关带指示灯
147 type 45A bipolar switch
¥:360.00

F71-0187

147 16A二位德式插座
147 Double German socket
¥:326.00

F71-0188

147 16A二位法式插座
147 Double French socket
¥:326.00

F71-0189

147 16A二位德式插座
147 Double Geman socket
¥:326.00

F71-0190

147 16A二位法式插座
147 Double French socket
¥:326.00

F71-0191

147型二位德式带USB+type-c(模块)
147 double German + USB / type-C (module)
¥:510.00

F71-0192

147型二位法式带USB+type-c(模块)
147 double French + USB / type-C (module)
¥:510.00

F71-0193

二位17A德式+二位USB（小板连体）
147 Double German with 2USB
¥:410.00

F71-0194

147二位16A法式+2USB（小板连体）
147 Double French with 2USB
¥:410.00

F71-0195

147 四位USB插座
147 4 USB socket
¥:530.00

F71-0196

147 二位多功能插座+4USB
147 2-bit multi-function socket + 4USB
¥:460.00

F71-0197

147 二位13A方角插座+4USB
147 two bit 13A square socket +4USB
¥:460.00

F71-0198

147 一位13A方角插座+二位USB
13A square comer socket and Two USB
¥:418.00

F71-0199

147 一位16A多功能插座+二位USB插座
16A MF 3 pin socket and 2USB socket
¥:418.00

F71-0200

147型二位开关带二位多功能五孔插座带双USB
147 Tow switch and double 13A 5 pin multi-purpose socket+2USB
¥:415.00



F71-0201

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two position switch with two position 13A multifunction Five hole socket + 2 USB (with indicator)
¥:580.00

F71-0202

147 二位13A多功能五孔插座+四位USB
147 13A double 5 pin multi-function socket+4USB
¥:460.00

F71-0203

147 二位开关二位13A多功能五孔插座+四位USB
147 two switch double 5 pin multi function socket+4USB
¥:480.00

F71-0204

147型二位开关带二位多功能五孔插座带USB+type-c
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:550.00

F71-0205

147型二位开关带二位13A多功能带四位USB（带指示灯）
147 two switch and double 13A MF +4USB socket (with indicator light)
¥:480.00

F71-0206

147型二开带二位13A方插带四位USB
147 type two switch two position 13A square inserting band 4 USB
¥:480.00

F71-0207

147二位13A方插带四位USB
147 type double position 13A square inserting band 4 USB
¥:460.00

F71-0208

147 二位13A多功能+4USB(带盖板)
147 double 13A multi-function + 4USB (with cover plate)
¥:530.00

F71-0209

147型二位13A方插带四位USB(带盖板)
147 double 13A square inserting +4USB socket
¥:530.00

F71-0210

147一开单控带13A多功能五孔插座
147 1 gang 1 way switch with 13A 5 pin MF socket
¥:274.00

F71-0211

147 一开单控带13A方角插座+双USB
147 1 gang 1 way socket with 13A square Angle socket +2USB
¥:348.00

F71-0212

147型一开单控带15A泰式插座
147 one open single control with 15A Thai socket
¥:283. 00

F71-0213

147型一开单控带多功能五孔+双USB插座
147 one open single control and MF 5 pin + 2USB socket
¥:348. 00

F71-0214

147型二位10A二三极五孔带四位USB插座
147 double 10A 5 pin socket + 4 USB with indicator light
¥:440.00

F71-0215

147型二位13A多功能带四位USB带小开关
147 double 13A 3pin multi-function socket + 4USB with small switch
¥:480.00

F71-0216

147型二位13A方插带四位USB带小开关
147 double 13A square plug with 4USB with small switch
¥:480.00

F71-0217

147 二位一开16A多功能带指示灯
147 Tow switch and double 16A MF 3 pin socket with neon
¥:326.00

F71-0218

147二位多功能带四位USB
147 type multi-functional 3 pin socket band 4 USB
¥:460.00



F71-0219

147 16A多功能+万用五孔插座
147 16A MF 3 pin +MF 5 pin socket
¥:295.00



F71-0220

147 10A二二二二极插座
10A 8 pole socket
¥:310.00

F71-0221

147二开单控开关带16A多功能插座
147 two switch single control 16A MF 3 pin socket
¥:276.00

F71-0222

147型二开单控带13A方角插座
147 type double open single control socket with 13A square angle
¥:276.00



F71-0223

147型10A二极带10A二极插座
147 10A two pole with 10A two pole socket
¥:280.00

F71-0224

147型二位一开单控带二位16A三极插座
147 type 2 gang 1 way switch double 16A three pole socket
¥:320.00

F71-0225

147型二位一开单控带二位10A二三极插座
147 type 2 gang 1 way switch double 10A 5 pole socket
¥:320.00

F71-0226

147型二位10A二三极插座 ¥:460.00
带USB+type-c 2.1A
147 type double 10A 5 pole socket USB + type-c 2.1A
147型二位10A二三极插座 ¥:720.00
带USB+type-c 4A
147 type double 10A 5 pole socket USB + type-c 4A

F71-0227

147型二位多功能五孔插座 ¥:460.00
带USB+type-c 2.1A
147 type double 5 pin MF socket USB + type-c 2.1A
147型二位多功能五孔插座 ¥:720.00
带USB+type-c 4A
147 type double 5 pin MF socket USB + type-c 4A

F71-0228

147型13A多功能双USB带多五孔插座
147 type 13A multi-function 2USB with 5 pin multi-functional socket
¥:480.00

F71-0229

147型二位电脑插座带二位USB插座
147 type double computer with 2USB socket
¥:460.00

F71-0230

147型二位电话带二位电脑插座
147 double telephone with double computer socket
¥:390.00

F71-0231

147型 二位电脑插座带16A多功能插座
147 double computer with 16A MF pin socket
¥:333.00

F71-0232

147型二位16A德式插座带防水
147 two position 16A German socket with waterproof
¥:350.00

F71-0233

147型二位16A法式插座带防水
147 two position 16A French socket with waterproof
¥:350.00

F71-0234

147二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 double switch double German socket+USB/Type-c with light
¥:550.00

F71-0235

147二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 double switch double French socket+USB/Type-c with light
¥:550.00

F71-0236

147二位开关二位16A德式插座（带指示灯）
147 two switch double 16A German socket with light
¥:365.00

F71-0237

147二位开关二位16A法式插座（带指示灯）
147 two switch double 16A French socket with light
¥:365.00

F71-0238

147二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket + 2usb with light
¥:450.00

F71-0239

147二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch double 16A French socket +2USB with light
¥:450.00

F71-0240

147型二位空白面板
147 Blank plate
¥:185.00

F71 玻璃爵士黑
Glass jazz black

天猫直连 Tmall direct link
蓝牙配对 Bluetooth pairing
APP控制 App control
语音控制 Voice control
智能联动 Intelligent linkage

F71 Baking paint gray 玻璃爵士黑

F71-0001

一位触摸开关(零火线) ￥:400.00
1 gang 1 way touch switch
蓝牙WIFI一位触摸开关(零火版) ￥:500.00
1 gang 1 way touch switch
涂鸦Zigbee一位触摸开关(零火版) ￥:600.00
1 gang 1 way touch switch

F71-0002

二位触摸开关（零火版） ￥:450.00
2 gang 1 way touch switch
蓝牙WIFI二位触摸开关(零火版) ￥:550.00
2 gang 1 way touch switch
涂鸦Zigbee二位触摸开关(零火版) ￥:650.00
2 gang 1 way touch switch

F71-0003

三位触摸开关（零火版） ￥:500.00
3 gang 1 way touch switch
蓝牙WIFI三位触摸开关(零火版) ￥:600.00
3 gang 1 way touch switch
涂鸦Zigbee三位触摸开关(零火版) ￥:700.00
3 gang 1 way touch switch

F71-0004

四位触摸开关（零火版） ￥:550.00
4 gang 1 way touch switch
蓝牙WIFI四位触摸开关(零火版) ￥:650.00
4 gang 1 way touch switch
涂鸦Zigbee四位触摸开关(零火版) ￥:750.00
4 gang 1 way touch switch

F71-0005

调光开关(零火线) ￥:600.00
Dimming switch (zero live wire)
WIFI调光开关 ￥:700.00
WiFi dimming switch
Zigbee调光开关 ￥:800.00
Zigbee dimming switch

F71-0006

调速开关(零火线) ￥:600.00
Speed control switch (zero live line)
WIFI调速开关 ￥:700.00
WiFi speed control switch
Zigbee调速开关 ￥:800.00
Zigbee speed control switch

F71-0007

窗帘开关(零火线) ￥:600.00
Curtain switch (zero live wire)
WIFI窗帘开关 ￥:700.00
WiFi curtain switch
Zigbee窗帘开关 ￥:800.00
Zigbee curtain switch

F71-0008

大板一位开关带16A多功能插座
1 gang switch and 3 pin multi-purpose socket
￥:163.00

F71-0009

大板一位开关带13A方角插座
1 gang switch and 13A square pin socket
￥:158.00

F71-0010

大板一位开关带16A多功能带二位USB
1 gang switch with 16A 3pin multi-function with 2USB
￥:290.00

F71-0011

一位开关2USB带13A方角插座
1 gang switch and 13A square pin socket
￥:295.00

F71-0012

小板16A一位开关单控 ￥:118. 00
16A 1 gang 1 way switch
小板16A一位开关双控 ￥:121. 00
16A 1 gang 2 way switch
小板16A一位开关多控 ￥:158.00
16A 1 gang more way switch

F71-0013

小板16A二位开关单控 ￥:138.00
16A 2 gang 1 way switch
小板16A二位开关双控 ￥:144.00
16A 2 gang 2 way switch
小板16A二位开关多控 ￥:210.00
16A 2 gang more way switch

F71-0014

小板16A三位开关单控 ￥:158.00
16A 3 gang 1 way switch
小板16A三位开关双控 ￥:167.00
16A 3 gang 2 way switch

F71-0015

小板16A四位开关单控 ￥:178.00
16A 4 gang 1 way switch
小板16A四位开关双控 ￥:190.00
16A 4 gang 2 way switch

F71-0016

小板16A三位开关多控
Small panel 16A 3 gang 3 way switch
￥:230.00

F71-0017

小板16A百叶窗升降开关
louver window lifter switch
￥:175.00

F71-0018

小板16A门控开关
gating switch
￥: 142.00

F71-0019

小板16A英式门控开关
British gating switch
￥:142.00

F71-0020

小板16A门铃开关
doorbell switch
￥:142.00

F71-0021

小板16A拨动一位开关单控 ￥:175.00
1 gang 1 way toggle switch
小板16A拨动一位开关双控 ￥:180.00
1 gang 2 way toggle switch

F71-0022

小板16A拨动二位开关单控 ￥:190.00
2 gang 1 way toggle switch
小板16A拨动二位开关双控 ￥:200.00
2 gang 2 way toggle switch

F71-0023

小板16A拨动三位开关单控 ￥:205.00
3 gang 1 way toggle switch
小板16A拨动三位开关双控 ￥:220.00
3 gang 2 way toggle switch

F71-0024

小板16A拨动四位开关单控 ￥:220.00
4 gang 1 way toggle switch
小板16A拨动四位开关双控 ￥:240.00
4 gang 2 way toggle switch

F71-0025

小板20A双极开关带指示灯 ￥:187.00
20A switch with indicator light
小板45A双极开关带指示灯 ￥:226.00
45A swich with indicator light

F71-0026

小板45A双极开关带指示灯
45A switch with indicator light
￥:226.00

F71-0027

小板16A卷帘门复位开关
Shutter reset switch
￥:195.00

F71-0028

小板16A德式插座
German socket
￥:163.00

F71-0029

小板16A法式插座
French socket
￥:163..00

F71-0030

小板16A俄式插座
Russian socket
￥:163.00

F71-0031

小板16A以色列插座
Israel socket
￥:175.00

F71-0032

小板16A意大利+德式插座
Italy+German socket
￥:175.00

F71-0033

大板16A三极插座
16A 3 pole socket
￥:130.00

F71-0034

大板10A二三极插座
10A 5 pole socket
￥:125.00

F71-0035

大板10A错位二三极插座
10A Two or three pole socket
￥:130.00

F71-0036

大板10A二二三极插座
10A 7 pole socket
￥:135.00

F71-0037

小板16A一位开关单控带16A三极插座
1 gang 1 way switch and 16A 3 pole socket
￥:160.00
小板16A一位开关双控带16A三极插座
1 gang 2 way switch and 16A 3 pole socket
￥:163.00

F71-0038

大板一位开关单控带10A二三极插座
1 gang 2 way switch and 5 pole socket
￥:160.00
大板一位开关双控带10A二三极插座
1 gang 2 way switch and 5 pole socket
￥:163.00

F71-0039

小板10A二位开关单控带二三极插座
2 gang 1 way switch and 5 pole socket
￥:180.00
小板10A二位开关双控带二三极插座
2 gang 2 way switch and 5 pole socket
￥:186.00

F71-0040

小板10A二极插座
10A 2 pole socket
￥:140.00

F71-0041

小板10A二二极插座
10A Double 2 pole socket
￥:155.00

F71-0042

小板10A一位开关带二极插座
1 gang switch and 2 pole socket
￥:155.00

F71-0043

小板10A一位开关带二二极座
1gang switch and 4 pole socket
￥:165.00

F71-0044

小板16A多功能三极插座
16A 3 pin universal socket
￥:138.00

F71-0045

小板13A二三极多功能插座
5 pin multi-function socket
￥:156.00

F71-0046

小板13A二三极错位多功能插座
5 pin multi-function socket
￥:166.00

F71-0047

小板13A方角插座
13A square corner socket
￥:138.00

F71-0048

小板15A圆角插座
15A 3 round pins socket
￥:155.00

F71-0049

小板15A美标扁三极插座
15A triode flat American standard socket
￥:158.00

F71-0050

小板15A泰式多功能三极插座
15A Thai type multi-function 3 pole socket
￥:158.00

F71-0051

小板错位泰式六孔插座
Dislocation Thai 6 pin socket
￥:165.00

F71-0052

小板一位开关带13A方角插座
1 gang switch and 13A square pin socket
￥:158.00

F71-0053

小板一位开关带15A圆孔插座
1 gang switch and 15A 3 round pins socket
￥:163.00

F71-0054

小板一位开关带16A多功能插座
1 gang switch and 3 pin MF socket
￥:163.00

F71-0055

小板一位开关带13A方角插座（带指示灯）
1 gang switch and 13A square pin socket
￥:158.00

F71-0056

小板一位开关带15A圆孔插座（带指示灯）
1 gang switch and 15A 3 round pins socket
￥:163.00

F71-0057

小板一位开关带16A多功能插座（带指示灯）
1 gang switch and 3 pin MF socket(with neon)
￥:163.00

F71-0058

小板一位开关带13A多功能五孔插座（带指示灯）
1 gang switch and 5 pin multi-function socket
￥:178.00

F71-0059

小板16A德式插座带二位USB
2 USB with German socket
￥:255.00

F71-0060

小板16A法式插座带二位USB
2 USB with French socket
￥:255.00

F71 Baking paint gray 玻璃爵士黑

F71-0061

小板16A德式插座+USB/Type-c
Small board 16A German socket + USB / type-c
¥:230.00

F71-0062

小板16A法式插座+USB/Type-c
Small board 16A French socket + USB / type-c
¥:230.00

F71-0063

小板16A一位开关带德式插座
1 gang German socket
¥:175.00

F71-0064

小板16A一位开关带法式插座
1 gang French socket
¥:175.00

F71-0065

小板16A德式插座带防水
German socket and Waterproof belt
¥:175.00

F71-0066

小板16A法式插座带防水
French socket and Waterproof belt
¥:175.00

F71-0067

小板二位USB带13A方角插座（横）
2 USB with 13A square corner socket with switch
¥:230.00

F71-0068

小板15A美标插座带USB+TYPE-C
American Standard with USB+type-C
¥:230.00

F71-0069

小板15A泰式插座带USB+TYPE-C
15A Thai MF socket with USB+type-C
¥:230.00

F71-0070

小板二位USB带13A方角插座（带保护门）
2 USB with 13A square corner socket with flip cover
¥:265.00

F71-0071

小板二位USB带13A多功能插座（带保护门）
2 USB with 3 pin multi-purpose socket with flip cover
¥:265.00

F71-0072

小板一位开关带二位USB带13A多功能插座（带指示灯）
1 gang switch with two USB and 13A multi-function socket
¥:240.00

F71-0073

小板一位开关带二位USB带13A方角插座（带指示灯）
2 USB with 13A a quare comer socket with flip cover
¥:240.00

F71-0074

小板13A多功能带Type-c+USB
13A multifunction with type-C + USB
¥:230.00

F71-0075

小板13A方插带Type-c+USB
13A square angle band type-C + USB
¥:230.00

F71-0076

小板一位开关13A多功能插座带Type-c+USB(带指示灯)
1 gang switch 13A multi-purpose socket with Type-c+USB(with light)
¥:240.00

F71-0077

小板二位USB带13A多功能插座带小开关（竖）
2 USB with Three very multi-purpose socket with switch
¥:240.00

F71-0078

小板一位开关13A方插带Type-c+USB(带指示灯)
1 gang switch 13A square insert belt Type-c+USB(with light)
¥:240.00

F71-0079

小板二位USB带13A方角插座带小开关（竖）
2 USB with 13A square corner socket with switth
¥:240.00

F71-0080

小板15A泰式多功能插座带二位USB
15A Thai multi-function socket with 2-bit USB
¥:230.00

F71-0081

小板15A泰式+2USB
15A Thai + 2USB
¥:230.00

F71-0082

小板二位USB带13A多功能插座（横）
2 USB with 3 pin multi-purpose socket
¥:230.00

F71-0083

小板二位USB带10A二三极插座
2 USB and 5 pin socket
¥:220.00

F71-0084

小板二位USB带10A二三极插座带开关
2 USB and 5 pin socket with switch
¥:230.00

F71-0085

10A二三极五孔带USB+TYPE-C 2.1A
10A 5 pole socket with USB+type-c 2.1A
¥:240.00
10A二三极五孔带USB+TYPE-C 4A
10A 5 pole socket with USB+type-c 4A
¥:360.00

F71-0086

小板一位开关带13A多功能五孔插座带USB
1 gang switch and 5 pin multi-function socket with USB and indicator light
¥:290.00

F71-0087

小板13A二位USB带多功能五孔插座
2 USB with 5 pin multi-function socket
¥:230.00

F71-0088

小板13A二位USB带多功能五孔插座带开关
2 USB with 5 pin multi-function socket with switch
¥:240.00

F71-0089

小板13A多功能五孔带USB+Type-c 2.1A
13A MF 5 pin socket with USB+type-c 2.1A
¥:240.00
小板13A多功能五孔带USB+Type-c 4A
13A MF 5 pin socket with USB+type-c 4A
¥:360.00

F71-0090

小板一位电视插座
TV socket
¥:155.00

F71-0091

小板一位电话插座 telephone socket ¥:155.00
小板一位电脑插座 computer socket ¥:165.00
小板一位电脑插座(超六类) computer socket(6) ¥:218.00

F71-0092

小板双电视插座
Two TV socket
¥:175.00

F71-0093

小板双电话插座 Two telephone socket ¥:175.00
小板双电脑插座 Two computer socket ¥:195.00
小板双电脑插座(超六类) Two computer socket(6) ¥:245.00
小板电话电脑插座 telephone+computer socket ¥:185.00
小板电话电脑插座(超六类) telephone+computer socket(6) ¥:235.00

F71-0094

小板电视电话插座 TV + telephone socket ¥:175.00
小板电视电脑插座 TV + computer socket ¥:185.00
小板电视电脑插座(超六类) TV + computer socket(6) ¥:235.00

F71-0095

小板电话带USB插座 TEL + USB socket ¥:320.00
小板电脑带USB插座 computer + USB socket ¥:320.00
小板电脑带USB插座(超六类) computer + USB socket(6) ¥:370.00

F71-0096

小板一位TV+FM
TV and FM
¥:230.00

F71-0097

小板一位卫星插座
Satellite socket
¥:165.00

F71-0098

小板二位卫星插座
Double satellite socket
¥:195.00

F71-0099

小板卫星+电视插座
Satellite and TV socket
¥:185.00

F71-0100

小板卫星带电话插座 Satellite and telephone socket ¥:185.00
小板卫星带电脑插座 Satellite and computer socket ¥:195.00
小板卫星带电脑插座(超六类) Satellite and computer socket(6) ¥:245.00

F71-0101

小板二极插座带电视插座
2 pin socket with TV
¥:320.00

F71-0102

小板二极插座带电话插座 2 pin socket with telephone ¥:320.00
小板二极插座带电脑插座 2 pin socket with computer ¥:320.00
小板二极插座带电脑插座(超六类) 2 pin socket with computer ¥:370.00

F71-0103

小板一位光纤插座
Optical fiber socket
¥:195.00

F71-0104

小板二位USB插座
Double USB socket
¥:265.00

F71-0105

小板单联音响插座
Single audio socket
¥:225.00

F71-0106

小板双联音响插座
Double audio socket
¥:305.00

F71-0107

触摸延时开关（节能）
Touch delay delay switch (energy saving)
¥:225.00

F71-0108

声光控延时开关（节能）
Sound-light controlled delay switch (energy saving)
¥:225.00

F71-0109

红外线人体感应开关
Human body induction
¥:300.00

F71-0110

凹型地脚灯(亮光/暖光)
The footlights
¥:260.00

F71-0111

凹型红外线人体感应地脚灯(亮光/暖光)
The human body induction footlights
¥:330.00



F71-0112

平面地脚灯(亮光/暖光)
Footlights
¥:260.00

F71-0113

叮咚门铃
Ding dong doorbell
¥:291.00

F71-0114

机械式40A插卡取电 Mechanical card for electricity ¥:320.00
感应式低频40A插卡取电 Low frequency induction card for electricity ¥:490.00
感应式高频40A插卡取电 High frequency induction card for electricity ¥:590.00

F71-0115

紧急呼叫开关
Emergency call switch
¥:280.00

F71-0116

请勿打扰请即清理门铃开关（按键式）
Do not disturb, please namely cleaning please + later doorbell "button"
¥:323.00

F71-0117

请勿打扰门铃开关(按键式)
Do not disturb + doorbell "button"
¥:475.00

F71-0118

请勿打扰请即清理门铃开关(按键式)
Do not disterb please namely cleaning please "button"
¥:475.00

F71-0119

智能音乐控制开关
Intelligent music control switch
¥:750.00

F71-0120

温度控制调节开关
Temperature control switch
¥:780.00

F71 Baking paint gray 玻璃爵士黑

F71-0121

温度控制调节开关
Temperature control switch
¥:930.00

F71-0122

调音开关
Tuning switch
¥:300.00

F71-0123

调光开关300W ¥:220.00
Dimming 300W
调光开关600W ¥:250.00
Dimming 600W
调光开关1000W ¥:280.00
Dimming 1000W

F71-0124

调速开关300W ¥:220.00
Speed 300W
调速开关600W ¥:250.00
Speed 600W
调速开关1000W ¥:280.00
Speed 1000W

F71-0125

一位开关带调光开关500W
1 gang with dimmer switch
¥:235.00

F71-0126

一位开关带调速开关500W
1 gang with speed switch
¥:235.00

F71-0127

13A开关带保险丝（带指示灯）
13A switch with fuse(with neon)
¥:265.00

F71-0128

20A出线柱
20A outgoing post
¥:245.00

F71-0129

剃须插座
Shaving socket
¥:500.00

F71-0130

USB+电脑插座+无线路由
USB+computer socket wireless router
¥:900.00

F71-0131

蓝牙+3.5音频+二位USB+HDMI
Bluetooth audio+3.5+2USB+HDMI
¥:5300.00

F71-0132

HDMI
¥:320.00

F71-0133

USB+TYPE-C
¥:360.00

F71-0134

HDMI+USB
¥:320.00

F71-0135

HDMI+USB+3.5音频
HDMI+USB+3.5
¥:320.00

F71-0136

VGA+USB+3.5音频
VGA+USB +3.5
¥:320.00

F71-0137

AV+3.5音频
AV +3.5
¥:320.00

F71-0138

VGA+AV音频接口
VGA + AV audio interface
¥:320.00

F71-0139

HDMI+AV音频接口
HDMI + AV audio interface
¥:320.00

F71-0140

二分之一AV音频+卫星
Half AV audio interface+
Satellite socket
¥:320.00

F71-0141

二分之一AV音频+USB+3.5音频
Half AV audio interface+USB+3.5
¥:320.00

F71-0142

二分之一VGA+TV
Half VGA+TV
¥:320.00

F71-0143

二分之一VGA+电脑插座
Half VGA+computer socket
¥:320.00

F71-0144

VGA+USB
¥:320.00

F71-0145

VGA+HDMI
¥:320.00

F71-0146

45A出线柱
45A Outlet
¥:275.00

F71-0147

德式插座带开关（WIFI版）
German socket with switch
(WiFi version)
¥:670.00

F71-0148

法式插座带开关（WIFI版）
French socket with switch
(WiFi version)
¥:670.00

F71-0149

13A多功能插座带开关（WIFI版）
13A multi-functional socket with switch
(WiFi version)
¥:700.00

F71-0150

13A方角插座带开关（WIFI版）
13A square corner socket with switch
(WiFi version)
¥:700.00

F71-0151

空白面板
Blank plate
¥:113.00



F71-0152

大板147型二位双极开关带二位13A方角插座
147 type two position bipolar switch with double 13A square socket
¥:295.00



F71-0153

大板147型二位开关带二位13A多功能插座
147 Tow switch and double 13A multi-purpose socket
¥:295.00

F71-0154

大板147型二开双极开关带13A方插+二位USB
147 two bipolar switch and double 13A square plug + 2USB
¥:435.00

F71-0155

大板147型二位开关带13A多功能+二位USB
147 two switch and double 13A MF+2USB socket
¥:435.00

F71-0156

小板147型二位开关单控
147 2 gang 1 way switch
¥:236.00
小板147型二位开关双控
147 2 gang 2 way switch
¥:242.00

F71-0157

小板147型三位开关单控
147 3 gang 1 way switch
¥:256.00
小板147型三位开关双控
147 3 gang 2 way switch
¥:265.00

F71-0158

小板147型四位开关单控
147 4 gang 1 way switch
¥:276.00
小板147型四位开关双控
147 4 gang 2 way switch
¥:288.00

F71-0159

小板147型五位开关单控
147 5 gang 1 way switch
¥:296.00
小板147型 五位开关双控
147 5 gang 2 way switch
¥:311.00

F71-0160

小板147型六位开关单控
147 6 gang 1 way switch
¥:311.00
小板147型六位开关双控
147 6 gang 2 way switch
¥:334.00

F71-0161

小板147型七位开关单控
147 7 gang 1 way switch
¥:336.00
小板147型七位开关双控
147 7 gang 2 way switch
¥:357.00

F71-0162

小板147型八位开关单控
147 8 gang 1 way switch
¥:356.00
小板147型八位开关双控
147 8 gang 2 way switch
¥:380.00

F71-0163

147 二位16A多功能三极插座
147 Double 16A MF socket
¥:276.00

F71-0164

147 二位13A多功能五孔插座
147 Double 5 pin multi-function socket
¥:312.00

F71-0165

小板147型二位15A美标扁插座
147 Double 15A triode flat Ammerican standard socket
¥:310.00

F71-0166

小板147型二位15A泰式三极插座
147 Double 15A triode flat Ammerican standard socket
¥:310.00

F71-0167

147 二位13A方角插座
147 Double 13A square comer
¥:276.00

F71-0168

147 二位15A圆孔插座
147 Double 15A 3 round pins socket
¥:310.00

F71-0169

小板147型二位13A错位多功能五孔插座
147 type Double 13A dislocation multi-function 5 hole socket
¥:332.00

F71-0170

147 二位10A二三极插座
147 Double position two and three pole socket
¥:250.00

F71-0171

147二位开关带二位13A方角插座
147 Tow switch and double 13A square comer socket
¥:285.00

F71-0172

147 二位开关带二位13A多功能插座
147 two switch with double 13A MF socket
¥:285.00

F71-0173

147二位开关带二位五孔多功能插座
147 Tow switch and double 5 pin MF socket
¥:315.00

F71-0174

147 二位开关带二位13A方角插座(带指示灯)
147 Tow switch and double 13A square comer socket with indicator light
¥:295.00

F71-0175

147 二位开关带二位13A多功能插座（带指示灯）
147 Tow switch and double 13A MF socket with light
¥:295.00

F71-0176

147二位开关二位13A方插+二位USB（小板）
147 Tow switch and double 13A square comer socket+2USB
¥:385.00

F71-0177

147二位开关二位13A多功能+二位USB（小板）
147 Tow switch and double 13A MF socket+2USB
¥:385.00

F71-0178

147 二位开关二位13A方插+USB/Type-c
147 two switch double 13A square band lamp+USB/Type-c
¥:385.00

F71-0179

147 二位开关二位13A多功能插带灯+USB/Type-c
147 two switch double 13A MF band lamp+USB/Type-c
¥:385.00

F71-0180

147 二位开关带二位15A圆角插座(带指示灯)
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:326.00

F71 Baking paint gray 玻璃爵士黑

F71-0181

小板147型二位开关带二位13A方角插座(带指示灯)
147 two switch with double 13A square angle socket (with indicator light)
¥:326.00

F71-0182

147型二位剃须插座
147 two shaving socket
¥:680.00

F71-0183

147 45A开关+一位开关16A多功能插座带指示灯（组合厨房开关）
147 kitchen switch
¥:415.00

F71-0184

14745A开关+一位开关13A方角插带指示灯(组合厨房开关)
147 kitchen switch
¥:415.00

F71-0185

147 45A开关+一位开关13A方插带灯(厨房开关)
147 Kitchen switch
¥:415.00

F71-0186

147 45A双极开关带指示灯
147 type 45A bipolar switch
¥:360.00

F71-0187

147 16A二位德式插座
147 Double German socket
¥:326.00

F71-0188

147 16A二位法式插座
147 Double French socket
¥:326.00

F71-0189

147 16A二位德式插座
147 Double Geman socket
¥:326.00

F71-0190

147 16A二位法式插座
147 Double French socket
¥:326.00

F71-0191

147型二位德式带USB+type-c(模块)
147 double German + USB / type-C (module)
¥:510.00

F71-0192

147型二位法式带USB+type-c(模块)
147 double French + USB / type-C (module)
¥:510.00

F71-0193

二位17A德式+二位USB（小板连体）
147 Double German with 2USB
¥:410.00

F71-0194

147二位16A法式+2USB（小板连体）
147 Double French with 2USB
¥:410.00

F71-0195

147 四位USB插座
147 4 USB socket
¥:530.00

F71-0196

147 二位多功能插座+4USB
147 2-bit multi-function socket + 4USB
¥:460.00

F71-0197

147 二位13A方角插座+4USB
147 two bit 13A square socket +4USB
¥:460.00

F71-0198

147 一位13A方角插座+二位USB
13A square corner socket and Two USB
¥:418.00

F71-0199

147 一位16A多功能插座+二位USB插座
16A MF 3 pin socket and 2USB socket
¥:418.00

F71-0200

147型二位开关带二位多功能五孔插座带双USB
147 Tow switch and double 13A 5 pin multi-purpose socket+2USB
¥:415.00

F71-0201

147 二位开关带二位13A多功能五孔插座+2 USB(带指示灯)
147 two position switch with two position 13A multifunction Five hole socket + 2 USB (with indicator)
¥:580.00

F71-0202

147 二位13A多功能五孔插座+四位USB
147 13A double 5 pin multi-function socket+4USB
¥:460.00

F71-0203

147 二位开关二位13A多功能五孔插座+四位USB
147 two switch double 5 pin multi function socket+4USB
¥:480.00

F71-0204

147型二位开关带二位多功能五孔插座带USB+type-c
147 Tow switch and double 15A 3 round pins socket with indicator light
¥:550.00

F71-0205

147型二位开关带二位13A多功能带四位USB（带指示灯）
147 two switch and double 13A MF +4USB socket (with indicator light)
¥:480.00

F71-0206

147型二开带二位13A方插带四位USB
147 type two switch two position 13A square inserting band 4 USB
¥:480.00

F71-0207

147二位13A方插带四位USB
147 type double position 13A square inserting band 4 USB
¥:460.00

F71-0208

147 二位13A多功能+4USB(带盖板)
147 double 13A multi-function + 4USB (with cover plate)
¥:530.00

F71-0209

147型二位13A方插带四位USB(带盖板)
147 double 13A square inserting +4USB socket
¥:530.00

F71-0210

147一开单控带13A多功能五孔插座
147 1 gang 1 way switch with 13A 5 pin MF socket
¥:274.00

F71-0211

147 一开单控带13A方角插座+双USB
147 1 gang 1 way socket with 13A square Angle socket +2USB
¥:348.00

F71-0212

147型一开单控带15A泰式插座
147 one open single control with 15A Thai socket
¥:283. 00

F71-0213

147型一开单控带多功能五孔+双USB插座
147 one open single control and MF 5 pin + 2USB socket
¥:348. 00

F71-0214

147型二位10A二三极五孔带四位USB插座
147 double 10A 5 pin socket + 4 USB with indicator light
¥:440.00

F71-0215

147型二位13A多功能带四位USB带小开关
147 double 13A 3pin multi-function socket + 4USB with small switch
¥:480.00

F71-0216

147型二位13A方插带四位USB带小开关
147 double 13A square plug with 4USB with small switch
¥:480.00

F71-0217

147 二位一开16A多功能带指示灯
147 Tow switch and double 16A MF 3 pin socket with neon
¥:326.00

F71-0218

147二位多功能带四位USB
147 type multi-functional 3 pin socket band 4 USB
¥:460.00

F71-0219

147 16A多功能+万用五孔插座
147 16A MF 3 pin +MF 5 pin socket
¥:295.00

F71-0220

147 10A二二二二极插座
10A 8 pole socket
¥:310.00

F71-0221

147二开单控开关带16A多功能插座
147 two switch single control 16A MF 3 pin socket
¥:276.00

F71-0222

147型二开单控带13A方角插座
147 type double open single control socket with 13A square angle
¥:276.00

F71-0223

147型10A二极带10A二极插座
147 10A two pole with 10A two pole socket
¥:280.00

F71-0224

147型二位一开单控带二位16A三极插座
147 type 2 gang 1 way switch double 16A three pole socket
¥:320.00

F71-0225

147型二位一开单控带二位10A二三极插座
147 type 2 gang 1 way switch double 10A 5 pole socket
¥:320.00

F71-0226

147型二位10A二三极插座 ¥:460.00
带USB+type-c 2.1A
147 type double 10A 5 pole socket USB + type-c 2.1A
147型二位10A二三极插座 ¥:720.00
带USB+type-c 4A
147 type double 10A 5 pole socket USB + type-c 4A

F71-0227

147型二位多功能五孔插座 ¥:460.00
带USB+type-c 2.1A
147 type double 5 pin MF socket USB + type-c 2.1A
147型二位多功能五孔插座 ¥:720.00
带USB+type-c 4A
147 type double 5 pin MF socket USB + type-c 4A

F71-0228

147型13A多功能双USB带多五孔插座
147 type 13A multi-function 2USB with 5 pin multi-functional socket
¥:480.00

F71-0229

147型二位电脑插座带二位USB插座
147 type double computer with 2USB socket
¥:460.00

F71-0230

147型二位电话带二位电脑插座
147 double telephone with double computer socket
¥:390.00

F71-0231

147型 二位电脑插座带16A多功能插座
147 double computer with 16A MF pin socket
¥:333.00

F71-0232

147型二位16A德式插座带防水
147 two position 16A German socket with waterproof
¥:350.00

F71-0233

147型二位16A法式插座带防水
147 two position 16A French socket with waterproof
¥:350.00

F71-0234

147二位开关二位16A德式插座带指示灯+USB/Type-c（小板）
147 double switch double German socket+USB/Type-c with light
¥:550.00

F71-0235

147二位开关二位16A法式插座带指示灯+USB/Type-c（小板）
147 double switch double French socket+USB/Type-c with light
¥:550.00

F71-0236

147二位开关二位16A德式插座（带指示灯）
147 two switch double 16A German socket with light
¥:365.00

F71-0237

147二位开关二位16A法式插座（带指示灯）
147 two switch double 16A French socket with light
¥:365.00

F71-0238

147二位开关二位16A德式插座带指示灯+二位USB（小板）
147 two switch double 16A German socket + 2usb with light
¥:450.00

F71-0239

147二位开关二位16A法式插座带指示灯+二位USB（小板）
147 two switch double 16A French socket +2USB with light
¥:450.00

F71-0240

147型二位空白面板
147 Blank plate
¥:185.00

AB-PC-W-01
二开双联13A英式带
USB/type-c带指示灯
two position switch with
two position 13A square plug
+USB / type-C (indicator)
¥:330.00



AB-PC-W-02
二开双联多三孔带
USB/type-c带指示灯
two position switch with
two position 13A multi-function
+USB / type-C (indicator)
¥:330.00



AB-PC-W-03
二开双联多五孔带USB/type-c
插座带指示灯
two position switch with two
position 5 pin multi-function
+USB / type-C (indicator)
¥:350.00

AB-PC-G-01
二开双联13A英式带
USB/type-c带指示灯
two position switch with
two position 13A square plug
+USB / type-C (indicator)
¥:350.00

AB-PC-G-02
二开双联多三孔带
USB/type-c带指示灯
two position switch with
two position 13A multi-function
+USB / type-C (indicator)
¥:350.00

AB-PC-G-03
二开双联多五孔带USB/type-c
插座带指示灯
two position switch with two
position 5 pin multi-function
+USB / type-C (indicator)
¥:380.00

AB-PC-GR-01
二开双联13A英式带
USB/type-c带指示灯
two position switch with
two position 13A square plug
+USB / type-C (indicator)
¥:350.00.00

AB-PC-GR-02
二开双联多三孔带
USB/type-c带指示灯
two position switch with
two position 13A multi-function
+USB / type-C (indicator)
¥:350.00.00

AB-PC-GR-03
二开双联多五孔带USB/type-c
插座带指示灯
two position switch with two
position 5 pin multi-function
+USB / type-C (indicator)
¥:380.00.00

AB-PC-B-01
二开双联13A英式带
USB/type-c带指示灯
two position switch with
two position 13A square plug
+USB / type-C (indicator)
¥:350.00.00

AB-PC-B-02
二开双联多三孔带
USB/type-c带指示灯
two position switch with
two position 13A multi-function
+USB / type-C (indicator)
¥:350.00.00

AB-PC-B-03
二开双联多五孔带USB/type-c
插座带指示灯
two position switch with two
position 5 pin multi-function
+USB / type-C (indicator)
¥:380.00.00

18W快充每个产品200起订
18W fast charging, starting at 200 for each product

AB-TG-W-01
二开双联13A英式带
USB/type-c带指示灯
two position switch with
two position 13A square plug
+USB / type-C (indicator)
¥:400.00

AB-TG-W-02
二开双联多三孔带
USB/type-c带指示灯
two position switch with
two position 13A multi-function
+USB / type-C (indicator)
¥:400.00

AB-TG-W-03
二开双联多五孔带USB/type-c
插座带指示灯
two position switch with two
position 5 pin multi-function
+USB / type-C (indicator)
¥:430.00

AB-TG-G-01
二开双联13A英式带
USB/type-c带指示灯
two position switch with
two position 13A square plug
+USB / type-C (indicator)
¥:400.00

AB-TG-G-02
二开双联多三孔带
USB/type-c带指示灯
two position switch with
two position 13A multi-function
+USB / type-C (indicator)
¥:400.00

AB-TG-G-03
二开双联多五孔带USB/type-c
插座带指示灯
two position switch with two
position 5 pin multi-function
+USB / type-C (indicator)
¥:430.00

AB-TG-GR-01
二开双联13A英式带
USB/type-c带指示灯
two position switch with
two position 13A square plug
+USB / type-C (indicator)
¥:400.00

AB-TG-GR-02
二开双联多三孔带
USB/type-c带指示灯
two position switch with
two position 13A multi-function
+USB / type-C (indicator)
¥:400.00

AB-TG-GR-03
二开双联多五孔带USB/type-c
插座带指示灯
two position switch with two
position 5 pin multi-function
+USB / type-C (indicator)
¥:430.00

AB-TG-B-01
二开双联13A英式带
USB/type-c带指示灯
two position switch with
two position 13A square plug
+USB / type-C (indicator)
¥:400.00

AB-TG-B-02
二开双联多三孔带
USB/type-c带指示灯
two position switch with
two position 13A multi-function
+USB / type-C (indicator)
¥:400.00

AB-TG-B-03
二开双联多五孔带USB/type-c
插座带指示灯
two position switch with two
position 5 pin multi-function
+USB / type-C (indicator)
¥:430.00

18W快充每个产品200起订
18W fast charging, starting at 200 for each product

酒店门牌系列
Hotel House Number Series

触摸门铃
细腻的触摸手感

多功能钢化玻璃门牌面板，触摸门铃显档次

Touch doorbell
Delicate touch

Multi-functional tempered glass door panel,
touch the doorbell display grade

Voltage：AC220/DC12V
Installation: National Standard 86 Bottom Box

型号: 230
功能(标配): 标志+房号+勿扰+清理+门铃
+已入住(可选+稍后)
面板材质：2.5mm黑色钢化玻璃
(金色、白色加6元)
尺寸：130×230mm
PC 框: 700.00元 / 锌合金: 800.00元
Function (standard configuration): sign +
room number + do not disturb + clean up
+ doorbell+ Checked in (optional + later)
Panel material: 2.5mm black tempered glass
(Gold, white plus RMB 6)
Size: 130×230mm
PC frame: RMB 700.00
Zinc alloy: RMB 800.00

型号: 240
功能(标配): 标志+房号+勿扰+清理+门铃
+已入住(可选+稍后)
面板材质：钢化玻璃
边框材质：不锈钢/金色，银色，玫瑰金
尺寸：140×240mm
钢化玻璃: 800.00元
Function (standard configuration): sign +
room number + do not disturb + clean up
+ doorbell+ Checked in (optional + later)
Panel material: tempered glass
Frame material: stainless steel
/gold, silver, rose gold
Size: 140×240mm
Tempered glass: RMB 800.00

型号: 520
功能(标配): 标志+房号+勿扰+清理+门铃
+已入住(可选+稍后)
面板材质/面盖材质颜色：拉丝不锈钢盖板
银色/透明水晶金色、玫瑰金色、黑色
尺寸：140×240×15mm
银色/透明水晶:1700.00元
玫瑰金色: 1800.00元
Function (standard configuration): sign +
room number + do not disturb + clean up
+ doorbell+ Checked in (optional + later)
Panel material / cover material color: brushed
stainless steel cover Silver/clear crystal gold,
rose gold, black
Size: 140×240×15mm
Silver/clear crystal: RMB 1700.00
Rose gold: RMB 1800.00

型号: XYD-380-1MGBH(特色/定制系列)
功能(标配): 标志+房号+勿扰+清理+门铃
+已入住(可选+稍后)
面板材质：不锈钢/铝精雕
尺寸：130×380×15mm
不锈钢: 2000.00元
铝精雕: 2200.00元
Model: XYD-380-1MGBH
(featured/customized series)
Function (standard configuration): sign +
room number + do not disturb + clean up
+ doorbell+ Checked in (optional + later)
Panel material: stainless steel / aluminum carved
Size: 130×380×15mm
PC frame: RMB 2000.00
Zinc alloy: RMB 2200.00

型号: 380
功能(标配): 标志+房号+勿扰+清理+门铃
+已入住(可选+稍后)
面板材质：2.5mm黑色钢化玻璃(带图案/定制)
边框材质：锌合金边框 银色、金色、玫瑰金
尺寸：130×380mm
锌合金边框(银色): 2000.00元
锌合金边框: 2100.00元
Function (standard configuration): sign +
room number + do not disturb + clean up
+ doorbell+ Checked in (optional + later)
Panel material: 2.5mm black tempered glass
(with pattern/customized)
Frame material: zinc alloy frame silver,
gold, rose gold
Size: 130×380mm
Zinc alloy frame (silver): RMB 2000.00
Zinc alloy frame: RMB2100.00

名称: 黑色不锈钢拉丝(特色/定制系列)
功能(标配): 标志+房号+勿扰+清理
+已入住(可选+稍后)
面板材质：不锈钢/铝精雕
尺寸：300×120mm
不锈钢: 2800.00元
铝精雕: 2900.00元
Name: Black stainless steel wire
drawing (featured/custom series)
Function (standard configuration): sign
+ room number + do not disturb + clean up
+ Checked in (optional + later)
Panel material: stainless steel / aluminum carved
Size: 300×120mm
PC frame: RMB 2800.00
Zinc alloy: RMB 2900.00

型号: 420
功能(标配): 标志+房号+勿扰+清理+门铃
+已入住(可选+稍后)
面板材质：2.5mm黑色钢化玻璃
(金色、白色加6元)
尺寸：140×420mm
PC 框: 1400.00元 / 锌合金: 1500.00元
Function (standard configuration): sign +
room number + do not disturb + clean up
+ doorbell+ Checked in (optional + later)
Panel material: 2.5mm black tempered glass
(Gold, white plus RMB 6)
Size: 140×420mm
PC frame: RMB 1400.00
Zinc alloy: RMB 1500.00

名称: 实木系列
功能(标配): 标志+房号+勿扰+清理+门铃
+已入住(可选+稍后)
面板材质：实木
尺寸：360×90mm
实木: 2500.00元
Name: Solid wood series
Function (standard configuration): sign +
room number + do not disturb + clean up
+ doorbell+ Checked in (optional + later)
Panel material: solid wood
Size: 360×90mm
Solid wood: RMB 2500.00

型号: XYD-810BH/三角形
功能(标配): 标志+房号+勿扰+清理+门铃
面板材质：黑色微晶玻璃
三角形亚克力(上下带射灯)
尺寸：400×110×90mm
黑色微晶玻璃: 2000.00元
Model: XYD-810BH/triangle
Function (standard configuration): sign
+ room number + do not disturb
+ clean up + doorbell
Panel material: black glass-ceramic
Triangular acrylic
(with spotlights on top and bottom)
Size: 400×110×90mm
Black glass-ceramic: RMB 2000.00

*材质款式均可定制
*Material styles can be customized

名称: 130/圆形系列
功能(标配): 标志+房号+勿扰+清理+门铃+已入住(可选+稍后)
面板材质：2mm黑色微晶玻璃(钢化玻璃加10元)
边框材质：不锈钢金色/银色
尺寸：150×150mm
不锈钢银色: 900.00元 / 不锈钢金色: 1000.00元
Name: 130/round series
Function (standard configuration): sign +
room number + do not disturb + clean up
+ doorbell+ Checked in (optional + later)
Panel material: 2mm black crystal glass
(Toughened glass plus RMB10)
Frame material: stainless steel gold/silver
Size: 150×150mm
Stainless steel silver: RMB 900.00
Stainless steel gold: RMB 1000.00

名称: 150/椭圆形系列
功能(标配): 标志+房号+勿扰+清理+门铃+已入住(可选+稍后)
面板材质：2mm黑色微晶玻璃
边框材质：PC金色/银色
尺寸：140×240mm
PC金色/银色:1100.00元
Name: 150/Oval Series
Function (standard configuration): sign +
room number + do not disturb + clean up
+ doorbell+ Checked in (optional + later)
Panel material: 2mm black crystal glass
Frame material: PC gold/silver
Size: 140×240mm
PC gold/silver: RMB 1100.00

名称: 146型
功能(标配): 标志+六位开关(定制款)
面板材质：黑色微晶玻璃
尺寸：86×146mm
黑色微晶玻璃: 1800.00元
Function (standard): logo + six-position switch
(customized)
Panel material: black glass-ceramic
Size: 86×146mm
Black glass-ceramic: RMB 1800.00

型号: 90-1/86系列
功能(标配): 标志+房号+勿扰+清理+门铃
面板材质：黑色钢化玻璃(金色、白色加3元)
边框材质：PC框：银色、玫瑰金色
锌合金框：银色、金色、亮铬
尺寸：86×90mm
无边框: 800.00元 / PC框: 900.00元 / 锌合金框: 1000.00元
Model: 90-1/86 series
Panel material: black tempered glass (gold, white plus 3 yuan)
Frame material: PC frame: silver, rose gold
Zinc alloy frame: silver, gold, bright chrome
Size: 86×90mm
Frameless: RMB 800.00
PC frame: RMB 900.00
Zinc alloy frame: RMB 1000.00

名称: 定制黑色拉丝/不锈钢立体房号
功能(标配): 标志+房号+勿扰+清理+门铃
+已入住(可选+稍后)
面板材质：不锈钢/铝精雕
尺寸：100×300×13mm
不锈钢: 2900.00元
铝精雕: 3100.00元
Name: Customized black drawing/stainless
steel three-dimensional room number
Function (standard configuration): sign +
room number + do not disturb + clean up
+ doorbell+ Checked in (optional + later)
Panel material: stainless steel / aluminum carved
Size: 100×300×13mm
PC frame: RMB 2900.00
Zinc alloy: RMB 3100.00

名称: 指示牌系列
功能(标配): 标志+房号
面板材质：黑色微晶玻璃
尺寸：定制
黑色微晶玻璃: 1700.00元
Name: Sign series
Function (standard configuration): logo + room number
Panel material: black glass-ceramic
Size: customized
Black glass-ceramic: RMB 1700.00

智能开关布线图
Wiring Diagram of Intelligent Switches



隐藏式插座
Concealed socket

高颜值
新体验

生活不做加法，
摒弃繁杂，让它更简单，更惬意

Life does not add,
Get rid of complexity
and make it simpler and
more comfortable

16A大功率插座
16A 3 pole socket

10A五孔插座
10A 5 pole socket

13A英式插座
13A British socket

16A大功率插座
16A 3 pole socket

10A五孔插座
10A 5 pole socket

13A英式插座
13A British socket

16A大功率插座
16A 3 pole socket

10A五孔插座
10A 5 pole socket

13A英式插座
13A British socket

16A大功率插座
16A 3 pole socket

10A五孔插座
10A 5 pole socket

13A英式插座
13A British socket

隐藏式弹起插座
Concealed spring socket

暗盒展示 Cassette display

安装时请将施工时堆积在暗盒内的杂物和灰尘清理干净，
预装暗盒时请务必注意插座的开口方向。

When installing, please clean up the debris and dust accumulated in the cassette during construction.
Please pay attention to the opening direction of the socket when pre-installing the cassette.

整体阻燃　超耐高温　进口材料　安全耐用　锡磷青铜　品质保证

精于型 慧于芯

弧形设计，与地面紧密贴合
优雅大方，更有防水防尘等功能,保障使用安全。

Curved design, close to the ground
Elegant and generous, with waterproof and dust-proof functions to ensure safe use.

A30-B 铝拉丝
多功能五孔插座
尺寸:120mmx120mm
A30-B Aluminum wire drawing
Multifunctional 5-hole socket
size:120mmx120mm
¥:600.00

D11 不锈钢-D
13A方角插座带二极插座
尺寸:120mmx120mm
D11 Stainless steel-D
13A square corner socket with 2-pole socket
size:120mmx120mm
¥:500.00

D11 黑色不锈钢-D
二位15A美标三极扁插座
尺寸:120mmx120mm
D11 Black stainless steel-D
Two 15A American standard 3-pole flat socket
size:120mmx120mm
¥:500.00

D11 不锈钢/铝支架-D
多功能五孔插座
尺寸:120mmx120mm
D11 stainless steel/ aluminum bracket-D
Multifunctional 5-hole socket
size:120mmx120mm
¥:500.00

C30-B 不锈钢/铜拉丝
二位美标插座
尺寸:120mmx120mm
C30-B stainless steel/ copper wire drawing
Two American standard socket
size:120mmx120mm
¥:550.00

M21 不锈钢-C
一位USB插座带德式插座
尺寸:120mmx120mm
M21 stainless steel-C
One USB socket with German socket
size:120mmx120mm
¥:650.00

M15-C 铜
13A方角插座带电脑插座
尺寸:120mmx120mm
M15-C copper
13A square corner socket with computer socket
size:120mmx120mm
¥:630.00

C22-B 铜
五孔插座
尺寸:120mmx120mm
C22-B copper
Five-hole socket
size:120mmx120mm
¥:650.00

A20-B 青古铜
13A方角插座带USB插座
尺寸:120mmx120mm
A20-B Green bronze
13A square corner socket with USB socket
size:120mmx120mm
¥:700.00

C31 铝/铜
多功能五孔插座
尺寸:120mmx120mm
C31 aluminum/copper
Multifunctional five-hole socket
size:120mmx120mm
铝 aluminum ¥:1000.00
铜 copper ¥:1300.00

G20-A 铜
德式插座带电脑插座
尺寸:150mmx150mm
G20-A copper
German socket with computer socket
size:150mmx150mm
¥:800.00

B11-A 不锈钢
USB插座带五孔插座
尺寸:150mmx150mm
B11-A stainless steel
USB socket with five-hole socket
size:150mmx150mm
¥:100.00

T86-E 铜
多功能六孔插座
尺寸:120mmx120mm
T86-E copper
Multifunctional six-hole socket
size:95mmx95mm
¥:100.00

T80-E 不锈钢
五孔插座带电话电脑插座
尺寸:120mmx135mm
T80-E stainless steel
Five-hole socket with telephone and computer socket
size:120mmx135mm
¥:400.00

T80-E 铜
六孔插座带电话电脑插座
尺寸:120mmx135mm
T80-E copper
Six-hole socket with telephone and computer socket
size:120mmx135mm
¥:500.00

T41 铜/双开滑盖-E
十孔插座
尺寸:120mmx120mm
T41 Copper/Double open sliding cover-E
Ten-hole socket
size:120mmx120mm
¥:650.00

F60-E 铝合金-防水式
IP55防水防尘地插
尺寸:120mmx120mm
F60-E Aluminum Alloy-Waterproof
Ip55 waterproof and dustproof plug
size:120mmx120mm
¥:650.00

F60-E 铝合金-防水式
IP55防水防尘地插
尺寸:120mmx120mm
F60-E Aluminum Alloy-Waterproof
Ip55 waterproof and dustproof plug
size:120mmx120mm
¥:650.00

F50-E 铜-防水式
IP55防水防尘地插
尺寸:146mmx146mm
F50-E Copper-Waterproof
Ip55 waterproof and dustproof plug
size:146mmx146mm
¥:1000.00

F60-E 铜-防水式
IP55防水防尘地插
尺寸:146mmx146mm
F60-E Copper-Waterproof
Ip55 waterproof and dustproof plug
size:146mmx146mm
¥:1000.00

F22-E 铜-防水式
螺旋装饰防水地插
尺寸:120mmx120mm
F22-E Copper-Waterproof
Spiral decorative waterproof ground plug
size:120mmx120mm
¥:1200.00

T40 不锈钢-单开滑盖-E
多功能十孔插座
尺寸:120mmx135mm
T40 Stainless Steel-Single Open Slide-E
Multifunctional ten-hole socket
size:120mmx135mm
¥:600.00

T40 不锈钢-单开滑盖-E
十孔插座
尺寸:120mmx135mm
T40 Stainless Steel-Single Open Slide-E
Ten-hole socket
size:120mmx135mm
¥:600.00

G28 铝/**铜**
二位多功能插座
尺寸:146mmx146mm
G28 aluminum/copper
Two multi-function socket
size:120mmx120mm
铝 aluminum ¥:900.00
铜 copper ¥:1000.00

G28 铝/**铜**
二位13A方角插座
尺寸:146mmx146mm
G28 aluminum/copper
Two 13A square corner socket
size:120mmx120mm
铝 aluminum ¥:900.00
铜 copper ¥:1000.00

双德式地板插座-铜
尺寸:146mmx146mm
Double German floor socket-copper
size:146mmx146mm
¥:1100.00

空白面板-铜/不锈钢
尺寸:120mmx120mm
Blank panel-copper/ stainless steel
size:120mmx120mm
铜 copper ¥:240.00
不锈钢 stainless steel ¥:200.00

G80 双联地板插座-铜
德式+八孔插座
尺寸:120mmx220mm
G80 double floor socket-copper
German + eight-hole socket
size:120mmx220mm
¥:1200.00

开启式地板插座 Open floor socket

型号：**K210-E**
名称：开启式双86地插
材质：不锈钢/铜
尺寸：210mmx140mm
颜色：银色/金色
不锈钢 ¥:800.00
铜 ¥:1000.00

Model: **K210-E**
Name: Open type double 86 ground plug
Material: stainless steel/copper
Size: 210mmx140mm
Color: silver/gold
Stainless steel ¥:800.00 Copper ¥:1000.00



型号：**K300-E**
名称：开启式三位86地插
材质：不锈钢/铜
尺寸：300mmx130mm
颜色：银色/金色
不锈钢 ¥:1000.00
铜 ¥:1300.00

Model: **K300-E**
Name: Open type three-position 86 ground plug
Material: stainless steel/copper
Size: 300mmx130mm
Color: silver/gold
Stainless steel ¥:1000.00 Copper ¥:1300.00



型号：**K420-E**
名称：开启式四位86地插
材质：不锈钢/铜
尺寸：420mmx130mm
颜色：银色/金色
不锈钢 ¥:1450.00
铜 ¥:1750.00

Model: **K420-E**
Name: Open type four 86 ground plug
Material: stainless steel/copper
Size: 420mmx130mm
Color: silver/gold
Stainless steel ¥:1000.00
Copper ¥:1300.00



开启式地板插座 Open floor socket

型号：**K550-E**
名称：开启式五位86地插
材质：不锈钢/铜
尺寸：550mmx155mm
颜色：银色/金色
不锈钢 ¥:1950.00
铜 ¥:2250.00

Model: **K550-E**
Name: Open type five-position 86 ground plug
Material: stainless steel/copper
Size: 550mmx155mm
Color: silver/gold
Stainless steel ¥:1950.00
Copper ¥:2250.00



型号：**K250-E**
名称：开启式四位86侧插
材质：不锈钢/铜
尺寸：250mmx220mm
颜色：银色/金色
不锈钢 ¥:1150.00
铜 ¥:1750.00

Model: **K250-E**
Name: Open type four 86 side insert
Material: stainless steel/copper
Size: 250mmx220mm
Color: silver/gold
Stainless steel ¥:1150.00
Copper ¥:1750.00



型号：**K210-E**
名称：开启式四位86平插
材质：不锈钢/铜
尺寸：210mmx210mm
颜色：银色/金色
不锈钢 ¥:1150.00
铜 ¥:1750.00

Model: K210-E
Name: Open type four 86 flat plug
Material: stainless steel/copper
Size: 210mmx210mm
Color: silver/gold
Stainless steel ¥:1150.00
Copper ¥:1750.00



内销地板插功能键 Internal floor insert function key

001
10A 五孔插座
10A Five-hole socket
¥:50.00

002
10A 七孔插座
10A seven-hole socket
¥:60.00

003
10A 十孔插座
10A ten-hole socket
¥:70.00

004
一位USB带10A 五孔插座
One USB with
10A five-hole socket
¥:150.00



005
13A 多功能六孔插座
13A multifunctional
six-hole socket
¥:60.00

006
16A德式插座
16A German socket
¥:80.00

007
16A法式插座
16A French socket
¥:80.00

008
13A方角插座
13A square corner socket
¥:80.00

009
10A 二极插座
10A two pole socket
¥:35.00

010
16A三极插座(空调插)
16A three-pole socket
(air conditioning plug)
¥:60.00

011
10A五孔插座
10A five-hole socket
¥:60.00

012
13A多功能三极插座
13A multi-function
three-pole socket
¥:60.00

013
空白面板
Blank panel
¥:10.00

014
电话插座
Telephone socket
¥:35.00
电脑插座
Computer socket
¥:44.00

015
电话电脑插座
Telephone computer
socket
¥:60.00

016
电视插座
TV socket
¥:36.00

017
卫星插座
Satellite socket
¥:120.00

018
USB插座
USB socket
¥:110.00

019
Sc光纤插座
SC fiber optic socket
¥:120.00

020
视频插座
Video socket
¥:90.00

021
音频插座
Audio socket
¥:100.00

022
耳机免焊
Headphone free welding
¥:90.00

023
话筒插座
Microphone socket
¥:100.00

024
音响插座
Audio socket
¥:100.00

025
HDMI
¥:150.00

026
VGA
¥:150.00

027
AV音频接口
AV audio interface
¥:150.00

028
公卡侬插座
Male cannon socket
¥:150.00

029
母卡侬插座
Female Cannon Socket
¥:130.00

防水盒/开关插座/暗盒 Waterproof box / switch socket / cassette

CY-A085
户外IP66一位
白色/白透明/黑透明
Outdoor IP66 one
White/white transparent/
black transparent
¥:200.00

CY-A086
户外IP66双联
白色/白透明/黑透明
Outdoor IP66 duplex
White/white transparent/
black transparent
¥:280.00

CY-A087
户外IP66(146)
白色/白透明/黑透明
Outdoor IP66(146)
White/white trans
parent/black trans
parent
¥:280.00

CY-A094
新146防水盒
白色/白透明
New 146 waterproof box
White/white transparent
¥:60.00

CY-A001
公牛型
白色带花纹/平面
Bull type
White with pattern/flat
¥:30.00

CY-A002
公牛型
白透明带花纹/平面
Bull type
White transparent
belt pattern/plane
¥:30.00

CY-A004
公牛型
黑透明带花纹/平面
Bull type
Black transparent
belt pattern/plane
¥:30.00

CY-A011
TNC型
黄透明
TNC type
Yellow transparent
¥:35.00

CY-A026
ABB型
香槟色(喷漆)
(喷漆颜色可选)
ABB type
Champagne (spray paint)
(Paint color optional)
¥:50.00

CY-A051
新款118防溅盒二位
白色/白透明/蓝透明
New 118 splash box
two positions
White/white transpare
nt/blue transparent
¥:36.00

CY-A052
新款118防溅盒三位
白色/白透明/蓝透明
New 118 splash box
three positions
White/white transpare
nt/blue transparent
¥:60.00

CY-A053
新款118防溅盒四位
白色/白透明/蓝透明
Four new 118 splash box
White/white transpare
nt/blue transparent
¥:80.00

CY-A057
146防溅盒
白色
white
146 splash box
¥:50.00

CY-A059
新款86双联防溅盒
白色/白透明/蓝透明/茶色透明
New 86 double splash box
White/white transparent/
blue transparent/
Brown transparent
¥:60.00

CY-A076
电热水器漏电保护
插头专用(加高款)
白色/白透明
Special for electric water
heater leakage protection
plug (higher version)
White/white transparent
¥:58.00

CY-B01
新款防水一开
铁中板 单控/双控
The new waterproof
one open
Iron plate single control/
dual control
¥:50.00

CY-B02
新款防水二开
铁中板 单控/双控
New waterproof
two open
Iron plate single control/
dual control
¥:60.00

CY-B03
新款防水三开
铁中板 单控/双控
New waterproof triple
Iron plate single control/
dual control
¥:75.00

CY-B04
新款防水四开
铁中板 单控/双控
New waterproof four open
Iron plate single control/
dual control
¥:90.00

CY-B05
新款防水门铃开关
New waterproof doorbell
switch
¥:80.00

CY-D01
普通型86盖板
白色/聚丙
Ordinary type 86 cover
White/polypropylene
¥:8.00

CY-D05
普通型146盖板
白色
Ordinary 146 cover
White
¥:15.00

CY-G34
墙壁四孔插座
10A 250V~ (充电桩用)
Wall four-hole socket
10A 250V~ (for charging pile)
¥:50.00

CY-G35
墙壁六孔插座
10A 250V~ (充电桩用)
Six-hole wall socket
10A 250V~ (for charging pile)
¥:50.00

CY-D06
146暗装底盒
白色新料/PVC阻燃
146 concealed bottom box
White new material/
PVC flame retardant
¥:30.00

CY-D07
146明装(二位)
白色新料/PVC阻燃
118 cover (two positions)
White new material/
PVC flame retardant
¥:30.00

CY-F03
86明装底盒
白色新料/PVC阻燃
86 surface mounted
bottom box
White new material/
PVC flame retardant
¥:15.00

CY-F02
新86型暗盒
PVC阻燃
New Type 86 Cassette
PVC flame retardant
¥:18.00

CY-F04
118明装底盒二位
PVC阻燃新料ABS
118 exposed bottom box
two positions
PVC flame retardant
new material ABS
¥:25.00

CY-F07
118暗装底盒二位
PVC阻燃
118 concealed bottom box
two positions
PVC flame retardant
¥:25.00

桌面插座 Desktop socket

K530J 黑色/银色
K530J black/silver
¥:1400.00

K522U黑色/银色
K522U black/silver
¥:1050.00

K522黑色/银色
K522 black/silver
¥:900.00

L0219黑色/银色
L0219 black/silver
¥:950.00

AM-175H 拉丝黑/拉丝银
AM-175H brushed black/brushed silver
¥:1250.00

Am145 毛刷款拉丝黑/拉丝银
Am145 brush brushed black/brushed silver
¥:750.00

AM-203G 拉丝黑/拉丝银
AM-203G brushed black/brushed silver
¥:1800.00

AM-700 黑色/银色
AM-700 black/silver
¥:1000.00

AM700F 银色
AM700F silver
¥:1100.00

AM-801 拉丝黑/拉丝银
AM-801 brushed black/brushed silver
¥:3100.00

AM-823 拉丝黑/拉丝银
AM-823 brushed black/brushed silver
¥:3300.00

AM-706 拉丝黑/拉丝银
AM-706 brushed black/brushed silver
¥:1700.00

AM-818 拉丝黑/拉丝银
AM-818 brushed black/brushed silver
¥:4700.00

AM-917 拉丝黑/拉丝银
AM-917 brushed black/brushed silver
¥:2100.00

AM-1702 拉丝黑/拉丝银
AM-1702 brushed black/brushed silver
¥:1600.00

AM-100*100
¥:800.00

AM-1001 黑色/银色
AM-1001 black/silver
¥:1300.00

AM-1702 拉丝黑/拉丝银
AM-1702 brushed black/
brushed silver
¥:1600.00

AM-1302 拉丝黑/拉丝银
AM-1302 brushed black/brushed silver
¥:1000.00

AM-P5 黑色/银色
AM-P5 black/silver
¥:900.00

AM-P6 黑色/银色
AM-P6 black/silver
¥:1000.00

AM-1303 拉丝黑/拉丝银
AM-1303 brushed black/brushed silver
¥:1200.00

AM-1304 拉丝黑/拉丝银
AM-1304 brushed black/brushed silver
¥:1200.00

AM-707 拉丝黑/拉丝银
AM-707 brushed black/brushed silver
¥:1800.00

*特殊材质、功能、尺寸、要求需定制。**以上款式10个起订**
*Special materials, functions, dimensions and requirements need to be customized. **Minimum order of 10 styles above**

手提式工程插座箱 Portable engineering socket box

Tx101
铁箱单五孔A
Iron box single five hole A
¥:250.00

Tx001
铁箱双五孔A
Iron box double five holes A
¥:300.00

Tx102
铁箱单多五孔A
Iron box single multiple
five holes A
¥:260.00

Tx002
铁箱双多五孔A
Iron box double multiple
five holes A
¥:310.00

Tx103
铁箱单多六孔A
Iron box single multiple
six holes A
¥:270.00

Tx003
铁箱双多六孔A
Iron box double more
six holes A
¥:320.00

Tx104
铁箱单七孔A
Iron box single seven hole A
¥:260.00

Tx004
铁箱双七孔A
Iron box double
seven holes A
¥:310.00

Tx105
铁箱单[16A]A
Iron box list [16A]A
¥:250.00

Tx005
铁箱双[16A]A
Iron box double[16A]A
¥:300.00

Tx106
铁箱单USB五孔A
Iron box single USB
five hole A
¥:340.00

Tx006
铁箱双USB五孔A
Iron box double USB
five holes A
¥:400.00

Tx103
铁箱单USB多五孔A
Iron box single USB more
than five holes A
¥:350.00

Tx204
铁箱双USB多五孔A
Iron box double USB
more five holes A
¥:410.00

Tx301
铁箱单欧式插座A
Iron box single European
socket A
¥:320.00

Tx201
铁箱双欧式插座A
Iron box double European
socket A
¥:370.00

Tx302
铁箱单英式插座A
Iron box single British
socket A
¥:320.00

Tx206
铁箱双英式插座A
Iron box double British
socket A
¥:370.00

Tx303
铁箱单英式13A插座A
Iron box single British
13A socket A
¥:320.00

Tx202
铁箱双英式13A插座A
Iron box double British
13A socket A
¥:370.00

Tx304
铁箱单英式15A插座A
Iron box single British
15A socket A
¥:320.00

Tx203
铁箱双英式15A插座A
Iron box double British
15A socket A
¥:370.00

Tx107
铁箱单工业插座A
Iron box single industrial
socket A
¥:280.00

Tx007
铁箱双工业插座A
Iron box double
industrial socket A
¥:330.00